



---

**HY17M24 Series  
Peripheral Driver  
C Library**

## Table of Contents

<b>1. OVERVIEW .....</b>	<b>16</b>
1.1. C Library Introduction.....	16
1.2. Relative Document.....	16
<b>2. SYS DRIVER.....</b>	<b>17</b>
2.1. Introduction .....	17
2.2. Functions.....	17
2.2.1. Sleep .....	17
2.2.2. Idle.....	18
2.2.3. GIE_Enable .....	18
2.2.4. GIE_Disable .....	19
2.2.5. SYS_ReadI2CGCR .....	19
2.2.6. SYS_ReadBOR2LV .....	19
2.2.7. SYS_ReadSKERR .....	20
2.2.8. SYS_ReadRST.....	20
2.2.9. SYS_ReadIDLE.....	21
2.2.10. SYS_ReadWDT.....	21
2.2.11. SYS_ReadSLEEP .....	22
2.2.12. SYS_ReadBOR.....	22
2.2.13. SYS_ClearSKERR .....	23
2.2.14. SYS_ClearIDLE.....	23
2.2.15. SYS_ClearWDT.....	23
2.2.16. SYS_ClearSLEEP .....	24
2.2.17. SYS_ClearBOR.....	24
2.2.18. CSFON_Enable.....	25
2.2.19. CSFON_Disable .....	25
2.2.20. SKRST_Enable .....	26
2.2.21. SKRST_Disable.....	26
2.2.22. ENBOR2_Enable .....	26
2.2.23. ENBOR2_Disable.....	27
2.2.24. BOR2_RSTMode .....	27
2.2.25. BOR2_INTMode .....	28
2.2.26. BOR_THSelect .....	28
2.2.27. MCLR_Enable .....	29

2.2.28. MCLR_Disable .....	29
<b>3. CLOCK DRIVER .....</b>	<b>31</b>
3.1. Introduction .....	31
3.2. Functions.....	31
3.2.1. CLK_CPUCKOpen .....	31
3.2.2. CLK_XTEnable.....	32
3.2.3. CLK_XTDisable.....	33
3.2.4. CLK_XTSelect.....	33
3.2.5. CLK_HAOEnable .....	33
3.2.6. CLK_HAODisable.....	34
3.2.7. CLK_HAOSelect.....	34
3.2.8. CLK_LPCKSelect .....	35
3.2.9. CLK_OSCSelect.....	35
3.2.10. CLK_DHSCKSelect.....	36
3.2.11. CLK_DMSCKSelect .....	36
3.2.12. CLK_CPUCKSelect.....	37
3.2.13. CLK_ADCCKDivSelect.....	37
3.2.14. CLK_TMBCKSelect.....	38
3.2.15. CLK_TMBCKDivSelect.....	38
<b>4. TIMER/WDT DRIVER .....</b>	<b>40</b>
4.1. Introduction .....	40
4.2. Functions.....	41
4.2.1. WDT_Open.....	41
4.2.2. WDTIE_Enable.....	41
4.2.3. WDTIE_Disable.....	42
4.2.4. WDTIF_IsFlag .....	42
4.2.5. WDTIF_ClearFlag .....	43
4.2.6. WDT_Enable .....	43
4.2.7. WDT_WDTCKDivSelect.....	43
4.2.8. WDT_Clear.....	44
4.2.9. BZ_Enable.....	44
4.2.10. BZ_Disable .....	45
4.2.11. BZ_BZCKSelect .....	45
4.2.12. BZ_CLKSelect.....	46

4.2.13.	TMA_Open .....	46
4.2.14.	TA1IE_Enable .....	47
4.2.15.	TA1IE_Disable.....	47
4.2.16.	TA1IF_IsFlag .....	48
4.2.17.	TA1IF_ClearFlag .....	48
4.2.18.	TA1CIE_Enable.....	49
4.2.19.	TA1CIE_Disable.....	49
4.2.20.	TA1CIF_IsFlag .....	50
4.2.21.	TA1CIF_ClearFlag .....	50
4.2.22.	TMA1Enable.....	50
4.2.23.	TMA1Disable .....	51
4.2.24.	TMA1_CLKSelect.....	51
4.2.25.	TMA1_CLKDiv.....	52
4.2.26.	TMA1ClearSet.....	52
4.2.27.	TMA1_CompSet.....	53
4.2.28.	TMA1_CompSet.....	53
4.2.29.	TMB_Open .....	54
4.2.30.	TMBIE_Enable .....	54
4.2.31.	TMBIE_Disable.....	55
4.2.32.	TMBIF_IsFlag .....	55
4.2.33.	TMBIF_ClearFlag .....	56
4.2.34.	TB1Enable.....	56
4.2.35.	TB1Disable .....	56
4.2.36.	TB1_ModeSelect.....	57
4.2.37.	TB1_TRIG_MODE .....	57
4.2.38.	TB1_ClearTMB1.....	58
4.2.39.	TB1_TC1Select .....	58
4.2.40.	TB1_PWMO1 .....	59
4.2.41.	TB1_PWMO0 .....	59
4.2.42.	TB1_PWM1ModeSelect.....	60
4.2.43.	TB1_PWM0ModeSelect.....	60
4.2.44.	TB1_PWM1_PHASE .....	61
4.2.45.	TB1_PWM0_PHASE .....	61
4.2.46.	TB1C0Set.....	62
4.2.47.	TB1C1Set.....	62
4.2.48.	TB1C2Set.....	63
5.	<b>GPIO DRIVER .....</b>	64

5.1.	Introduction .....	64
5.2.	Functions.....	67
5.2.1.	GPIO_OpenPT1Input .....	67
5.2.2.	GPIO_OpenPT2Input .....	67
5.2.3.	GPIO_OpenPT3Input .....	68
5.2.4.	GPIO_OpenPT1Output .....	69
5.2.5.	GPIO_OpenPT2Output .....	70
5.2.6.	GPIO_OpenPT3Output .....	70
5.2.7.	GPIO_PT1OutputMode .....	71
5.2.8.	GPIO_PT1OutputHigh.....	72
5.2.9.	GPIO_PT1OutputLow .....	72
5.2.10.	GPIO_PT1InputModule .....	73
5.2.11.	GPIO_PT1SETPU .....	73
5.2.12.	GPIO_PT1CLRPU.....	74
5.2.13.	GPIO_PT1SETPUAll .....	75
5.2.14.	GPIO_PT1InputEnable .....	75
5.2.15.	GPIO_PT1InputDisable .....	76
5.2.16.	GPIO_PT1SETDA .....	76
5.2.17.	GPIO_PT1CLRDA .....	77
5.2.18.	GPIO_PT1GET .....	77
5.2.19.	E0IE_Enable .....	78
5.2.20.	E0IE_Disable .....	78
5.2.21.	E0IF_IsFlag .....	79
5.2.22.	E0IF_ClearFlag .....	79
5.2.23.	GPIO_INTEG0Sel .....	80
5.2.24.	E1IE_Enable .....	80
5.2.25.	E1IE_Disable .....	81
5.2.26.	E1IF_IsFlag .....	81
5.2.27.	E1IF_ClearFlag .....	82
5.2.28.	GPIO_INTEG1Sel .....	82
5.2.29.	E2IE_Enable .....	82
5.2.30.	E2IE_Disable .....	83
5.2.31.	E2IF_IsFlag .....	83
5.2.32.	E2IF_ClearFlag .....	84
5.2.33.	INTG12_Edgerise .....	84
5.2.34.	INTG12_Edgefall .....	85
5.2.35.	E3IE_Enable .....	85
5.2.36.	E3IE_Disable .....	85

5.2.37.	E3IF_IsFlag .....	86
5.2.38.	E3IF_ClearFlag .....	86
5.2.39.	INTG13_Edgerise.....	87
5.2.40.	INTG13_Edgefall.....	87
5.2.41.	INTE14_Enable .....	88
5.2.42.	INTE14_Disable .....	88
5.2.43.	INTF14_IsFlag.....	88
5.2.44.	INTF14_ClearFlag .....	89
5.2.45.	INTG14_Edgerise.....	89
5.2.46.	INTG14_Edgefall.....	90
5.2.47.	INTE15_Enable .....	90
5.2.48.	INTE15_Disable .....	90
5.2.49.	INTF15_IsFlag.....	91
5.2.50.	INTF15_ClearFlag .....	91
5.2.51.	INTG15_Edgerise.....	92
5.2.52.	INTG15_Edgefall.....	92
5.2.53.	INTE16_Enable .....	93
5.2.54.	INTE16_Disable .....	93
5.2.55.	INTF16_IsFlag.....	93
5.2.56.	INTF16_ClearFlag .....	94
5.2.57.	INTG16_Edgerise.....	94
5.2.58.	INTG16_Edgefall.....	95
5.2.59.	GPIO_PM10Sel.....	95
5.2.60.	GPIO_PM12Sel.....	96
5.2.61.	GPIO_PM13Sel.....	96
5.2.62.	GPIO_PM15Sel.....	96
5.2.63.	GPIO_PM16Sel.....	97
5.2.64.	GPIO_PT2OutputMode .....	97
5.2.65.	GPIO_PT2OutputHigh.....	98
5.2.66.	GPIO_PT2OutputLow .....	98
5.2.67.	GPIO_PT2InputMode .....	99
5.2.68.	GPIO_PT2SETPU .....	99
5.2.69.	GPIO_PT2CLRPU.....	100
5.2.70.	GPIO_PT2SETPUAI.....	100
5.2.71.	GPIO_PT2InputEnable.....	101
5.2.72.	GPIO_PT2InputDisable.....	101
5.2.73.	GPIO_PT2GET.....	102
5.2.74.	INTE20_Enable .....	102
5.2.75.	INTE20_Disable .....	102

5.2.76.	INTF20_IsFlag.....	103
5.2.77.	INTF20_ClearFlag.....	103
5.2.78.	INTG20_Edgerise.....	104
5.2.79.	INTG20_Edgefall.....	104
5.2.80.	INTE21_Enable .....	105
5.2.81.	INTE21_Disable .....	105
5.2.82.	INTF21_IsFlag.....	105
5.2.83.	INTF21_ClearFlag.....	106
5.2.84.	INTG21_Edgerise.....	106
5.2.85.	INTG21_Edgefall.....	107
5.2.86.	GPIO_PM20Sel.....	107
5.2.87.	GPIO_PM21Sel.....	108
5.2.88.	GPIO_PT3OutputMode.....	108
5.2.89.	GPIO_PT3OutputHigh.....	109
5.2.90.	GPIO_PT3OutputLow .....	109
5.2.91.	GPIO_PT3InputMode.....	110
5.2.92.	GPIO_PT3SETPU.....	111
5.2.93.	GPIO_PT3CLRPU.....	111
5.2.94.	GPIO_PT3SETPUAI.....	112
5.2.95.	GPIO_PT3InputEnable.....	112
5.2.96.	GPIO_PT3InputDisable.....	113
5.2.97.	GPIO_PT3SETDA.....	114
5.2.98.	GPIO_PT3CLRDA.....	114
5.2.99.	GPIO_PT3GET.....	115
5.2.100.	INTE30_Enable .....	115
5.2.101.	INTE30_Disable .....	116
5.2.102.	INTF30_IsFlag.....	116
5.2.103.	INTF30_ClearFlag.....	117
5.2.104.	INTG30_Edgerise.....	117
5.2.105.	INTG30_Edgefall.....	118
5.2.106.	INTE31_Enable .....	118
5.2.107.	INTE31_Disable .....	118
5.2.108.	INTF31_IsFlag.....	119
5.2.109.	INTF31_ClearFlag.....	119
5.2.110.	INTG31_Edgerise.....	120
5.2.111.	INTG31_Edgefall.....	120
5.2.112.	INTE32_Enable .....	120
5.2.113.	INTE32_Disable .....	121
5.2.114.	INTF32_IsFlag.....	121

5.2.115. INTF32_ClearFlag.....	122
5.2.116. INTG32_Edgerise.....	122
5.2.117. INTG32_Edgefall.....	123
5.2.118. INTE33_Enable .....	123
5.2.119. INTE33_Disable .....	123
5.2.120. INTF33_IsFlag.....	124
5.2.121. INTF30_ClearFlag.....	124
5.2.122. INTG33_Edgerise.....	125
5.2.123. INTG33_Edgefall.....	125
5.2.124. INTE34_Enable .....	126
5.2.125. INTE34_Disable .....	126
5.2.126. INTF34_IsFlag.....	126
5.2.127. INTF34_ClearFlag.....	127
5.2.128. INTG34_Edgerise.....	127
5.2.129. INTG34_Edgefall.....	128
5.2.130. INTE35_Enable .....	128
5.2.131. INTE35_Disable .....	128
5.2.132. INTF35_IsFlag.....	129
5.2.133. INTF35_ClearFlag.....	129
5.2.134. INTG35_Edgerise.....	130
5.2.135. INTG35_Edgefall.....	130
5.2.136. INTE36_Enable .....	131
5.2.137. INTE36_Disable .....	131
5.2.138. INTF36_IsFlag.....	131
5.2.139. INTF36_ClearFlag.....	132
5.2.140. INTG36_Edgerise.....	132
5.2.141. INTG36_Edgefall.....	133
5.2.142. INTE37_Enable .....	133
5.2.143. INTE37_Disable .....	133
5.2.144. INTF37_IsFlag.....	134
5.2.145. INTF37_ClearFlag.....	134
5.2.146. INTG37_Edgerise.....	135
5.2.147. INTG37_Edgefall.....	135
5.2.148. GPIO_PM30Sel.....	136
5.2.149. GPIO_PM32Sel.....	136
5.2.150. GPIO_PM33Sel.....	137
5.2.151. GPIO_PM34Sel.....	137
5.2.152. GPIO_PM36Sel.....	137

<b>6. ADC DRIVER .....</b>	<b>139</b>
6.1.    Introduction .....	139
6.2.    Functions.....	139
6.2.1.    ADC_Open .....	140
6.2.2.    ADC_GetData.....	142
6.2.3.    ADC_Enable.....	143
6.2.4.    ADC_Disable.....	143
6.2.5.    ADC_INT_Enable .....	144
6.2.6.    ADC_INT_Disable .....	144
6.2.7.    ADC_INT_IsFlag .....	145
6.2.8.    ADC_INT_ClearFlag .....	145
6.2.9.    ADC_OSRSelect .....	145
6.2.10.    ADC_CMFREnable .....	146
6.2.11.    ADC_CMFRDisable .....	147
6.2.12.    ADC_VRXSelect.....	147
6.2.13.    ADC_GainSelect .....	147
6.2.14.    ADC_DCSETSelect.....	148
6.2.15.    ADC_ENACMEEnable .....	149
6.2.16.    ADC_ENACMDDisable .....	149
6.2.17.    ADC_ACMBufSelect .....	150
6.2.18.    ADC_VINSelect.....	150
6.2.19.    ADC_VRINSelect .....	151
6.2.20.    ADC_INXSelect.....	152
6.2.21.    ADC_ENINXCH_Enable .....	153
6.2.22.    ADC_ENINXCH_Disable.....	153
6.2.23.    ADC_VCMSSelect .....	154
6.2.24.    ADC_REFOISel.....	154
6.2.25.    ADC_ENTPSEnable.....	155
6.2.26.    ADC_ENTPSDisable .....	155
6.2.27.    ADC_TPSSelect .....	155
6.2.28.    ADC_DAFMSelect.....	156
6.2.29.    ADC_ENCH_Enable .....	156
6.2.30.    ADC_ENCH_Disable.....	157
<b>7. UART DRIVER .....</b>	<b>158</b>
7.1.    Introduction .....	158

7.2. Functions.....	159
7.2.1. UART_Open.....	159
7.2.2. UART_BGRSet.....	159
7.2.3. UART_Enable.....	160
7.2.4. UART_Disable.....	160
7.2.5. UART_TXEnable.....	161
7.2.6. UART_TXDisable .....	161
7.2.7. UART_TX9Enable.....	161
7.2.8. UART_TX9Disable .....	162
7.2.9. UART_TX9Data.....	162
7.2.10. UART_Parity.....	163
7.2.11. UART_WUEEnable .....	163
7.2.12. UART_WUEDisable .....	164
7.2.13. UART_CREnable .....	164
7.2.14. UART_CRDDisable.....	165
7.2.15. UART_CR9Enable .....	165
7.2.16. UART_CR9Disable .....	165
7.2.17. UART_ADDEnable .....	166
7.2.18. UART_ADDDisable .....	166
7.2.19. UART_ABDEnable .....	167
7.2.20. UART_ABDDisable .....	167
7.2.21. UART_INT_TXEnable .....	167
7.2.22. UART_INT_TXDisable .....	168
7.2.23. UART_INT_TXIsFlag .....	168
7.2.24. UART_INT_TXClearFlag.....	169
7.2.25. UART_INT_RCEnable .....	169
7.2.26. UART_INT_RCDDisable.....	170
7.2.27. UART_INT_RCIsFlag.....	170
7.2.28. UART_INT_RCClearFlag .....	170
7.2.29. UART_GETRC9 .....	171
7.2.30. UART_GETPERR .....	171
7.2.31. UART_GETFERR .....	172
7.2.32. UART_GETOERR .....	172
7.2.33. UART_GETRCIDL .....	173
7.2.34. UART_GETTRMT .....	173
7.2.35. UART_GETABDOVF .....	174
8. CMP DRIVER .....	175

8.1.	Introduction .....	175
8.2.	Functions.....	175
8.2.1.	CMP_Open.....	175
8.2.2.	CMP_RLOSet.....	176
8.2.3.	CMP_Enable .....	178
8.2.4.	CMP_Disable.....	178
8.2.5.	CMP_CMPResult .....	179
8.2.6.	CMP_PInput.....	179
8.2.7.	CMP_NInput.....	180
8.2.8.	CMP_OutputSelect.....	180
8.2.9.	CMP_OutReverse .....	181
8.2.10.	CMP_2usLPFEnable.....	181
8.2.11.	CMP_2usLPFDisable .....	182
8.2.12.	CMP_MODESel.....	182
8.2.13.	CMP_CPRLOpen .....	183
8.2.14.	CMP_CPRLShort .....	183
8.2.15.	CMP_RLO_VrefSel .....	183
8.2.16.	CMP_R_DASel.....	184
8.2.17.	CMP_CPDMSet.....	185
8.2.18.	CMP_INT_Enable .....	186
8.2.19.	CMP_INT_Disable.....	186
8.2.20.	CMP_INT_IsFlag.....	186
8.2.21.	CMP_INT_ClearFlag .....	187
<b>9.</b>	<b>OPAMP DRIVER .....</b>	<b>188</b>
9.1.	Introduction .....	188
9.2.	Functions.....	188
9.2.1.	OPA_Out2Dig_Open.....	188
9.2.2.	OP1_Enable .....	189
9.2.3.	OP1_Disable .....	190
9.2.4.	OP1_InputShort.....	190
9.2.5.	OP1_INPSet.....	190
9.2.6.	OP1_INN0Set.....	191
9.2.7.	OP1_INN1Set.....	192
9.2.8.	OP1_AnalogyOutSel .....	192
9.2.9.	OP1_DigitalOutEnable .....	193
9.2.10.	OP1_DigitalOutDisable .....	193

9.2.11.	OP1_OutputReverse .....	193
9.2.12.	OP1_10pF_AppSel .....	194
9.2.13.	OP1_FilterEnable .....	194
9.2.14.	OP1_FilterDisable .....	195
9.2.15.	OP1_GAINSelect .....	195
9.2.16.	OP1_GAINSourceSel.....	196
9.2.17.	OP1_INT_Trigger .....	196
9.2.18.	OP1_INT_Enable .....	197
9.2.19.	OP1_INT_Disable .....	197
9.2.20.	OP1_INT_IsFlag.....	198
9.2.21.	OP1_INT_ClearFlag.....	198
<b>10.</b>	<b>PWR DRIVER.....</b>	<b>199</b>
10.1.	Introduction .....	199
10.2.	Functions.....	199
10.2.1.	PWR_VDDAOpen .....	199
10.2.2.	PWR_BGREnable .....	200
10.2.3.	PWR_BGRDisable .....	200
10.2.4.	PWR_LDOEnable .....	201
10.2.5.	PWR_LDODisable.....	201
10.2.6.	PWR_VDDASel.....	201
10.2.7.	PWR_LDOMODE .....	202
10.2.8.	PWR_LDOPLEnable .....	203
10.2.9.	PWR_LDOPLDisable .....	203
10.2.10.	PWR_ENREFOEnable .....	203
10.2.11.	PWR_ENREFODisable .....	204
10.2.12.	PWR_REFOSel .....	204
10.2.13.	PWR_REFOISel .....	205
<b>11.</b>	<b>12-BIT RESISTANCE LADDER DRIVER.....</b>	<b>206</b>
11.1.	Introduction .....	206
11.2.	Functions.....	206
11.2.1.	DAC_Open .....	206
11.2.2.	LADER_DASelect .....	207
11.2.3.	LADDER_DALH_Enable .....	208
11.2.4.	LADDER_DALH_Disable .....	208

11.2.5.	LADDER_DAOE_Enable .....	208
11.2.6.	LADDER_DAOE_Disable.....	209
11.2.7.	LADDER_ENDA_Enable.....	209
11.2.8.	LADDER_ENDA_Disable.....	210
<b>12.</b>	<b>I2C DRIVER .....</b>	<b>211</b>
12.1.	Introduction .....	211
12.2.	Functions.....	211
12.2.1.	I2C_Open .....	212
12.2.2.	I2C_TimeOutOpen .....	212
12.2.3.	I2C_SlaveSet.....	213
12.2.4.	I2C_Ctrl .....	213
12.2.5.	I2CEnable.....	214
12.2.6.	I2CDisable .....	215
12.2.7.	I2C_TimeOutEnable.....	215
12.2.8.	I2C_TimeOutDisable .....	215
12.2.9.	I2C_GCRstEnable .....	216
12.2.10.	I2C_GCRstDisable .....	216
12.2.11.	I2C_SCLCLKSet.....	217
12.2.12.	I2C_SlaveModeEnable.....	217
12.2.13.	I2C_SlaveModeDisable.....	217
12.2.14.	I2C_I2CER_READ .....	218
12.2.15.	I2C_I2CER_CLEAR .....	218
12.2.16.	I2C_MACTF_READ .....	219
12.2.17.	I2C_SACTF_READ .....	219
12.2.18.	I2C_RDBF_READ .....	220
12.2.19.	I2C_RWF_READ.....	220
12.2.20.	I2C_DFF_READ .....	221
12.2.21.	I2C_ACKF_READ .....	221
12.2.22.	I2C_GCF_READ .....	221
12.2.23.	I2C_ARBF_READ .....	222
12.2.24.	I2C_I2CTF_READ .....	222
12.2.25.	I2C_I2CTF_CLEAR.....	223
12.2.26.	I2C_TimeOutCLKSel.....	223
12.2.27.	I2C_TimeOutCYCSel .....	224
12.2.28.	I2C_SendData .....	225
12.2.29.	I2C_ReceiveData .....	225

12.2.30. I2C_INT_Enable .....	226
12.2.31. I2C_INT_Disable .....	226
12.2.32. I2C_INT_IsFlag .....	226
12.2.33. I2C_INT_ClearFlag .....	227
12.2.34. I2C_ERINT_Enable .....	227
12.2.35. I2C_ERINT_Disable .....	228
12.2.36. I2C_ERINT_IsFlag .....	228
12.2.37. I2C_ERINT_ClearFlag .....	229
<b>13. BIE DRIVER .....</b>	<b>230</b>
13.1. Introduction .....	230
13.2. Functions.....	230
13.2.1. BIE2_Enable.....	230
13.2.2. BIE2_Disable.....	230
13.2.3. BIE2_DataWrite.....	231
13.2.4. BIE2_Clear .....	231
13.2.5. BIE2_DataRead.....	232
<b>14. LIBRARY.....</b>	<b>233</b>
14.1. Library File .....	233
<b>15. REVISION HISTORY .....</b>	<b>234</b>
<b>16. LIBRARY CHANGE LIST .....</b>	<b>235</b>

Attention :

- 1、 HYCON Technology Corp. reserves the right to change the content of this datasheet without further notice. For most up-to-date information, please constantly visit our website : <http://www.hycontek.com> .
- 2、 HYCON Technology Corp. is not responsible for problems caused by figures or application circuits narrated herein whose related industrial properties belong to third parties.
- 3、 Specifications of any HYCON Technology Corp. products detailed or contained herein stipulate the performance, characteristics, and functions of the specified products in the independent state. We does not guarantee of the performance, characteristics, and functions of the specified products as placed in the customer's products or equipment. Constant and sufficient verification and evaluation is highly advised.
- 4、 Please note the operating conditions of input voltage, output voltage and load current and ensure the IC internal power consumption does not exceed that of package tolerance. HYCON Technology Corp. assumes no responsibility for equipment failures that resulted from using products at values that exceed, even momentarily, rated values listed in products specifications of HYCON products specified herein.
- 5、 Notwithstanding this product has built-in ESD protection circuit, please do not exert excessive static electricity to protection circuit.
- 6、 Products specified or contained herein cannot be employed in applications which require extremely high levels of reliability, such as device or equipment affecting the human body, health/medical equipments, security systems, or any apparatus installed in aircrafts and other vehicles.
- 7、 Despite the fact that HYCON Technology Corp. endeavors to enhance product quality as well as reliability in every possible way, failure or malfunction of semiconductor products may happen. Hence, users are strongly recommended to comply with safety design including redundancy and fire-precaution equipments to prevent any accidents and fires that may follow.
- 8、 Use of the information described herein for other purposes and/or reproduction or copying without the permission of HYCON Technology Corp. is strictly prohibited.

# 1. Overview

## 1.1.C Library Introduction

This document describes the HYCON™ HY17M24 Series driver reference manual. System-level software developers can use the HYCON™ HY17M24 Series driver to do the fast application software development, instead of using the register level programming, which can reduce the total development time significantly.

## 1.2.Relative Document

User can find the following documents in our website for other relative information.

<http://www.hycontek.com/>

- (1)HYCON HY17M24 Series Data Sheet
- (2)HYCON HY17M24 Series User's Guide
- (3)HYCON HY17M24 Series Hardware TOOL User Manual
- (4)HYCON HY17M24 Series Software TOOL User Manual

## 2. SYS Driver

### 2.1. Introduction

The following functions are included in System Manager Section.

Item	Functions	Description
01	Sleep	Enable low power Sleep Mode
02	Idle	Enable low power Idle Mode
03	GIE_Enable	Enable GIE
04	GIE_Disable	Disable GIE
05	SYS_ReadI2CGCR	Read I2C Reset flag(GCRstIF)
06	SYS_ReadBOR2LV	ReadBOR2 flag of data(BOR2LV)
07	SYS_ReadSKERR	Read SKERR flag(SKERR)
08	SYS_ReadRST	Read reset flag of data (RST)
09	SYS_ReadIDLE	Read Idle Flag (IDL)
10	SYS_ReadWDT	Read watch dog flag (TO)
11	SYS_ReadSLEEP	Read Sleep Flag (PD)
12	SYS_ReadBOR	Read BOR flag of data (BOR)
13	SYS_ClearSKERR	Clear SKERR flag
14	SYS_ClearIDLE	Clear Idle Flag
15	SYS_ClearWDT	Clear watch dog flag
16	SYS_ClearSLEEP	Clear Sleep Flag
17	SYS_ClearBOR	Clear BOR flag
18	CSFON_Enable	Enable CSF(Chip Special Function)controller
19	CSFON_Disable	Disable CSF controller
20	SKRST_Enable	Enable SKRST function
21	SKRST_Disable	Disable SKRST function
22	ENBOR2_Enable	Enable BOR2 function
23	ENBOR2_Disable	Disable BOR2 function
24	BOR2_RSTMode	Select the reset mode of BOR2
25	BOR2_INTMode	Select the interrupt mode of BOR2
26	BOR_THSelect	Set voltage of BOR detection
27	MCLR_Enable	Enable hardware reset pin
28	MCLR_Disable	Disable hardware reset pin

### 2.2. Functions

#### 2.2.1. Sleep

- **Prototype**

    Sleep();

- **Description**

    Enable low power Sleep Mode.

- **Parameters**

- None
- **Include**  
Driver/HY17M/HY17M24/RST.h
- **Return Value**  
None
- **Example**  
/\* Enable Sleep Mode. Before enable Sleep Mode, disable no use function. \*/  
Sleep();

### 2.2.2. Idle

- **Prototype**  
Idle();
- **Description**  
Enable low power Idle Mode.
- **Parameters**  
None
- **Include**  
Driver/HY17M/HY17M24/RST.h
- **Return Value**  
None
- **Example**  
/\* Enable Idle Mode. Before enable Idle Mode, disable no use function. \*/  
Idle();

### 2.2.3. GIE\_Enable

- **Prototype**  
GIE\_Enable();
- **Description**  
Enable GIE.
- **Parameters**  
None
- **Include**  
Driver/HY17M/HY17M24/RST.h
- **Return Value**  
None
- **Example**  
/\* Enable GIE \*/  
GIE\_Enable();

#### **2.2.4. GIE\_Disable**

- **Pro]otype**

```
GIE_Disable();
```

- **Description**

Disable GIE.

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Disable GIE */  
GIE_Disable();
```

#### **2.2.5. SYS\_ReadI2CGCR**

- **Prototype**

```
SYS_ReadI2CGCR();
```

- **Description**

Read I2C Reset flag of data.

Read the value of register PSTAT[0].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

0 : Normal

1 : The I2C has reset

- **Example**

```
/* Read I2C Reset flag of data. */  
unsigned char temp_flag;  
temp_flag= SYS_ReadI2CGCR();
```

#### **2.2.6. SYS\_ReadBOR2LV**

- **Prototype**

```
SYS_ReadBOR2LV();
```

- **Description**

Read BOR2 flag of data.

Read the value of register PSTAT[1].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

0 : VDD >BOR\_TH[2:0]

1 : VDD <=BOR\_TH[2:0]

- **Example**

```
/* Read BOR2 flag of data. */  
unsigned char temp_flag;  
temp_flag= SYS_ReadBOR2LV();
```

## 2.2.7. SYS\_ReadSKERR

- **Prototype**

SYS\_ReadSKERR();

- **Description**

Read Stack Error flag(SKERR) of data.

Read the value of register PSTAT[2].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

0 : Clear by BOR, RST or command.

1 : stack has error.

- **Example**

```
/* Read SKERR flag of data. */  
unsigned char temp_flag;  
temp_flag= SYS_ReadSKERR();
```

## 2.2.8. SYS\_ReadRST

- **Prototype**

SYS\_ReadRST();

- **Description**

Read external reset pin flag(RST) of data.

Read the value of register PSTAT[3].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

0 : Normal

1 : The Reset Pin has reset

- **Example**

```
/* Read reset flag of data*/  
unsigned char flag;  
flag=SYS_ReadRST();
```

### 2.2.9. SYS\_ReadIDLE

- **Prototype**

SYS\_ReadIDLE();

- **Description**

Read Idle flag(RST) of data.

Read the value of register PSTAT[4].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

0 : Clear by BOR, RST or command.

1 : Chip has entered Idle Mode

- **Example**

```
/* Read Idle flag of data*/  
unsigned char flag;  
flag=SYS_ReadIDLE();
```

### 2.2.10. SYS\_ReadWDT

- **Prototype**

SYS\_ReadWDT();

- **Description**

Read watch dog flag(TO) of data.

Read the value of register PSTAT[5].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

0 : Clear by BOR, RST or command.

1 : Watch dog has triggered

- **Example**

```
/* Read watch dog flag of data. */  
unsigned char flag;  
flag=SYS_WdogFlagRead();  
flag=SYS_ReadIDLE();
```

## 2.2.11. SYS\_ReadSLEEP

- **Prototype**

```
SYS_ReadSLEEP();
```

- **Description**

Read Sleep Flag.

Read the register PSTAT[6]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/RST.h
```

- **Return Value**

0 : Clear by BOR, RST or command.

1 : Chip has entered Sleep Mode

- **Example**

```
/* Read Sleep Flag. */  
SYS_ReadSLEEP();
```

## 2.2.12. SYS\_ReadBOR

- **Prototype**

```
SYS_ReadBOR();
```

- **Description**

Read BOR flag of data.

Read the value of register PSTAT[7].

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/RST.h
```

- **Return Value**

0 : Normal, clear by command.

1 : BOR has triggered

- **Example**

```
/* Read BOR flag of data. */  
unsigned char flag;  
flag=SYS_ReadBOR();
```

### **2.2.13. SYS\_ClearSKERR**

- **Prototype**

SYS\_ClearSKERR();

- **Description**

Clear Stack Error flag.

Clear the value of register PSTAT[2].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Clear SKERR flag. */  
SYS_ClearSKERR();
```

### **2.2.14. SYS\_ClearIDLE**

- **Prototype**

SYS\_ClearIDLE();

- **Description**

Clear Idle flag.

Clear the value of register PSTAT[4].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Clear Idle flag */  
SYS_ClearIDLE();
```

### **2.2.15. SYS\_ClearWDT**

- **Prototype**

SYS\_ClearWDT();

- **Description**

Clear watch dog flag  
Clear the register PSTAT[5]

- **Parameters**

None

- **include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Clear watch dog flag */  
SYS_ClearWDT();
```

## 2.2.16. SYS\_ClearSLEEP

- **Prototype**

SYS\_ClearSLEEP();

- **Description**

Clear Sleep flag  
Clear the register PSTAT[6]

- **Parameters**

None

- **include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Clear Sleep flag */  
SYS_ClearSLEEP();
```

## 2.2.17. SYS\_ClearBOR

- **Prototype**

SYS\_ClearBOR();

- **Description**

Clear BOR flag  
Clear the value of register PSTAT[7]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Clear BOR flag */  
SYS_ClearBOR;
```

## 2.2.18. CSFON\_Enable

- **Prototype**

```
CSFON_Enable();
```

- **Description**

Enable CSF(Chip Special Function) controller, user must set CSFON[0] before control register CSFCN0 and CSFCN1

Configure the register PWRCN[0]=1

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/RST.h
```

- **Return Value**

None

- **Example**

```
/* Enable CSF */  
CSFON_Enable();
```

## 2.2.19. CSFON\_Disable

- **Prototype**

```
CSFON_Disable();
```

- **Description**

Disable CSF(Chip Special Function) controller.

Clear the register PWRCN[0]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/RST.h
```

- **Return Value**

None

- **Example**

```
/* Disable CSF */  
CSFON_Disable();
```

### **2.2.20. SKRST\_Enable**

- **Prototype**

```
SKRST_Enable();
```

- **Description**

Enable stack error reset function.

Configure the register CSFCN0[7]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Enable stack error reset function */  
CSFON_Enable();  
SKRST_Enable();
```

### **2.2.21. SKRST\_Disable**

- **Prototype**

```
SKRST_Disable();
```

- **Description**

Disable stack error reset function.

Clear the register CSFCN0[7].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Disable stack error reset function */  
CSFON_Disable();  
SKRST_Disable();
```

### **2.2.22. ENBOR2\_Enable**

- **Prototype**

```
ENBOR2_Enable();
```

- **Description**

Enable BOR2 voltage detecting function

Configure the register CSFCN1[0]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Enable BOR2 voltage detecting function */  
CSFON_Enable();  
ENBOR2_Enable();
```

## 2.2.23. ENBOR2\_Disable

- **Prototype**

ENBOR2\_Disable();

- **Description**

Disable BOR2 voltage detecting function.

Clear the register CSFCN1[0]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Disable BOR2 voltage detecting function */  
CSFON_Enable();  
ENBOR2_Disable();
```

## 2.2.24. BOR2\_RSTMode

- **Prototype**

BOR2\_RSTMode();

- **Description**

Enable BOR2 reset mode.

Configure the register CSFCN1[1]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Enable BOR2 reset mode. */  
CSFON_Enable();  
BOR2_RSTMode();
```

### 2.2.25. BOR2\_INTMode

- **Prototype**

BOR2\_INTMode();

- **Description**

Enable BOR2 interrupt mode.

Clear the register CSFCN1[1]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Enable BOR2 interrupt mode. */  
CSFON_Enable();  
BOR2_INTMode();
```

### 2.2.26. BOR\_THSelect

- **Prototype**

BOR\_THSelect(sel);

- **Description**

Select BOR detection of voltage.

Configure the register CSFCN1[4:2]

- **Parameters**

sel [in] : BOR\_TH[2:0]

- BORTH\_4V0 : When the battery uses 1.5V\*4, voltage below 4.0V(=1.0V\*4) means low voltage
- BORTH\_3V65 : When the battery uses 1.5V\*4, voltage below 3.6V(=0.9V\*4) means low voltage
- BORTH\_3V0 : When the battery uses 1.5V\*3, voltage below 3V(=1.0V\*3) means low voltage
- BORTH\_2V75 : When the battery uses 1.5V\*3, voltage below 2.7V(=0.9V\*3) means low voltage
- BORTH\_2V5 : for VDDA=2.4V mode, VDD>=2.45V
- BORTH\_2V2 :

BORTH\_2V0 : When the battery uses 1.5V\*2, voltage below 2V(=1.0V\*2) means low voltage

BORTH\_1V7 : Chip power on preset

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Set BOR_TH=3.65V. */  
CSFON_Enable();  
BOR_THSelect(BORTH_3V65);
```

### 2.2.27. MCLR\_Enable

- **Prototype**

MCLR\_Enable();

- **Description**

Enable hardware reset pin, set PT1.0 as RST pin.

Configure the register CSFCN1[7]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Enable MCLR. */  
CSFON_Enable();  
MCLR_Enable();
```

### 2.2.28. MCLR\_Disable

- **Prototype**

MCLR\_Disable();

- **Description**

Disable hardware reset pin, set PT1.0 as GPIO pin.

Clear the register CSFCN1[7]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/RST.h

- **Return Value**

None

- **Example**

```
/* Disable MCLR. */
```

```
CSFON_Enable();
```

```
MCLR_Disable();
```

## 3. CLOCK Driver

### 3.1. Introduction

The following functions are included in Clock Manager Section.

Item	Functions	Description
01	CLK_CPUCKOpen	Open a high-speed oscillator
02	CLK_XTEnable	Enable external oscillator
03	CLK_XTDisable	Disable external oscillator
04	CLK_XTSelect	Select frequency of external oscillator
05	CLK_HAOEnable	Enable HAO oscillator
06	CLK_HAODisable	Disable HAO oscillator
07	CLK_HAOSelect	Select frequency of HAO oscillator
08	CLK_LPCKSelect	Select the source of LPC Clock
09	CLK_OSCSelect	Select clock source of the chip
10	CLK_DHSCKSelect	Select DHS clock frequency
11	CLK_DMSCKSelect	Select DMS clock frequency
12	CLK_CPUCKSelect	Select source of CPU clock
13	CLK_ADCCKDivSelect	Select ADC clock frequency
14	CLK_TMBCKSelect	Select TMB clock frequency
15	CLK_TMBCKDivSelect	Select DTMB clock frequency

### 3.2. Functions

#### 3.2.1. CLK\_CPUCKOpen

- **Prototype**

```
void CLK_CPUCKOpen(unsigned char haom,
                    unsigned char oscs,
                    unsigned char dhsck,
                    unsigned char cpuck)
```

- **Description**

Open a high-speed oscillator, select HAO, CPU clock, DHS\_CK clock source.

Configure the register OSCCN0[7:0]

- **Parameter**

haom [in] : Configure frequency of HAO oscillator

HAOM\_17510KHZ : 17.51MHz  
HAOM\_8755KHZ : 8.557MHz  
HAOM\_4147KHZ : 4.147MHz  
HAOM\_1843KHZ : 1.843MHz

oscs [in] : Select clock source of the chip

OSCS\_HAO : HAO  
OSCS\_LPO : LPO  
OSCS\_XT : External oscillator

dhsck [in] : Configure DHS clock frequency

DHS\_HSCKDIV8 : HS\_CK/8  
DHS\_HSCKDIV4 : HS\_CK/4  
DHS\_HSCKDIV2 : HS\_CK/2  
DHS\_HSCKDIV1 : HS\_CK/1

cpuck [in] : Select CPU\_CK clock source

CPUS\_DHSCK : DHS\_CK  
CPUS\_HSCK : HS\_CK

- **Include**

Driver/HY17M/HY17M24/CLK.h

- **Return Value**

None

- **Example**

```
/* Configure HAO frequency to 1.843MHz and use it as the chip clock source, DHS clock frequency to
HS_CK/1, and CPU clock source to DHS_CK */
CLK_CPUCKOpen(HAOM_1843KHZ, OSCS_HAO, DHS_HSCKDIV1, CPUS_DHSCK );
```

### 3.2.2. CLK\_XTEnable

- **Prototype**

CLK\_XTEnable()

- **Description**

Enable external oscillator

Configure the register OSCCN2[5]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/CLKL.h

- **Return Value**

None

- **Example**

```
/* Enable external oscillator */
```

```
CLK_XTEnable();
```

### 3.2.3. CLK\_XTDisable

- **Prototype**

```
CLK_XTDisable()
```

- **Description**

Disable external oscillator

Clear the register OSCCN2[5]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/CKL.h
```

- **Return Value**

None

- **Example**

```
/* Disable external oscillator */
```

```
CLK_XTDisable();
```

### 3.2.4. CLK\_XTSelect

- **Prototype**

```
CLK_XTSelect(XTSel)
```

- **Description**

Select external oscillator frequency

Clear the register OSCCN2[4:3]

- **Parameter**

XTSel [in] : Select external oscillator frequency

XTS\_16M : 2~16MHz

XTS\_2M : 2MHz(low power)

XTS\_32768 : 32768Hz

- **Include**

```
Driver/HY17M/HY17M24/CKL.h
```

- **Return Value**

None

- **Example**

```
/*Select 2M Hz of external oscillator */
```

```
CLK_XTSelect(XTS_2M);
```

### 3.2.5. CLK\_HAOEnable

- **Prototype**

- CLK\_HAODisable()
- **Description**  
Enable HAO oscillator  
Clear the register OSCCN2[0]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/CLK.h
- **Return Value**  
None
- **Example**  
/\* Disable HAO oscillator\*/  
`CLK_HAODisable();`

## 3.2.6. CLK\_HAODisable

- **Prototype**  
CLK\_HAOEnable()
- **Description**  
Enable HAO oscillator  
Configure the register OSCCN2[0]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/CLK.h
- **Return Value**  
None
- **Example**  
/\* Enable HAO oscillator\*/  
`CLK_HAOEnable();`

## 3.2.7. CLK\_HAOSelect

- **Prototype**  
CLK\_HAOSelect(HAOSel)
- **Description**  
Select frequency of HAO oscillator  
Configure the register OSCCN2[2:1]
- **Parameter**  
HAOSel [in] : Select HAO oscillator frequency

HAOM\_17510KHZ : 17.51MHz  
HAOM\_8755KHZ : 8.557MHz  
HAOM\_4147KHZ : 4.147MHz  
HAOM\_1843KHZ : 1.843MHz

- **Include**

Driver/HY17M/HY17M24/CLK.h

- **Return Value**

None

- **Example**

```
/* Select 1.843M Hz as HAO oscillator */  
CLK_HAOSelect(HAOM_1843KHZ);
```

### 3.2.8. CLK\_LPCKSelect

- **Prototype**

CLK\_LPCKSelect(LPCKSel)

- **Description**

Select the source of LPC Clock

Configure register OSCCN1[6]

- **Parameter**

LPCKSel [in] : Select the source of LPC Clock

LCPS\_XT : External oscillator XT

LCPS\_LPO : Low-speed oscillator LPO

- **Include**

Driver/HY17M/HY17M24/CLK.h

- **Return Value**

None

- **Example**

```
/* Select the LPC Clock from LPO */  
CLK_LPCKSelect(LCPS_LPO);
```

### 3.2.9. CLK\_OSCSelect

- **Prototype**

CLK\_OSCSelect(OSCSel)

- **Description**

Select clock source of the chip

Configure the register OSCCN0[7:6]

- **Parameter**

OSCSel [in] : Select clock source of the chip

OSCS\_HAO : High-speed oscillator HAO  
OSCS\_LPO : Low-speed oscillator LPO  
OSCS\_XT : External oscillator XT

- **Include**

Driver/HY17M/HY17M24/CLK.h

- **Return Value**

None

- **Example**

```
/*Select HAO oscillator as the chip clock */  
CLK_OSCSelect(OSCS_HAO);
```

### 3.2.10. CLK\_DHSCKSelect

- **Prototype**

CLK\_DHSCKSelect (DHSCKSel)

- **Description**

Select DHS clock frequency.

Configure the register OSCCN0[5:4]

- **Parameter**

DHSCKSel [in] : Select DHS\_CK frequency from HS\_CK Pre-scale

DHS\_HSCKDIV1 : HS\_CK÷1  
DHS\_HSCKDIV2 : HS\_CK÷2  
DHS\_HSCKDIV4 : HS\_CK÷4  
DHS\_HSCKDIV8 : HS\_CK÷8

- **Include**

Driver/HY17M/HY17M24/CLK.h

- **Return Value**

None

- **Example**

```
/* Select HS_CK and Pre-scale 1 as DHS_CK*/  
CLK_DHSCKSelect (DHS_HSCKDIV1);
```

### 3.2.11. CLK\_DMSCKSelect

- **Prototype**

CLK\_DMSCKSelect(DMSCKSel)

- **Description**

Select DMS clock frequency

Configure the register OSCCN0[3:1]

- **Parameter**

DMSCKSel [in] : Select DMS\_CK frequency from DHS\_CK and Pre-scale

DMS_DHSCKDIV2	: DHS_CK÷2
DMS_DHSCKDIV4	: DHS_CK÷4
DMS_DHSCKDIV8	: DHS_CK÷8
DMS_DHSCKDIV16	: DHS_CK÷16
DMS_DHSCKDIV32	: DHS_CK÷32
DMS_DHSCKDIV64	: DHS_CK÷64
DMS_DHSCKDIV128	: DHS_CK÷128
DMS_DHSCKDIV256	: DHS_CK÷256

- **Include**

Driver/HY17M/HY17M24/CLK.h

- **Return Value**

None

- **Example**

```
/* Select DHS_CK and Pre-scale 2 as DMS clock */  
CLK_DMSCKSelect(DMS_DHSCKDIV2);
```

### 3.2.12. CLK\_CPUCKSelect

- **Prototype**

CLK\_CPUCKSelect(CPUCKSel)

- **Description**

Select source of CPU clock

Configure the register OSCCN0[0].

- **Parameter**

CPUCKSel [in] : Select source of CPU clock

CPUS\_DHSCK : DHS\_CK

CPUS\_HSCK : HS\_CK

- **Include**

Driver/HY17M/HY17M24/CLK.h

- **Return Value**

None

- **Example**

```
/* Select DHS_CK as the CPU clock */  
CLK_CPUCKSelect(CPUS_DHSCK);
```

### 3.2.13. CLK\_ADCCKDivSelect

- **Prototype**

CLK\_ADCCKDivSelect(DADCSEL)

- **Description**

- Select source of ADC clock
- Configure the register OSCCN1[5:4].
- **Parameter**  
DADCSEL [in] : Select DHS\_CK and Pre-scale as ADC clock
  - DADC\_DHSCKDIV2 : DHS\_CK÷2
  - DADC\_DHSCKDIV4 : DHS\_CK÷4
  - DADC\_DHSCKDIV8 : DHS\_CK÷8
  - DADC\_DHSCKDIV16 : DHS\_CK÷16
- **Include**  
Driver/HY17M/HY17M24/CLK.h
- **Return Value**  
None
- **Example**

```
/* Select DHS_CK and Pre-scale 2 as ADC clock */  
CLK_ADCCKDivSelect(DADC_DHSCKDIV2);
```

## 3.2.14. CLK\_TMBCKSelect

- **Prototype**  
CLK\_TMBCKSelect(TMBCKSel)
- **Description**  
Select source of Timer B clock  
Configure the register OSCCN1[1].
- **Parameter**  
TMBCKSel [in] : Select source of TMB
  - TMBS\_LPCCK : LPC\_CK
  - TMBS\_HSCK : HS\_CK
- **Include**  
Driver/HY17M/HY17M24/CLK.h
- **Return Value**  
None
- **Example**

```
/* Select HS_CK as TMB clock */  
CLK_TMBCKSelect(TMBS_HSCK);
```

## 3.2.15. CLK\_TMBCKDivSelect

- **Prototype**  
CLK\_TMBCKDivSelect(TMBCKDivSel)
- **Description**  
Select Timer B frequency from TMB\_CK and Pre-scale

Configure the register OSCCN1[3:2].

- **Parameter**

TMBCKSel [in] : Select DTMB\_CK frequency

DTMB\_TMBCKDIV1 : TMB\_CK÷1

DTMB\_TMBCKDIV2 : TMB\_CK÷2

DTMB\_TMBCKDIV4 : TMB\_CK÷4

- **DTMB\_TMBCKDIV8 : TMB\_CK÷8**

- **Include**

Driver/HY17M/HY17M24/CLK.h

- **Return Value**

None

- **Example**

```
/* Select TMB_CK and Pre-scale 1 as DTMB_CK frequency */
```

```
CLK_TMBCKDivSelect(TMB_CK÷1);
```

## 4. TIMER/WDT Driver

### 4.1. Introduction

The following functions are included in Timer Manager Section.

Item	Functions	Description
01	WDT_Open	Enable watchdog timer and set time-out interval
02	WDTIE_Enable	Enable WDT interrupt
03	WDTIE_Disable	Disable WDT interrupt
04	WDTIF_IsFlag	Read the WDT interrupt flag
05	WDTIF_ClearFlag	Clear the WDT interrupt flag
06	WDT_Enable	Enable WDT function
07	WDT_WDTCKDivSelect	Set the WDT time-out interval
08	WDT_Clear	Clear WDT count value
09	BZ_Enable	Enable buzzer function
10	BZ_Disable	Disable buzzer function
11	BZ_BZCKSelect	Select buzzer output frequency
12	BZ_CLKSelect	Select source of buzzer clock
13	TMA_Open	Enable timerA ,set counter value and clock source of TMA
14	TA1IE_Enable	Enable Timer-A interrupt function
15	TA1IE_Disable	Disable Timer-A interrupt function
16	TA1IF_IsFlag	Read the TMA interrupt flag
17	TA1IF_ClearFlag	Clear the TMA interrupt flag
18	TA1CIE_Enable	Enable TMA compare interrupt function
19	TA1CIE_Disable	Disable TMA compare interrupt function
20	TA1CIF_IsFlag	Read the TMA compare interrupt flag
21	TA1CIF_ClearFlag	Clear the TMA compare interrupt flag
22	TMA1Enable	Enable Timer-A function
23	TMA1Disable	Disable Timer-A function
24	TMA1_CLKSelect	Select clock source of TMA
25	TMA1_CLKDiv	Select TMA count frequency
26	TMA1ClearSet	Clear TMA1_CK and DTMA1_CK counter
27	TMA1_CompSet	Set TMA compare value
28	TMA1_CompSet	Clear TMA counter value
29	TMB_Open	Enable Timer-B ,set counter value, clock source and trigger source of TMB
30	TMBIE_Enable	Enable Timer-B interrupt function
31	TMBIE_Disable	Disable Timer-B interrupt function
32	TMBIF_IsFlag	Read the TMB interrupt flag
33	TMBIF_ClearFlag	Clear the TMB interrupt flag
34	TB1Enable	Enable Timer-B function
35	TB1Disable	Disable Timer-B function
36	TB1_ModeSelect	Select TMB mode
37	TB1_TRIG_MODE	Select TMB trigger source
38	TB1_ClearTMB1	Clear TMB counter value
39	TB1_TC1Select	Select source of CPI1 input
40	TB1_PWMO1	Configure the PWMO1 output function
41	TB1_PWMO0	Configure the PWMO0 output function
42	TB1_PWM1ModeSelect	Select the PWM1 output mode
43	TB1_PWM0ModeSelect	Select the PWM0 output mode

44	TB1_PWM1_PHASE	Set the PWM1output phase
45	TB1_PWM0_PHASE	Set the PWM0 output phase
46	TB1C0Set	Set TMB counter value
47	TB1C1Set	Set PWM0/PWM1 count condition parameter
48	TB1C2Set	Set PWM0/PWM1 count condition parameter

## 4.2. Functions

### 4.2.1. WDT\_Open

- **Prototype**

```
Void WDT_Open(unsigned char wdts)
```

- **Description**

Enable watchdog timer(WDT) and set time-out interval.

Configure the register WDTCN[2:0]

- **Parameter**

wdts [in] : set the WDT time-out interval

DWDT_WDTCKDIV16384	:	WDT_CK÷16384
DWDT_WDTCKDIV8192	:	WDT_CK÷8192
DWDT_WDTCKDIV4096	:	WDT_CK÷4096
DWDT_WDTCKDIV2048	:	WDT_CK÷2048
DWDT_WDTCKDIV64	:	WDT_CK÷64
DWDT_WDTCKDIV32	:	WDT_CK÷32
DWDT_WDTCKDIV16	:	WDT_CK÷16
DWDT_WDTCKDIV8	:	WDT_CK÷8

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None

- **Example**

```
/* Open WDT function and set time-out interval WDT_CK÷32 */
```

```
WDT_Open (DWDT_WDTCKDIV32);
```

### 4.2.2. WDTIE\_Enable

- **Prototype**

```
WDTIE_Enable()
```

- **Description**

Enable WDT interrupt.

Configure the register INTE0[4]=1

- **Parameter**

- None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None.
- **Example**  
/\* Enable WDT interrupt. \*/  
WDTIE\_Enable();

#### **4.2.3. WDTIE\_Disable**

- **Prototype**  
WDTIE\_Disable()
- **Description**  
Disable WDT interrupt.  
Clear the register INTE0[4]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None.
- **Example**  
/\* Disable WDT interrupt. \*/  
WDTIE\_Disable();

#### **4.2.4. WDTIF\_IsFlag**

- **Prototype**  
WDTIF\_IsFlag()
- **Description**  
Read the WDT interrupt flag.  
Read the register INTF0[4]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
0 : Normal  
1 : WDT has overflowed.
- **Example**

```
/* Read the WDT interrupt flag. */  
unsigned char flag;  
flag = WDTIF_IsFlag();
```

#### 4.2.5. WDTIF\_ClearFlag

- **Prototype**

WDTIF\_ClearFlag()

- **Description**

Clear the WDT interrupt flag.

Clear the register INTF0[4]=0.

- **Parameter**

None.

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None.

- **Example**

```
/* Clear the WDT interrupt flag. */  
WDTIF_ClearFlag();
```

#### 4.2.6. WDT\_Enable

- **Prototype**

WDT\_Enable()

- **Description**

Enable WDT function.

Configure the register WDTCN[3]=1.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None.

- **Example**

```
/* Enable WDT function. */  
WDT_Enable();
```

#### 4.2.7. WDT\_WDTCKDivSelect

- **Prototype**

WDT\_WDTCKDivSelect(Sel)

- **Description**

Set the WDT time-out interval.

Configure the register WDTCN[2:0]

- **Parameter**

Sel [in] : select time-out interval.

DWDT_WDTCKDIV16384	:	WDT_CK÷16384
DWDT_WDTCKDIV8192	:	WDT_CK÷8192
DWDT_WDTCKDIV4096	:	WDT_CK÷4096
DWDT_WDTCKDIV2048	:	WDT_CK÷2048
DWDT_WDTCKDIV64	:	WDT_CK÷64
DWDT_WDTCKDIV32	:	WDT_CK÷32
DWDT_WDTCKDIV16	:	WDT_CK÷16
DWDT_WDTCKDIV8	:	WDT_CK÷8

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None.

- **Example**

```
/* Set WDT time-out interval WDT_CK÷32. */  
WDT_WDTCKDivSelect(WDT_CK÷32);
```

## 4.2.8. WDT\_Clear

- **Prototype**

WDT\_Clear()

- **Description**

Clear WDT count value.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None.

- **Example**

```
/* Clear WDT count. */  
WDT_Clear();
```

## 4.2.9. BZ\_Enable

- **Prototype**

BZ\_Enable()

- **Description**

Enable buzzer function.

Configure the register WDTCN[7]=1.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None

- **Example**

```
/* Enable buzzer function */
```

```
BZ_Enable();
```

## 4.2.10. BZ\_Disable

- **Prototype**

```
BZ_Disable()
```

- **Description**

Disable buzzer function.

Clear the register WDTCN[7].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None

- **Example**

```
/* Disable buzzer function. */
```

```
BZ_Disable();
```

## 4.2.11. BZ\_BZCKSelect

- **Prototype**

```
BZ_BZCKSelect(Sel)
```

- **Description**

Select buzzer output frequency.

Configure the register WDTCN[5:4].

- **Parameter**

Sel [in] : Select buzzer output frequency

DBZ\_DZCKDIV2 : Output frequency is BZ\_CK÷2

DBZ\_DZCKDIV4 : Output frequency is BZ\_CK÷4  
DBZ\_DZCKDIV8 : Output frequency is BZ\_CK÷8  
DBZ\_DZCKDIV16 : Output frequency is BZ\_CK÷16

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None

- **Example**

```
/* Select BZ_CK and pre-scale 4 as buzzer output frequency */  
BZ_BZCKSelect(DBZ_DZCKDIV4);
```

## 4.2.12. BZ\_CLKSelect

- **Prototype**

BZ\_CLKSelect(Sel)

- **Description**

Select source of buzzer clock.

Configure the register WDTCN[6]

- **Parameter**

Sel [in] : Select source of buzzer clock.

BZS\_LPCCK : LPC\_CK

BZS\_LSCK : LS\_CK

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None

- **Example**

```
/* Select LPC_CK as buzzer clock source. */  
BZ_CLKSelect(BZS_LPCCK);
```

## 4.2.13. TMA\_Open

- **Prototype**

void TMA\_Open(unsigned char ck ,unsigned char cks ,unsigned char tma\_cmp)

- **Description**

Enable timer A, set counter value and clock source of TMA.

Configure the register TMA1CN[7:2].

- **Parameter**

ck [in] : TMA clock(TMA1\_CK) source

TMAS1\_DMSCK : From DMS\_CK

TMAS1\_LPCCK : From LPC\_CK  
cks [in] : TMA count frequency  
DTMA1\_TMA1CKDIV2 : TMA1\_CK ÷ 2  
DTMA1\_TMA1CKDIV4 : TMA1\_CK ÷ 4  
DTMA1\_TMA1CKDIV8 : TMA1\_CK ÷ 18  
DTMA1\_TMA1CKDIV16 : TMA1\_CK ÷ 16  
DTMA1\_TMA1CKDIV32 : TMA1\_CK ÷ 32  
DTMA1\_TMA1CKDIV64 : TMA1\_CK ÷ 64  
DTMA1\_TMA1CKDIV128 : TMA1\_CK ÷ 128  
DTMA1\_TMA1CKDIV256 : TMA1\_CK ÷ 256  
tma\_cmp [in] : TMA compare value(TMA1C) : 0x00~0xFF

- **Include**

Driver/HY17M/HY17M24/WDT.h

- **Return Value**

None

- **Example**

/\* Clear Timer A. \*/

DrvTMA\_ClearTMA();

#### 4.2.14. TA1IE\_Enable

- **Prototype**

TA1IE\_Enable()

- **Description**

Enable Timer-A interrupt function .

Configure the register INTE1[7]=1.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

/\* Enable Timer-A interrupt function \*/

TA1IE\_Enable();

#### 4.2.15. TA1IE\_Disable

- **Prototype**

TA1IE\_Disable()

- **Description**

- Disable Timer-A interrupt function.
- Clear the register INTE1[7].
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**

```
/* Disable Timer-A interrupt function. */  
TA1IE_Disable();`
```

## 4.2.16. TA1IF\_IsFlag

- **Prototype**  
TA1IF\_IsFlag()
- **Description**  
Read the TMA interrupt flag.  
Read the register INTF1[7]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
0 : No interrupt  
1 : Interrupt occurred
- **Example**

```
/* Read the TMA interrupt flag. */  
unsigned char flag ;  
flag = TA1IF_IsFlag();
```

## 4.2.17. TA1IF\_ClearFlag

- **Prototype**  
TA1IF\_ClearFlag()
- **Description**  
Clear the TMA interrupt flag.  
Clear the register INTF1[7].
- **Parameter**  
None
- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear Timer-A interrupt flag */  
TA1IF_ClearFlag();
```

## 4.2.18. TA1CIE\_Enable

- **Prototype**

TA1CIE\_Enable()

- **Description**

Enable TMA compare interrupt function.

Configure the register INTE0[6]=1.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable TMA compare interrupt function. */  
TA1CIE_Enable();
```

## 4.2.19. TA1CIE\_Disable

- **Prototype**

TA1CIE\_Disable()

- **Description**

Disable TMA compare interrupt function.

Clear the register INTE0[6].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable TMA compare interrupt function. */  
TA1CIE_Disable();
```

#### **4.2.20. TA1CIF\_IsFlag**

- **Prototype**

TA1CIF\_IsFlag()

- **Description**

Read the TMA compare interrupt flag.

Read the register INTF0[6].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the TMA compare interrupt flag. */  
unsigned char flag ;  
flag = TA1CIF_IsFlag();
```

#### **4.2.21. TA1CIF\_ClearFlag**

- **Prototype**

TA1CIF\_ClearFlag()

- **Description**

Clear the TMA compare interrupt flag.

Clear the register INTF0[6].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear Timer-A compare interrupt flag */  
TA1CIF_ClearFlag();
```

#### **4.2.22. TMA1Enable**

- **Prototype**

TAM1Enable()

- **Description**

Enable Timer-A function.

Configure the register TMA1CN[7]=1.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Enable Timer-A function. */
```

```
TMA1Enable();
```

## 4.2.23. TMA1Disable

- **Prototype**

```
TAM1Disable()
```

- **Description**

Disable Timer-A function.

Clear the register TMA1CN[7].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Disable Timer-A function. */
```

```
TMA1Disable();
```

## 4.2.24. TMA1\_CLKSelect

- **Prototype**

```
TMA1_CLKSelect(Sel)
```

- **Description**

Select clock source of TMA.

Configure the register TMA1CN[5].

- **Parameter**

ck [in] : Select clock source of TMA(TMA1\_CK).

TMAS1\_DMSCK : DMS\_CK

TMAS1\_LPCCK : LPC\_CK

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Select DMS_CK as TMA1_CK clock source */  
TMA1_CLKSelect(TMDS1_DMS);
```

## 4.2.25. TMA1\_CLKDiv

- **Prototype**

TMA1\_CLKDiv(Sel)

- **Description**

Select TMA count frequency.

Configure the register TMA1CN[4:2].

- **Parameter**

cks [in] : Select TMA count frequency

DTMA1_TMA1CKDIV2	:	TMA1_CK / 2
DTMA1_TMA1CKDIV4	:	TMA1_CK / 4
DTMA1_TMA1CKDIV8	:	TMA1_CK / 18
DTMA1_TMA1CKDIV16	:	TMA1_CK / 16
DTMA1_TMA1CKDIV32	:	TMA1_CK / 32
DTMA1_TMA1CKDIV64	:	TMA1_CK / 64
DTMA1_TMA1CKDIV128	:	TMA1_CK / 128
DTMA1_TMA1CKDIV256	:	TMA1_CK / 256

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Set TMA count frequency is TMA1_CK / 16 */  
TMA1_CLKDiv( TMA1_CK / 16);
```

## 4.2.26. TMA1ClearSet

- **Prototype**

TMA1ClearSet()

- **Description**

Clear TMA1\_CK and DTMA1\_CK counter.

Configure the register TMA1CN[6].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Clear TMA1_CK and DTMA1_CK counter */  
TMA1ClearSet();
```

## 4.2.27. TMA1\_CompSet

- **Prototype**

TMA1\_CompSet(Set)

- **Description**

Set TMA compare value(TMA1C). When the TMA1R value is added to the same as TMA1C, the TA1CIF flag is set to 1.

Configure the register TMA1C[7:0].

- **Parameter**

Set [in] : 0x00~0xFF

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Set TAM1C is 0x0f.*/  
TMA1_CompSet(0x0f);
```

## 4.2.28. TMA1\_CompSet

- **Prototype**

TMA1\_CompSet(Set)

- **Description**

Clear TMA counter value(TMA1R).

Clear the register TMA1R[7:0].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Clear TMA1R value. */  
TMA1_ClearTMA1();
```

#### 4.2.29. TMB\_Open

- **Prototype**

```
void TMB_Open( unsigned char ck,  
                unsigned char cks,  
                unsigned char mode,  
                unsigned char trig_mode)
```

- **Description**

Enable Timer-B ,set counter value, clock source and trigger source of TMB

Configure the register TB1CN0[7:0].

- **Parameter**

ck [in] : Selcet TMB clock source

TMBS\_LPCCK : LPC\_CK

TMBS\_HSCK : HS\_CK

cks [in] : Select TMB clock frequency

DTMB\_TMBCKDIV1 : TMB\_CK÷1

DTMB\_TMBCKDIV2 : TMB\_CK÷2

DTMB\_TMBCKDIV4 : TMB\_CK÷4

DTMB\_TMBCKDIV8 : TMB\_CK÷8

mode [in] : Select TMB mode

TB1M\_16bit : 16-bit Timer

TB1M\_17bit : 17-bit Timer

TB1M\_2\_8bit : two 8-bit Timer

TB1M\_8\_8bit : 8+8-bit Timer

trig\_mode [in] : Select trigger source

TB1RT\_LogicH : Logic High, always trigger

TB1RT\_CP11 : CPI1, trigger condition base on input compare result.

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Example**

```
/* Enable TMB · Set HS_CK as TMB clock source, TMB_CK and Pre-scale 1 as DTMB_CK frequency,
```

```
TMB mode is 16-bit Timer and Logic High as trigger source */
```

```
TMB_Open(TMBS_HSCK ,DTMB1_TMB1CKDIV2 ,TB1M_16bit ,TB1RT_LogicH );
```

#### 4.2.30. TMBIE\_Enable

- **Prototype**

```
TMBIE_Enable()
```

- **Description**

Enable Timer-B interrupt function.

Configure the register INTE0[3]=1.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable Timer-B interrupt function. */  
TMBIE_Enable();
```

## 4.2.31. TMBIE\_Disable

- **Prototype**

TMBIE\_Disable()

- **Description**

Disable Timer-B interrupt function.

Clear the register INTE0[3].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable Timer-B interrupt function. */  
TMBIE_Disable();
```

## 4.2.32. TMBIF\_IsFlag

- **Prototype**

TMBIF\_IsFlag()

- **Description**

Read the TMB interrupt flag.

Read the register INTF0[3].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the TMB interrupt flag. */  
TMBIF_IsFlag();
```

#### 4.2.33. **TMBIF\_ClearFlag**

- **Prototype**

TMBIF\_ClearFlag()

- **Description**

Clear the TMB interrupt flag.

Clear the register INTF0[3].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear the TMB interrupt flag. */  
TMBIF_ClearFlag();
```

#### 4.2.34. **TB1Enable**

- **Prototype**

TB1Enable()

- **Description**

Enable Timer-B function.

Configure the register TB1CN0[7]=1.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Enable Timer-B function. */  
TMB_Enable();
```

#### 4.2.35. **TB1Disable**

- **Prototype**

TB1Disable()

- **Description**

Disable Timer-B function.

Clear the register TB1CN0[7].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Disable Timer-B function. */
```

```
TMB_Disable();
```

#### 4.2.36. TB1\_ModeSelect

- **Prototype**

TB1\_ModeSelect(Sel)

- **Description**

Select TMB mode.

Configure the register TB1CN0[6:5].

- **Parameter**

Sel [in] : Select TMB mode

TB1M\_16bit : 16-bit Timer

TB1M\_17bit : 17-bit Timer

TB1M\_2\_8bit : two 8-bit Timer

TB1M\_8\_8bit : 8+8-bit Timer

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Set TMB is 16-bit timer mode */
```

```
TB1_ModeSelect ( TB1M_16bit );
```

#### 4.2.37. TB1\_TRIG\_MODE

- **Prototype**

TB1\_TRIG\_MODE(Sel)

- **Description**

- Select TMB trigger source
- Configure the register TB1CN0[4:3].
- **Parameter**
  - trig\_mode [in] : Select trigger source
    - TB1RT\_LogicH : Logic High, always trigger
    - TB1RT\_CP11 : CPI1, trigger condition base on input compare result.
- **Include**
  - Driver/HY17M/HY17M24/TMR.h
- **Return Value**
  - None
- **Example**

```
/* Set Logic High as TMB trigger source */  
TB1_TRIG_MODE(TB1RT_LogicH);
```

## 4.2.38. TB1\_ClearTMB1

- **Prototype**
  - TB1\_ClearTMB1()
- **Description**
  - Clear TMB counter value.
  - Configure the register TB1CN0[2]=1
- **Parameter**
  - None
- **Include**
  - Driver/HY17M/HY17M24/TMR.h
- **Return Value**
  - None
- **Example**

```
/* Clear TMB counter value. */  
TB1_ClearTMB1();
```

## 4.2.39. TB1\_TC1Select

- **Prototype**
  - TB1\_TC1Select(Set)
- **Description**
  - Select source of CPI1 input
  - Configure the register TC1CN0[6:5].
- **Parameter**
  - Set [in] : Select CPI1 input source

TC1S\_TBI0 : TBI0  
TC1S\_TBI1 : TBI1  
TC1S\_LSCK : LS\_CK  
TC1S\_OPC : OPC

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Select LPC_CK as CPI1 source */  
TB1_TC1Select(TC1S_LSCK);
```

## 4.2.40. TB1\_PWMO1

- **Prototype**

TB1\_PWMO1(Sel)

- **Description**

Configure the PWMO1 output function

Configure the register TB1CN0[1].

- **Parameter**

Sel [in] : Configure PWM1 output controller

PWMO1\_DISABLE : Disable PWM1 output

PWMO1\_OUTPUT : Enable PWM1 output

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Enable PWMO1 output */  
TB1_PWMO1(PWMO1_OUTPUT) ;
```

## 4.2.41. TB1\_PWMO0

- **Prototype**

TB1\_PWMO0(Sel)

- **Description**

Configure the PWMO0 output function

Configure the register TB1CN0[0].

- **Parameter**

Sel [in] : Configure PWM0 output controller

PWMO0\_DISABLE : Disable PWM0 output  
PWMO0\_OUTPUT : Enable PWM0 output

● **Include**

Driver/HY17M/HY17M24/TMR.h

● **Return Value**

None

● **Example**

```
/* Enable PWMO0 output */  
TB1_PWMO1(PWMO0_OUTPUT) ;
```

#### 4.2.42. TB1\_PWM1ModeSelect

● **Prototype**

TB1\_PWM1ModeSelect(Sel)

● **Description**

Select the PWM1 output mode.

Configure the register TB1CN1[6:4].

● **Parameter**

Sel [in] : Set PWM1 waveform

PWMA1\_PWM1O : PWM1O

PWMA1\_PWM2O : PWM2O

PWMA1\_PWM3O : PWM3O

PWMA1\_PWM4O : PWM4O

PWMA1\_PWM5O : PWM5O

PWMA1\_PWM6O : PWM6O

PWMA1\_PWM7O : PWM7O

● **Include**

Driver/HY17M/HY17M24/TMR.h

● **Return Value**

None

● **Example**

```
/* Select PWM1 output waveform is PWM4O */  
TB1_PWM1ModeSelect(PWMA1_PWM4O);
```

#### 4.2.43. TB1\_PWM0ModeSelect

● **Prototype**

TB1\_PWM0ModeSelect(Sel)

● **Description**

Select the PWM0 output mode.

Configure the register TB1CN1[2:0].

● **Parameter**

Sel [in] : Set PWM0 waveform  
PWMA0\_PWM1O : PWM1O  
PWMA0\_PWM2O : PWM2O  
PWMA0\_PWM3O : PWM3O  
PWMA0\_PWM4O : PWM4O  
PWMA0\_PWM5O : PWM5O  
PWMA0\_PWM6O : PWM6O  
PWMA0\_PWM7O : PWM7O

● **Include**

Driver/HY17M/HY17M24/TMR.h

● **Return Value**

None

● **Example**

```
/* Select PWM0 output waveform is PWM3O */  
TB1_PWM0ModeSelect(PWMA0_PWM3O);
```

#### 4.2.44. TB1\_PWM1\_PHASE

● **Prototype**

TB1\_PWM1\_PHASE(Sel)

● **Description**

Set the PWM1 output phase.

Configure the register TB1CN1[7].

● **Parameter**

Sel [in] : Set the PWM1 output phase.

PA1IV\_INVER : PWM1 output inver  
PA1IV\_NORMAL : PWM1 output normal

● **Include**

Driver/HY17M/HY17M24/TMR.h

● **Return Value**

None

● **Example**

```
/* Set PWM1 output inver */  
TB1_PWM1_PHASE(PA1IV_INVER);
```

#### 4.2.45. TB1\_PWM0\_PHASE

● **Prototype**

TB1\_PWM0\_PHASE(Sel)

● **Description**

- Set the PWM0 output phase.  
Configure the register TB1CN1[3].
- **Parameter**  
Sel [in] : Set the PWM0 output phase.  
PA0IV\_INVER : PWM0 output inver  
PA0IV\_NORMAL : PWM0 output normal
- **Include**  
Driver/HY17M/HY17M24/TMR.h
- **Return Value**  
None
- **Example**  

```
/* Set PWM0 output inver */  
TB1_PWM0_PHASE(PA0IV_INVER);
```

## 4.2.46. TB1C0Set

- **Prototype**  
void TB1C0Set(unsigned int TMB)
- **Description**  
Set TMB counter value.  
Configure the register TB1C0[15:0]
- **Parameter**  
TMB [in] : Set TMB counter overflow value.  
0x0000~0xFFFF : The setting range is different according to the PWM mode.
- **Include**  
Driver/HY17M/HY17M24/TMR.h
- **Return Value**  
None
- **Example**  

```
/* Set TB1C0 is 0x00ff */  
TB1C0Set(0x00ff);
```

## 4.2.47. TB1C1Set

- **Prototype**  
void TB1C1Set(unsigned int TMB)
- **Description**  
Set PWM0/PWM1 count condition parameter.  
Configure the register TB1C1[15:0]
- **Parameter**

TMB [in] : Set PWM count condition parameter.

0x0000~0xFFFF : The setting range is different according to the PWM mode.

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Set TB1C1 is 0x00ff */
```

```
TB1C1Set(0x00ff);
```

## 4.2.48. TB1C2Set

- **Prototype**

```
void TB1C2Set(unsigned int TMB)
```

- **Description**

Set PWM0/PWM1 count condition parameter.

Configure the register TB1C2[15:0]

- **Parameter**

TMB [in] : Set PWM count condition parameter.

0x0000~0xFFFF : The setting range is different according to the PWM mode.

- **Include**

Driver/HY17M/HY17M24/TMR.h

- **Return Value**

None

- **Example**

```
/* Set TB1C2 is 0x00ff */
```

```
TB1C2Set(0x00ff);
```

## 5. GPIO Driver

### 5.1. Introduction

The following functions are included in GPIO Manager Section.

Item	Functions	Description
01	GPIO_OpenPT1Input	Enable the input mode and enable pull-up resistor of the specified pin
02	GPIO_OpenPT2Input	Enable the input mode and enable pull-up resistor of the specified pin
03	GPIO_OpenPT3Input	Enable the input mode and enable pull-up resistor of the specified pin
04	GPIO_OpenPT1Output	Enable the output mode of the specified pin and output high
05	GPIO_OpenPT2Output	Enable the output mode of the specified pin and output high
06	GPIO_OpenPT3Output	Enable the output mode of the specified pin and output high
07	GPIO_PT1OutputMode	Enable the output mode of the specified pin
08	GPIO_PT1OutputHigh	Set the specified pin output high
09	GPIO_PT1OutputLow	Set the specified pin output low
10	GPIO_PT1InputModule	Enable the input mode of the specified pin
11	GPIO_PT1SETPU	Enable pull-up resistor of the specified pin
12	GPIO_PT1CLRPU	Disable pull-up resistor of the specified pin
13	GPIO_PT1SETPUAll	Enable pull-up resistor of PT1
14	GPIO_PT1InputEnable	Enable digital function of the specified pin
15	GPIO_PT1InputDisable	Disable digital function of the specified pin
16	GPIO_PT1SETDA	Enable analogy function of the specified pin
17	GPIO_PT1CLRDA	Disable analogy function of the specified pin
18	GPIO_PT1GET	Read the status of the specified pin
19	E0IE_Enable	Enable PT1.0 external interrupt function
20	E0IE_Disable	Disable PT1.0 external interrupt function
21	E0IF_IsFlag	Read PT1.0 external interrupt flag
22	E0IF_ClearFlag	Clear PT1.0 external interrupt flag
23	GPIO_INTEG0Sel	Select the trigger method of PT1.0 interrupt
24	E1IE_Enable	Enable PT1.1 external interrupt function
25	E1IE_Disable	Disable PT1.1 external interrupt function
26	E1IF_IsFlag	Read PT1.1 external interrupt flag
27	E1IF_ClearFlag	Clear PT1.1 external interrupt flag
28	GPIO_INTEG1Sel	Select the trigger method of PT1.1 interrupt
29	E2IE_Enable	Enable PT1.2 external interrupt function
30	E2IE_Disable	Disable PT1.2 external interrupt function
31	E2IF_IsFlag	Read PT1.2 external interrupt flag
32	E2IF_ClearFlag	Clear PT1.2 external interrupt flag
33	INTG12_Edgerise	Set edge rise to trigger PT1.2 interrupt
34	INTG12_Edgefall	Set edge fall to trigger PT1.2 interrupt
35	E3IE_Enable	Enable PT1.3 external interrupt function
36	E3IE_Disable	Disable PT1.3 external interrupt function
37	E3IF_IsFlag	Read PT1.3 external interrupt flag
38	E3IF_ClearFlag	Clear PT1.3 external interrupt flag
39	INTG13_Edgerise	Set edge rise to trigger PT1.3 interrupt

40	INTG13_Edgefall	Set edge fall to trigger PT1.3 interrupt
41	INTE14_Enable	Enable PT1.4 interrupt function
42	INTE14_Disable	Disable PT1.4 interrupt function
43	INTF14_IsFlag	Read PT1.4 interrupt flag
44	INTF14_ClearFlag	Clear PT1.4 interrupt flag
45	INTG14_Edgerise	Set edge rise to trigger PT1.4 interrupt
46	INTG14_Edgefall	Set edge fall to trigger PT1.4 interrupt
47	INTE15_Enable	Enable PT1.5 interrupt function
48	INTE15_Disable	Disable PT1.5 interrupt function
49	INTF15_IsFlag	Read PT1.5 interrupt flag
50	INTF15_ClearFlag	Clear PT1.5 interrupt flag
51	INTG15_Edgerise	Set edge rise to trigger PT1.5 interrupt
52	INTG15_Edgefall	Set edge fall to trigger PT1.5 interrupt
53	INTE16_Enable	Enable PT1.6 interrupt function
54	INTE16_Disable	Disable PT1.6 interrupt function
55	INTF16_IsFlag	Read PT1.6 interrupt flag
56	INTF16_ClearFlag	Clear PT1.6 interrupt flag
57	INTG16_Edgerise	Set edge rise to trigger PT1.6 interrupt
58	INTG16_Edgefall	Set edge fall to trigger PT1.6 interrupt
59	GPIO_PM10Sel	Select the main function of PT1.0
60	GPIO_PM12Sel	Select the main function of PT1.2
61	GPIO_PM13Sel	Select the main function of PT1.3
62	GPIO_PM15Sel	Select the main function of PT1.5
63	GPIO_PM16Sel	Select the main function of PT1.6
64	GPIO_PT2OutputMode	Enable the output mode of the specified pin
65	GPIO_PT2OutputHigh	Set the specified pin output high
66	GPIO_PT2OutputLow	Set the specified pin output low
67	GPIO_PT2InputMode	Enable the input mode of the specified pin
68	GPIO_PT2SETPU	Enable pull-up resistor of the specified pin
69	GPIO_PT2CLRPU	Disable pull-up resistor of the specified pin
70	GPIO_PT2SETPUAll	Enable pull-up resistor of PT2
71	GPIO_PT2InputEnable	Enable digital function of the specified pin
72	GPIO_PT2InputDisable	Disable digital function of the specified pin
73	GPIO_PT2GET	Read the status of the specified pin
74	INTE20_Enable	Enable PT2.0 interrupt function
75	INTE20_Disable	Disable PT2.0 interrupt function
76	INTF20_IsFlag	Read PT2.0 interrupt flag
77	INTF20_ClearFlag	Clear PT2.0 interrupt flag
78	INTG20_Edgerise	Set edge rise to trigger PT2.1 interrupt
79	INTG20_Edgefall	Set edge fall to trigger PT2.1 interrupt
80	INTE21_Enable	Enable PT2.1 interrupt function
81	INTE21_Disable	Disable PT2.1 interrupt function
82	INTF21_IsFlag	Read PT2.1 interrupt flag
83	INTF21_ClearFlag	Clear PT2.1 interrupt flag
84	INTG21_Edgerise	Set edge rise to trigger PT2.1 interrupt
85	INTG21_Edgefall	Set edge fall to trigger PT2.1 interrupt
86	GPIO_PM20Sel	Select the main function of PT2.0
87	GPIO_PM21Sel	Select the main function of PT2.1
88	GPIO_PT3OutputMode	Enable the output mode of the specified pin
89	GPIO_PT3OutputHigh	Set the specified pin output high
90	GPIO_PT3OutputLow	Set the specified pin output low
91	GPIO_PT3InputMode	Enable the input mode of the specified pin
92	GPIO_PT3SETPU	Enable pull-up resistor of the specified pin
93	GPIO_PT3CLRPU	Disable pull-up resistor of the specified pin
94	GPIO_PT3SETPUAll	Enable pull-up resistor of PT3
95	GPIO_PT3InputEnable	Enable digital function of the specified pin
96	GPIO_PT3InputDisable	Disable digital function of the specified pin
97	GPIO_PT3SETDA	Enable analogy function of the specified pin

98	GPIO_PT3CLRDA	Disable analogy function of the specified pin
99	GPIO_PT3GET	Read the status of the specified pin
100	INTE30_Enable	Enable PT3.0 interrupt function
101	INTE30_Disable	Disable PT3.0 interrupt function
102	INTF30_IsFlag	Read PT3.0 interrupt flag
103	INTF30_ClearFlag	Clear PT3.0 interrupt flag
104	INTG30_Edgerise	Set edge rise to trigger PT3.0 interrupt
105	INTG30_Edgefall	Set edge fall to trigger PT3.0 interrupt
106	INTE31_Enable	Enable PT3.1 interrupt function
107	INTE31_Disable	Disable PT3.1 interrupt function
108	INTF31_IsFlag	Read PT3.1 interrupt flag
109	INTF31_ClearFlag	Clear PT3.1 interrupt flag
110	INTG31_Edgerise	Set edge rise to trigger PT3.1 interrupt
111	INTG31_Edgefall	Set edge fall to trigger PT3.1 interrupt
112	INTE32_Enable	Enable PT3.2 interrupt function
113	INTE32_Disable	Disable PT3.2 interrupt function
114	INTF32_IsFlag	Read PT3.2 interrupt flag
115	INTF32_ClearFlag	Clear PT3.2 interrupt flag
116	INTG32_Edgerise	Set edge rise to trigger PT3.2 interrupt
117	INTG32_Edgefall	Set edge fall to trigger PT3.2 interrupt
118	INTE33_Enable	Enable PT3.3 interrupt function
119	INTE33_Disable	Disable PT3.3 interrupt function
120	INTF33_IsFlag	Read PT3.3 interrupt flag
121	INTF30_ClearFlag	Clear PT3.3 interrupt flag
122	INTG33_Edgerise	Set edge rise to trigger PT3.3 interrupt
123	INTG33_Edgefall	Set edge fall to trigger PT3.3 interrupt
124	INTE34_Enable	Enable PT3.4 interrupt function
125	INTE34_Disable	Disable PT3.4 interrupt function
126	INTF34_IsFlag	Read PT3.4 interrupt flag
127	INTF34_ClearFlag	Clear PT3.4 interrupt flag
128	INTG34_Edgerise	Set edge rise to trigger PT3.4 interrupt
129	INTG34_Edgefall	Set edge fall to trigger PT3.4 interrupt
130	INTE35_Enable	Enable PT3.5 interrupt function
131	INTE35_Disable	Disable PT3.5 interrupt function
132	INTF35_IsFlag	Read PT3.5 interrupt flag
133	INTF35_ClearFlag	Clear PT3.5 interrupt flag
134	INTG35_Edgerise	Set edge rise to trigger PT3.5 interrupt
135	INTG35_Edgefall	Set edge fall to trigger PT3.5 interrupt
136	INTE36_Enable	Enable PT3.6 interrupt function
137	INTE36_Disable	Disable PT3.6 interrupt function
138	INTF36_IsFlag	Read PT3.6 interrupt flag
139	INTF36_ClearFlag	Clear PT3.6 interrupt flag
140	INTG36_Edgerise	Set edge rise to trigger PT3.6 interrupt
141	INTG36_Edgefall	Set edge fall to trigger PT3.6 interrupt
142	INTE37_Enable	Enable PT3.7 interrupt function
143	INTE37_Disable	Disable PT3.7 interrupt function
144	INTF37_IsFlag	Read PT3.7 interrupt flag
145	INTF37_ClearFlag	Clear PT3.7 interrupt flag
146	INTG37_Edgerise	Set edge rise to trigger PT3.7 interrupt
147	INTG37_Edgefall	Set edge fall to trigger PT3.7 interrupt
148	GPIO_PM30Sel	Select the main function of PT3.0
149	GPIO_PM32Sel	Select the main function of PT3.2
150	GPIO_PM33Sel	Select the main function of PT3.3
151	GPIO_PM34Sel	Select the main function of PT3.4
152	GPIO_PM36Sel	Select the main function of PT3.6

## 5.2. Functions

### 5.2.1. GPIO\_OpenPT1Input

- **Prototype**

```
void GPIO_OpenPT1Input(unsigned char InputBits, unsigned char PullHighBits)
```

- **Description**

Enable the input mode and enable pull-up resistor of the specified pin.

Configure the register TRISC1/PT1PU.

- **Parameter**

InputBitst [in] : Enable the input mode of the specified pin

TC10\_H : PT1.0

TC11\_H : PT1.1

TC12\_H : PT1.2

TC13\_H : PT1.3

TC14\_H : PT1.4

TC15\_H : PT1.5

TC16\_H : PT1.6

PullHighBits [in] : Enable pull-up resistor of the specified pin

PU10\_H : Enable pull-up resistor of PT1.0

PU11\_H : Enable pull-up resistor of PT1.1

PU12\_H : Enable pull-up resistor of PT1.2

PU13\_H : Enable pull-up resistor of PT1.3

PU14\_H : Enable pull-up resistor of PT1.4

PU15\_H : Enable pull-up resistor of PT1.5

PU16\_H : Enable pull-up resistor of PT1.6

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the input mode and enable pull-up resistor of the pin PT1.4/PT1.5 */  
GPIO_OpenPT1Input(TC14_H, PU14_H);  
GPIO_OpenPT1Input(TC15_H, PU15_H);
```

### 5.2.2. GPIO\_OpenPT2Input

- **Prototype**

```
void GPIO_OpenPT2Input(unsigned char InputBits,unsigned char PullHighBits)
```

- **Description**

Enable the input mode and enable pull-up resistor of the specified pin.

Configure the register TRISC2/PT2PU.

- **Parameter**

InputBitst [in] : Enable the input mode of the specified pin

TC20\_H : PT2.0

TC21\_H : PT2.1

PullHighBits [in] : Enable pull-up resistor of the specified pin

PU20\_H : Enable pull-up resistor of PT2.0

PU21\_H : Enable pull-up resistor of PT2.1.

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the input mode and enable pull-up resistor of the pin PT2.0/PT2.1 */  
GPIO_OpenPT2Input(TC20_H, PU20_H);  
GPIO_OpenPT2Input(TC21_H, PU21_H);
```

## 5.2.3. GPIO\_OpenPT3Input

- **Prototype**

```
void GPIO_OpenPT3Input(unsigned char InputBits, unsigned char PullHighBits)
```

- **Description**

Enable the input mode and enable pull-up resistor of the specified pin

Configure the register TRISC3/PT3PU.

- **Parameter**

InputBitst [in] : Enable the input mode of the specified pin

TC30\_H : PT3.0

TC31\_H : PT3.1

TC32\_H : PT3.2

TC33\_H : PT3.3

TC34\_H : PT3.4

TC35\_H : PT3.5

TC36\_H : PT3.6

TC37\_H : PT3.6

PullHighBits [in] : Enable pull-up resistor of the specified pin

PU30\_H : Enable pull-up resistor of PT3.0

PU31\_H : Enable pull-up resistor of PT3.1

PU32\_H : Enable pull-up resistor of PT3.2

PU33\_H : Enable pull-up resistor of PT3.3  
PU34\_H : Enable pull-up resistor of PT3.4  
PU35\_H : Enable pull-up resistor of PT3.5  
PU36\_H : Enable pull-up resistor of PT3.6  
PU37\_H : Enable pull-up resistor of PT3.7

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the input mode and enable pull-up resistor of the pin PT3.4/PT3.5 */  
GPIO_OpenPT3Input(TC34_H, PU34_H);  
GPIO_OpenPT3Input(TC35_H, PU35_H);
```

#### 5.2.4. GPIO\_OpenPT1Output

- **Prototype**

void GPIO\_OpenPT1Output(unsigned char OutputBits,unsigned char OutHighBits)

- **Description**

Enable the output mode of the specified pin and output high.

Configure the register TRISC1/PT1

- **Parameter**

InputBitst [in] : Enable the output mode of the specified pin

TC11\_H : PT1.1

TC12\_H : PT1.2

TC13\_H : PT1.3

TC14\_H : PT1.4

TC15\_H : PT1.5

TC16\_H : PT1.6

OutHighBits [in] : Set the specified pin output high

PT11\_H : PT1.1 output high

PT12\_H : PT1.2 output high

PT13\_H : PT1.3 output high

PT14\_H : PT1.4 output high

PT15\_H : PT1.5 output high

PT16\_H : PT1.6 output high

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the output mode of PT1.4/PT1.5 and output high. */  
GPIO_OpenPT1Output ( TC14_H ,PT14_H );  
GPIO_OpenPT1Output ( TC15_H ,PT15_H );
```

## 5.2.5. GPIO\_OpenPT2Output

- **Prototype**

```
void GPIO_OpenPT2Output(unsigned char OutputBits,unsigned char OutHighBits)
```

- **Description**

Enable the output mode of the specified pin and output high.

Configure the register TRISC2/PT2

- **Parameter**

InputBitst [in] : Enable the output mode of the specified pin

TC20\_H : PT2.0

TC21\_H : PT2.1

OutHighBits [in] : Set the specified pin output high

PT20\_H : PT2.0 output high

PT21\_H : PT2.1 output high

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the output mode of PT2.1/PT2.0 and output high. */  
GPIO_OpenPT2Output ( TC21_H ,PT20_H );  
GPIO_OpenPT2Output ( TC21_H ,PT20_H );
```

## 5.2.6. GPIO\_OpenPT3Output

- **Prototype**

```
void GPIO_OpenPT3Output(unsigned char OutputBits,unsigned char OutHighBits)
```

- **Description**

Enable the output mode of the specified pin and output high.

Configure the register TRISC3/PT3

- **Parameter**

InputBitst [in] : Enable the output mode of the specified pin

TC30\_H : PT3.0

TC31\_H : PT3.1

TC32\_H : PT3.2

TC33\_H : PT3.3

TC34\_H : PT3.4

TC35\_H : PT3.5

TC36\_H : PT3.6

TC37\_H : PT3.7

OutHighBits [in] : Set the specified pin output high

PT30\_H : PT3.0 output high

PT31\_H : PT3.1 output high

PT32\_H : PT3.2 output high

PT33\_H : PT3.3 output high

PT34\_H : PT3.4 output high

PT35\_H : PT3.5 output high

PT36\_H : PT3.6 output high

PT37\_H : PT3.7 output high

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the output mode of PT3.4/PT3.5 and output high. */  
GPIO_OpenPT3Output ( TC34_H ,PT34_H );  
GPIO_OpenPT3Output ( TC35_H ,PT35_H );
```

### 5.2.7. GPIO\_PT1OutputMode

- **Prototype**

GPIO\_PT1OutputMode(BitSet)

- **Description**

Enable the output mode of the specified pin .

Configure the register TRISC1

- **Parameter**

BitSet [in] : Enable the output mode of the specified pin .

TC11\_H : PT1.1

TC12\_H : PT1.2

TC13\_H : PT1.3

TC14\_H : PT1.4

TC15\_H : PT1.5

TC16\_H : PT1.6

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the output mode of the PT1.6 . */  
GPIO_PT1OutputMode(TC16_H);
```

### 5.2.8. GPIO\_PT1OutputHigh

- **Prototype**

GPIO\_PT1OutputHigh(BitSet)

- **Description**

Set the specified pin output high.

Configure the register PT1[6:0]

- **Parameter**

BitSet [in] : Set the specified pin output high.

PT11\_H : PT1.1

PT12\_H : PT1.2

PT13\_H : PT1.3

PT14\_H : PT1.4

PT15\_H : PT1.5

PT16\_H : PT1.6

- **include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set the PT1.6 output high. */  
GPIO_PT1OutputMode(TC16_H);  
GPIO_PT1OutputHigh(PT16_H);
```

### 5.2.9. GPIO\_PT1OutputLow

- **Prototype**

GPIO\_PT1OutputLow(BitSet)

- **Description**

Set the specified pin output low.

Clear the register PT1[6:0]

- **Parameter**

BitSet [in] : Set the specified pin output low.

PT11\_H : PT1.1

PT12\_H : PT1.2  
PT13\_H : PT1.3  
PT14\_H : PT1.4  
PT15\_H : PT1.5  
PT16\_H : PT1.6

- **include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set the PT1.5 output low. */  
GPIO_PT1OutputMode(TC15_H);  
GPIO_PT1OutputLow(PT15_H);
```

### 5.2.10. GPIO\_PT1InputMode

- **Prototype**

GPIO\_PT1InputMode(BitSet)

- **Description**

Enable the input mode of the specified pin .

Configure the register TRISC1

- **Parameter**

BitSet [in] : Enable the input mode of the specified pin .

TC10\_H : PT1.0  
TC11\_H : PT1.1  
TC12\_H : PT1.2  
TC13\_H : PT1.3  
TC14\_H : PT1.4  
TC15\_H : PT1.5  
TC16\_H : PT1.6

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the input mode of the PT1.6 . */  
GPIO_PT1InputMode(TC16_H);
```

### 5.2.11. GPIO\_PT1SETPU

- **Prototype**

GPIO\_PT1SETPU(BitSet)

- **Description**

Enable pull-up resistor of the specified pin.

Configure the register PT1PU.

- **Parameter**

BitSet [in] : Enable pull-up resistor of the specified pin.

PU10\_H : Enable PT1.0 pull-up resistor

PU11\_H : Enable PT1.1 pull-up resistor

PU12\_H : Enable PT1.2 pull-up resistor

PU13\_H : Enable PT1.3 pull-up resistor

PU14\_H : Enable PT1.4 pull-up resistor

PU15\_H : Enable PT1.5 pull-up resistor

PU16\_H : Enable PT1.6 pull-up resistor

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable pull-up resistor of the PT1.4. */  
GPIO_PT1SETPU ( PU14_H );
```

### 5.2.12. GPIO\_PT1CLRPU

- **Prototype**

GPIO\_PT1CLRPU(BitSet)

- **Description**

Disable pull-up resistor of the specified pin.

Clear the register PT1PU.

- **Parameter**

BitSet [in] : Disable pull-up resistor of the specified pin.

PU10\_H : Disable PT1.0 pull-up resistor

PU11\_H : Disable PT1.1 pull-up resistor

PU12\_H : Disable PT1.2 pull-up resistor

PU13\_H : Disable PT1.3 pull-up resistor

PU14\_H : Disable PT1.4 pull-up resistor

PU15\_H : Disable PT1.5 pull-up resistor

PU16\_H : Disable PT1.6 pull-up resistor

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Disable pull-up resistor of the PT1.4. */  
GPIO_PT1CLRPU ( PU14_H );
```

## 5.2.13. GPIO\_PT1SETPUAll

- **Prototype**

```
GPIO_PT1SETPUAll()
```

- **Description**

Enable pull-up resistor of PT1.

Configure the register PT1PU

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/GPIO.h
```

- **Return Value**

None

- **Example**

```
/* Enable pull-up resistor of PT1 */  
GPIO_PT1SETPUAll();
```

## 5.2.14. GPIO\_PT1InputEnable

- **Prototype**

```
GPIO_PT1InputEnable(BitSet)
```

- **Description**

Enable digital function of the specified pin.

Configure the register PT1IN

- **Parameter**

BitSet [in] : Enable digital function of the specified pin.

IN10\_H : Enable digital function of the PT1.0

IN11\_H : Enable digital function of the PT1.1

IN12\_H : Enable digital function of the PT1.2

IN13\_H : Enable digital function of the PT1.3

IN14\_H : Enable digital function of the PT1.4

IN15\_H : Enable digital function of the PT1.5

IN16\_H : Enable digital function of the PT1.6

- **Include**

```
Driver/HY17M/HY17M24/GPIO.h
```

- **Return Value**

None

- **Example**

```
/* Enable digital function of the PT1.5 */  
GPIO_PT1InputEnable(IN15_H);
```

## 5.2.15. GPIO\_PT1InputDisable

- **Prototype**

```
GPIO_PT1InputDisable(BitSet)
```

- **Description**

Disable digital function of the specified pin.  
Clear the register PT1IN

- **Parameter**

BitSet [in] : Disable digital function of the specified pin.

IN10\_H : Disable digital function of the PT1.0

IN11\_H : Disable digital function of the PT1.1

IN12\_H : Disable digital function of the PT1.2

IN13\_H : Disable digital function of the PT1.3

IN14\_H : Disable digital function of the PT1.4

IN15\_H : Disable digital function of the PT1.5

IN16\_H : Disable digital function of the PT1.6

- **Include**

```
Driver/HY17M/HY17M24/GPIO.h
```

- **Return Value**

None

- **Example**

```
/* Disable digital function of the PT1.5 */  
GPIO_PT1InputDisable(IN15_H);
```

## 5.2.16. GPIO\_PT1SETDA

- **Prototype**

```
GPIO_PT1SETDA(BitSet)
```

- **Description**

Enable analogy function of the specified pin.  
Configure the register PT1DA

- **Parameter**

BitSet [in] : Enable analogy function of the specified pin

DA10\_H : Enable analogy function of the PT1.0

DA11\_H : Enable analogy function of the PT1.1

DA12\_H : Enable analogy function of the PT1.2

DA13\_H : Enable analogy function of the PT1.3  
DA14\_H : Enable analogy function of the PT1.4  
DA15\_H : Enable analogy function of the PT1.5  
DA16\_H : Enable analogy function of the PT1.6

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable analogy function of the PT1.5. */  
GPIO_PT1SETDA(DA15_H);
```

### 5.2.17. GPIO\_PT1CLRDA

- **Prototype**

GPIO\_PT1CLRDA(BitSet)

- **Description**

Disable analogy function of the specified pin.

Clear the register PT1DA

- **Parameter**

BitSet [in] : Disable analogy function of the specified pin  
DA10\_H : Disable analogy function of the PT1.0  
DA11\_H : Disable analogy function of the PT1.1  
DA12\_H : Disable analogy function of the PT1.2  
DA13\_H : Disable analogy function of the PT1.3  
DA14\_H : Disable analogy function of the PT1.4  
DA15\_H : Disable analogy function of the PT1.5  
DA16\_H : Disable analogy function of the PT1.6

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Disable analogy function of the PT1.5. */  
GPIO_PT1CLRDA(DA15_H);
```

### 5.2.18. GPIO\_PT1GET

- **Prototype**

GPIO\_PT1GET(BitSet)

- **Description**

Read the status of the specified pin

Read the register PT1

- **Parameter**

BitSet [in] : Read the status of the specified pin

PT10\_H : Read the status of the PT1.0

PT11\_H : Read the status of the PT1.1

PT12\_H : Read the status of the PT1.2

PT13\_H : Read the status of the PT1.3

PT14\_H : Read the status of the PT1.4

PT15\_H : Read the status of the PT1.5

PT16\_H : Read the status of the PT1.6

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Read the status of the specified pin PT1.5 and PT1.6 */
```

```
unsigned char PT1_DATA;
```

```
PT1_DATA = GPIO_PT1GET(PT15_H | PT16_H);
```

## 5.2.19. E0IE\_Enable

- **Prototype**

```
E0IE_Enable()
```

- **Description**

Enable PT1.0 external interrupt function.

Configure the register INT0[0]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT1.0 external interrupt function. */
```

```
E0IE_Enable();
```

## 5.2.20. E0IE\_Disable

- **Prototype**

```
E0IE_Disable()
```

- **Description**

Disable PT1.0 external interrupt function.

Clear the register INTFO[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT1.0 external interrupt function. */  
E0IE_Disable();
```

### 5.2.21. E0IF\_IsFlag

- **Prototype**

E0IF\_IsFlag()

- **Description**

Read PT1.0 external interrupt flag.

Read the register INTFO[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT1.0 external interrupt flag*/  
unsigned char flag;  
flag = E0IF_IsFlag();
```

### 5.2.22. E0IF\_ClearFlag

- **Prototype**

E0IF\_ClearFlag()

- **Description**

Clear PT1.0 external interrupt flag.

Clear the register INTFO[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT1.0 external interrupt flag*/  
unsigned char flag;  
E0IF_ClearFlag();
```

## 5.2.23. GPIO\_INTEG0Sel

- **Prototype**

GPIO\_INTEG0Sel(EG0Sel)

- **Description**

Select the trigger method of PT1.0 interrupt .

Configure the register PT1M1[1:0]

- **Parameter**

EG0Sel [in] : Select the trigger method of PT1.0 interrupt

INTEG0\_LEV : 0->1 or 1->0

INTEG0\_EDGERISE : 0->1

INTEG0\_EDGEFALL : 1->0

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Select the trigger method of PT1.0 interrupt is edge fall . */  
GPIO_INTEG0Sel(INTEG0_EDGEFALL);
```

## 5.2.24. E1IE\_Enable

- **Prototype**

E1IE\_Enable()

- **Description**

Enable PT1.1 external interrupt function.

Configure the register INTE0[1]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT1.1 external interrupt function. */  
E1IE_Enable();
```

### **5.2.25. E1IE\_Disable**

- **Prototype**

E1IE\_Disable()

- **Description**

Disable PT1.1 external interrupt function.

Clear the register INTE0[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT1.1 external interrupt function. */  
E1IE_Disable();
```

### **5.2.26. E1IF\_IsFlag**

- **Prototype**

E1IF\_IsFlag()

- **Description**

Read PT1.1 external interrupt flag.

Read the register INTF0[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT1.1 external interrupt flag*/  
unsigned char flag;  
flag = E1IF_IsFlag();
```

### 5.2.27. E1IF\_ClearFlag

- **Prototype**

E1IF\_ClearFlag()

- **Description**

Clear PT1.1 external interrupt flag.

Clear the register INTF0[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT1.1 external interrupt flag*/  
unsigned char flag;  
E1IF_ClearFlag();
```

### 5.2.28. GPIO\_INTEG1Sel

- **Prototype**

GPIO\_INTEG1Sel(EG1Sel)

- **Description**

Select the trigger method of PT1.1 interrupt.

Configure the register PT1M1[3:2]

- **Parameter**

EG1Sel [in] : Select the trigger method of PT1.1 interrupt

INTEG1\_LEV : 0->1 or 1->0

INTEG1\_EDGERISE : 0->1

INTEG1\_EDGEFALL : 1->0

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Select the trigger method of PT1.1 interrupt is edge fall . */  
GPIO_INTEG1Sel(INTEG1_EDGEFALL);
```

### 5.2.29. E2IE\_Enable

- **Prototype**

E2IE\_Enable()

- **Description**

Enable PT1.2 external interrupt function.

Configure the register INTE1[0]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT1.2 external interrupt function. */  
E2IE_Enable();
```

## 5.2.30. E2IE\_Disable

- **Prototype**

E2IE\_Disable()

- **Description**

Disable PT1.2 external interrupt function.

Clear the register INTE1[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT1.2 external interrupt function. */  
E2IE_Disable();
```

## 5.2.31. E2IF\_IsFlag

- **Prototype**

E2IF\_IsFlag()

- **Description**

Read PT1.2 external interrupt flag.

Read the register INTF1[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT1.2 external interrupt flag*/  
unsigned char flag;  
flag = E2IF_IsFlag();
```

### 5.2.32. E2IF\_ClearFlag

- **Prototype**

E2IF\_ClearFlag()

- **Description**

Clear PT1.2 external interrupt flag.

Clear the register INTF1[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT1.2 external interrupt flag*/  
unsigned char flag;  
E2IF_ClearFlag();
```

### 5.2.33. INTG12\_Edgerise

- **Prototype**

INTG12\_Edgerise()

- **Description**

Set edge rise to trigger PT1.2 interrupt .

Configure the register PT1INT[2]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT1.2 interrupt */
```

```
INTG12_Edgerise();
```

#### **5.2.34. INTG12\_Edgefall**

- **Prototype**

```
INTG12_Edgefall()
```

- **Description**

Set edge fall to trigger PT1.2 interrupt .

Clear the register PT1INT[2]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/INT.h
```

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT1.2 interrupt */
```

```
INTG12_Edgefall();
```

#### **5.2.35. E3IE\_Enable**

- **Prototype**

```
E3IE_Enable()
```

- **Description**

Enable PT1.3 external interrupt function.

Configure the register INTE1[1]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/INT.h
```

- **Return Value**

None

- **Example**

```
/* Enable PT1.3 external interrupt function. */
```

```
E3IE_Enable();
```

#### **5.2.36. E3IE\_Disable**

- **Prototype**

```
E3IE_Disable()
```

- **Description**

Disable PT1.3 external interrupt function.

- Clear the register INTE1[1]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**

```
/* Disable PT1.3 external interrupt function. */  
E3IE_Disable();
```

## 5.2.37. E3IF\_IsFlag

- **Prototype**  
E3IF\_IsFlag()
- **Description**  
Read PT1.3 external interrupt flag.  
Read the register INTF1[1]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
0 : No interrupt  
1 : Interrupt occurred
- **Example**

```
/* Read PT1.3 external interrupt flag*/  
unsigned char flag;  
flag = E3IF_IsFlag();
```

## 5.2.38. E3IF\_ClearFlag

- **Prototype**  
E3IF\_ClearFlag()
- **Description**  
Clear PT1.3 external interrupt flag.  
Clear the register INTF1[1]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT1. 3 external interrupt flag*/  
unsigned char flag;  
E3IF_ClearFlag();
```

### 5.2.39. INTG13\_Edgerise

- **Prototype**

INTG13\_Edgerise()

- **Description**

Set edge rise to trigger PT1.3 interrupt .

Configure the register PT1INT[3]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT1.3 interrupt */  
INTG13_Edgerise();
```

### 5.2.40. INTG13\_Edgefall

- **Prototype**

INTG13\_Edgefall()

- **Description**

Set edge fall to trigger PT1.3 interrupt .

Clear the register PT1INT[3]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT1.3 interrupt */  
INTG13_Edgefall();
```

#### **5.2.41. INTE14\_Enable**

- **Prototype**

INTE14\_Enable()

- **Description**

Enable PT1.4 interrupt function .

Configure the register PT1INTE[4]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT1.4 interrupt function */
```

```
INTE14_Enable();
```

#### **5.2.42. INTE14\_Disable**

- **Prototype**

INTE14\_Disable()

- **Description**

Disable PT1.4 interrupt function .

Clear the register PT1INTE[4]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT1.4 interrupt function */
```

```
INTE14_Disable();
```

#### **5.2.43. INTF14\_IsFlag**

- **Prototype**

INTF14\_IsFlag()

- **Description**

Read PT1.4 interrupt flag.

Read the register PT1INTF[4]

- **Parameter**

- None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
0 : No interrupt  
1 : Interrupt occurred
- **Example**

```
/* Read PT1.4 interrupt flag */  
unsigned char flag;  
flag = INTF14_IsFlag();
```

#### **5.2.44. INTF14\_ClearFlag**

- **Prototype**  
INTF14\_ClearFlag()
- **Description**  
Clear PT1.4 interrupt flag.  
Clear the register PT1INTF[4]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**

```
/* Clear PT1.4 interrupt flag */  
INTF14_ClearFlag();
```

#### **5.2.45. INTG14\_Edgerise**

- **Prototype**  
INTG14\_Edgerise()
- **Description**  
Set edge rise to trigger PT1.4 interrupt.  
Configure the register PT1INT[4]=1
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None

- **Example**

```
/* Set edge rise to trigger PT1.4 interrupt. */  
INTG14_Edgerise();
```

#### **5.2.46. INTG14\_Edgefall**

- **Prototype**

```
INTG14_Edgefall()
```

- **Description**

Set edge fall to trigger PT1.4 interrupt.

Clear the register PT1INT[4]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/INT.h
```

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT1.4 interrupt. */  
INTG14_Edgefall();
```

#### **5.2.47. INTE15\_Enable**

- **Prototype**

```
INTE15_Enable()
```

- **Description**

Enable PT1.5 interrupt function .

Configure the register PT1INTE[5]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/INT.h
```

- **Return Value**

None

- **Example**

```
/* Enable PT1.5 interrupt function */  
INTE15_Enable();
```

#### **5.2.48. INTE15\_Disable**

- **Prototype**

```
INTE15_Disable()
```

- **Description**

Disable PT1.5 interrupt function .

Clear the register PT1INTE[5]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT1.5 interrupt function */  
INTE15_Disable();
```

### 5.2.49. INTF15\_IsFlag

- **Prototype**

INTF15\_IsFlag()

- **Description**

Read PT1.5 interrupt flag.

Read the register PT1INTF[5]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT1.5 interrupt flag */  
unsigned char flag;  
flag = INTF15_IsFlag();
```

### 5.2.50. INTF15\_ClearFlag

- **Prototype**

INTF15\_ClearFlag()

- **Description**

Clear PT1.5 interrupt flag.

Clear the register PT1INTF[5]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT1.5 interrupt flag */
```

```
INTF15_ClearFlag();
```

## 5.2.51. INTG15\_Edgerise

- **Prototype**

```
INTG15_Edgerise()
```

- **Description**

Set edge rise to trigger PT1.5 interrupt.

Configure the register PT1INT[5]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT1.5 interrupt. */
```

```
INTG15_Edgerise();
```

## 5.2.52. INTG15\_Edgefall

- **Prototype**

```
INTG15_Edgefall()
```

- **Description**

Set edge fall to trigger PT1.5 interrupt.

Clear the register PT1INT[5]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT1.5 interrupt. */
```

```
INTG15_Edgefall();
```

### 5.2.53. INTE16\_Enable

- **Prototype**

INTE16\_Enable()

- **Description**

Enable PT1.6 interrupt function .

Configure the register PT1INTE[6]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT1.6 interrupt function */  
INTE16_Enable();
```

### 5.2.54. INTE16\_Disable

- **Prototype**

INTE16\_Disable()

- **Description**

Disable PT1.6 interrupt function .

Clear the register PT1INTE[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT1.6 interrupt function */  
INTE16_Disable();
```

### 5.2.55. INTF16\_IsFlag

- **Prototype**

INTF16\_IsFlag()

- **Description**

Read PT1.6 interrupt flag.

Read the register PT1INTF[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT1.6 interrupt flag */  
unsigned char flag;  
flag = INTF16_IsFlag();
```

### 5.2.56. INTF16\_ClearFlag

- **Prototype**

INTF16\_ClearFlag()

- **Description**

Clear PT1.6 interrupt flag.

Clear the register PT1INTF[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT1.6 interrupt flag */  
INTF16_ClearFlag();
```

### 5.2.57. INTG16\_Edgerise

- **Prototype**

INTG16\_Edgerise()

- **Description**

Set edge rise to trigger PT1.6 interrupt.

Configure the register PT1INT[6]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT1.6 interrupt. */  
INTG16_Edgerise();
```

### **5.2.58. INTG16\_Edgefall**

- **Prototype**

```
INTG16_Edgefall()
```

- **Description**

Set edge fall to trigger PT1.6 interrupt.

Clear the register PT1INT[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT1.6 interrupt. */  
INTG16_Edgefall();
```

### **5.2.59. GPIO\_PM10Sel**

- **Prototype**

```
GPIO_PM10Sel(PM10Sel)
```

- **Description**

Select the main function of PT1.0 multiple function pin.

Configure the register PT1M2[0]

- **Parameter**

PM10Sel [in] : Select the function of PT1.0

    PM10\_VOHL         : GPIO function

    PM10\_TBI0\_input   : TBI0 input

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set PT1.0 as TBI0 input pin*/  
GPIO_PM10Sel(PM10_TBI0_input);
```

### 5.2.60. GPIO\_PM12Sel

- **Prototype**

```
GPIO_PM12Sel(PM12Sel)
```

- **Description**

Select the main function of PT1.2 multiple function pin.

Configure the register PT1M2[4]

- **Parameter**

PM12Sel [in] : Select the function of PT1.2

    PM12\_VOHL : GPIO function

    PM12\_PWM1 : PWM1 output pin

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set PT1.2 as PWM1 output pin*/  
GPIO_PM12Sel(PM12_PWM1);
```

### 5.2.61. GPIO\_PM13Sel

- **Prototype**

```
GPIO_PM13Sel(PM13Sel)
```

- **Description**

Select the main function of PT1.3 multiple function pin

Configure the register PT1M2[7:6]

- **Parameter**

PM13Sel [in] : Select the function of PT1.3

    PM13\_VOHL : GPIO function

    PM13\_PWM0\_1 : PWM0 output pin

    PM13\_SCL : I2C SCL pin

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set PT1.3 as SCL pin */  
GPIO_PM13Sel(PM13_SCL);
```

### 5.2.62. GPIO\_PM15Sel

- **Prototype**

GPIO\_PM15Sel(PM15Sel)

- **Description**

Select the main function of PT1.5 multiple function pin.

Configure the register PT1M3[3:2]

- **Parameter**

PM15Sel [in] : Select the function of PT1.5

PM15\_VOHL : GPIO function

PM15\_BZ : BZ output pin

PM15\_TX : EUART TX pin

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set PT1.5 as TX pin */
```

```
GPIO_PM15Sel(PM15_TX);
```

## 5.2.63. GPIO\_PM16Sel

- **Prototype**

GPIO\_PM16Sel(PM16Sel)

- **Description**

Select the main function of PT1.6 multiple function pin.

Configure the register PT1M3[4]

- **Parameter**

PM16Sel [in] : Select the function of PT1.6

PM16\_VOHL : GPIO function

PM16\_PWM0 : PWM0 output pin

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set PT1.6 as PWM0 output pin*/
```

```
GPIO_PM16Sel(PM16_PWM0);
```

## 5.2.64. GPIO\_PT2OutputMode

- **Prototype**

GPIO\_PT2OutputMode(BitSet)

- **Description**

- Enable the output mode of the specified pin .
- Configure the register TRISC2
- **Parameter**
  - BitSet [in] : Enable the output mode of the specified pin .
  - TC20\_H : PT2.0
  - TC21\_H : PT2.1
- **Include**
  - Driver/HY17M/HY17M24/GPIO.h
- **Return Value**
  - None
- **Example**

```
/* Enable the output mode of the PT2.0 . */  
GPIO_PT2OutputMode(TC20_H);
```

## 5.2.65. GPIO\_PT2OutputHigh

- **Prototype**
  - GPIO\_PT2OutputHigh(BitSet)
- **Description**
  - Set the specified pin output high
  - Configure the register PT2[1:0]
- **Parameter**
  - BitSet [in] : Set the specified pin output high.
  - PT20\_H : PT2.0
  - PT21\_H : PT2.1
- **include**
  - Driver/HY17M/HY17M24/GPIO.h
- **Return Value**
  - None
- **Example**

```
/* Set the PT2.0 output high. */  
GPIO_PT2OutputMode(TC20_H);  
GPIO_PT2OutputHigh(PT20_H);
```

## 5.2.66. GPIO\_PT2OutputLow

- **Prototype**
  - GPIO\_PT2OutputLow(BitSet)
- **Description**
  - Set the specified pin output low.
  - Clear the register PT2[2:0]

- **Parameter**

BitSet [in] : Set the specified pin output low.

PT20\_H : PT2.0

PT21\_H : PT2.1

- **include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set the PT2.0 output low. */  
GPIO_PT2OutputMode(TC20_H);  
GPIO_PT2OutputLow(PT20_H);
```

## 5.2.67. GPIO\_PT2InputMode

- **Prototype**

GPIO\_PT2InputMode(BitSet)

- **Description**

Enable the input mode of the specified pin .

Configure the register TRISC2

- **Parameter**

BitSet [in] : Enable the input mode of the specified pin .

TC20\_H : PT2.0

TC21\_H : PT2.1

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the input mode of the PT2.1 . */  
GPIO_PT2InputMode(TC21_H);
```

## 5.2.68. GPIO\_PT2SETPU

- **Prototype**

GPIO\_PT2SETPU(BitSet)

- **Description**

Enable pull-up resistor of the specified pin.

Configure the register PT2PU.

- **Parameter**

BitSet [in] : Enable pull-up resistor of the specified pin.

PU20\_H : Enable PT2.0 pull-up resistor

PU21\_H : Enable PT2.1 pull-up resistor

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable pull-up resistor of the PT2.1. */
```

```
GPIO_PT2SETPU ( PU21_H );
```

## 5.2.69. GPIO\_PT2CLRPU

- **Prototype**

```
GPIO_PT2CLRPU(BitSet)
```

- **Description**

Disable pull-up resistor of the specified pin.

Clear the register PT1PU.

- **Parameter**

BitSet [in] : Disable pull-up resistor of the specified pin.

PU20\_H : Disable PT2.0 pull-up resistor

PU21\_H : Disable PT2.1 pull-up resistor

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Disable pull-up resistor of the PT2.1. */
```

```
GPIO_PT2CLRPU ( PU21_H );
```

## 5.2.70. GPIO\_PT2SETPUAll

- **Prototype**

```
GPIO_PT2SETPUAll()
```

- **Description**

Enable pull-up resistor of PT2.

Configure the register PT2PU

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable pull-up resistor of PT2 */  
GPIO_PT2SETPUAll();
```

### 5.2.71. GPIO\_PT2InputEnable

- **Prototype**

GPIO\_PT2InputEnable(BitSet)

- **Description**

Enable digital function of the specified pin.

Configure the register PT2IN

- **Parameter**

BitSet [in] : Enable digital function of the specified pin.

IN20\_H : Enable digital function of the PT2.0

IN21\_H : Enable digital function of the PT2.1

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable digital function of the PT2.1 */  
GPIO_PT2InputEnable(IN21_H);
```

### 5.2.72. GPIO\_PT2InputDisable

- **Prototype**

GPIO\_PT2InputDisable(BitSet)

- **Description**

Disable digital function of the specified pin.

Clear the register PT2IN

- **Parameter**

BitSet [in] : Disable digital function of the specified pin.

IN20\_H : Disable digital function of the PT2.0

IN21\_H : Disable digital function of the PT2.1

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Disable digital function of the PT2.1 */  
GPIO_PT2InputDisable(IN21_H);
```

### 5.2.73. GPIO\_PT2GET

- **Prototype**

GPIO\_PT2GET(BitSet)

- **Description**

Read the status of the specified pin.

Read the register PT2

- **Parameter**

BitSet [in] : Read the status of the specified pin

PT20\_H : Read the status of the PT2.0

PT20\_H : Read the status of the PT2.1

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Read the status of the specified pin PT2.0 */
```

```
unsigned char PT2_DATA;
```

```
PT2_DATA = GPIO_PT2GET(PT20_H);
```

### 5.2.74. INT20\_Enable

- **Prototype**

INT20\_Enable()

- **Description**

Enable PT2.0 interrupt function .

Configure the register PT2INTE[0]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT2.0 interrupt function */
```

```
INT20_Enable();
```

### 5.2.75. INT20\_Disable

- **Prototype**

INTE20\_Disable()

- **Description**

Disable PT20 interrupt function .

Clear the register PT2INTE[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT2.0 interrupt function */  
INTE20_Disable();
```

### 5.2.76. INTF20\_IsFlag

- **Prototype**

INTF20\_IsFlag()

- **Description**

Read PT2.0 interrupt flag.

Read the register PT2INTF[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT2.0 interrupt flag */  
unsigned char flag;  
flag = INTF20_IsFlag();
```

### 5.2.77. INTF20\_ClearFlag

- **Prototype**

INTF20\_ClearFlag()

- **Description**

Clear PT2.0 interrupt flag.

Clear the register PT2INTF[0]

- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**  
/\* Clear PT2.0 interrupt flag \*/  
INTF20\_ClearFlag();

### **5.2.78. INTG20\_Edgerise**

- **Prototype**  
INTG20\_Edgerise()
- **Description**  
Set edge rise to trigger PT2.0 interrupt.  
Configure the register PT2INT[0]=1
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**  
/\* Set edge rise to trigger PT2.0 interrupt. \*/  
INTG20\_Edgerise();

### **5.2.79. INTG20\_Edgefall**

- **Prototype**  
INTG20\_Edgefall()
- **Description**  
Set edge fall to trigger PT2.0 interrupt.  
Clear the register PT2INT[0]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**

```
/* Set edge fall to trigger PT2.0 interrupt. */  
INTG20_Edgefall();
```

## 5.2.80. INTE21\_Enable

- **Prototype**

INTE21\_Enable()

- **Description**

Enable PT2.1 interrupt function .

Configure the register PT2INTE[1]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT2.1 interrupt function */  
INTE21_Enable();
```

## 5.2.81. INTE21\_Disable

- **Prototype**

INTE21\_Disable()

- **Description**

Disable PT21 interrupt function .

Clear the register PT2INTE[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT2.1 interrupt function */  
INTE21_Disable();
```

## 5.2.82. INTF21\_IsFlag

- **Prototype**

INTF21\_IsFlag()

- **Description**

- Read PT2.1 interrupt flag.  
Read the register PT2INTF[1]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
0 : No interrupt  
1 : Interrupt occurred
- **Example**

```
/* Read PT2.1 interrupt flag */  
unsigned char flag;  
flag = INTF21_IsFlag();
```

### 5.2.83. INTF21\_ClearFlag

- **Prototype**  
INTF21\_ClearFlag()
- **Description**  
Clear PT2.1 interrupt flag.  
Clear the register PT2INTF[1]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**

```
/* Clear PT2.1 interrupt flag */  
INTF21_ClearFlag();
```

### 5.2.84. INTG21\_Edgerise

- **Prototype**  
INTG21\_Edgerise()
- **Description**  
Set edge rise to trigger PT2.1 interrupt.  
Configure the register PT2INT[1]=1
- **Parameter**  
None
- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT2.1 interrupt. */  
INTG21_Edgerise();
```

## 5.2.85. INTG21\_Edgefall

- **Prototype**

INTG21\_Edgefall()

- **Description**

Set edge fall to trigger PT2.1 interrupt.

Clear the register PT2INT[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT2.1 interrupt. */  
INTG21_Edgefall();
```

## 5.2.86. GPIO\_PM20Sel

- **Prototype**

GPIO\_PM20Sel(PM20Sel)

- **Description**

Select the main function of PT2.0 multiple function pin.

Configure the register PT2M1[1:0]

- **Parameter**

PM20Sel [in] : Select the function of PT2.0

PM20\_VOHL : GPIO function

PM20\_PWM1\_1 : PWM1 output pin

PM20\_TX\_1 : UART TX pin

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set PT2.0 as PWM1 output pin*/  
GPIO_PM20Sel(PM20_PWM1_1);
```

### 5.2.87. GPIO\_PM21Sel

- **Prototype**

```
GPIO_PM21Sel(PM21Sel)
```

- **Description**

Select the main function of PT2.1 multiple function pin.

Configure the register PT2M1[3:2]

- **Parameter**

PM21Sel [in] : Select the function of PT2.1

    PM20\_VOHL         : GPIO function

    PM21\_SCL\_1         : I2C SCL pin

    PM21\_BZ\_1         : BZ output pin

    PM21\_TBI1\_input    : TBI1 input pin

- **Include**

```
Driver/HY17M/HY17M24/GPIO.h
```

- **Return Value**

None

- **Example**

```
/* Set PT2.1 as BZ output pin*/
```

```
GPIO_PM21Sel(PM21_BZ_1);
```

### 5.2.88. GPIO\_PT3OutputMode

- **Prototype**

```
GPIO_PT3OutputMode(BitSet)
```

- **Description**

Enable the output mode of the specified pin .

Configure the register TRISC3

- **Parameter**

BitSet [in] : Enable the output mode of the specified pin .

    TC30\_H : PT3.0

    TC31\_H : PT3.1

    TC32\_H : PT3.2

    TC33\_H : PT3.3

    TC34\_H : PT3.4

    TC35\_H : PT3.5

    TC36\_H : PT3.6

TC37\_H : PT3.7

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the output mode of the PT3.6 . */  
GPIO_PT3OutputMode(TC36_H);
```

### 5.2.89. GPIO\_PT3OutputHigh

- **Prototype**

GPIO\_PT3OutputHigh(BitSet)

- **Description**

Set the specified pin output high.

Configure the register PT3

- **Parameter**

BitSet [in] : Set the specified pin output high.

PT30\_H : PT3.0

PT31\_H : PT3.1

PT32\_H : PT3.2

PT33\_H : PT3.3

PT34\_H : PT3.4

PT35\_H : PT3.5

PT36\_H : PT3.6

PT37\_H : PT3.7

- **include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set the PT3.6 output high. */  
GPIO_PT3OutputMode(TC36_H);  
GPIO_PT3OutputHigh(PT36_H);
```

### 5.2.90. GPIO\_PT3OutputLow

- **Prototype**

GPIO\_PT3OutputLow(BitSet)

- **Description**

Set the specified pin output low.

Clear the register PT3

- **Parameter**

BitSet [in] : Set the specified pin output low.

PT30\_H : PT3.0

PT31\_H : PT3.1

PT32\_H : PT3.2

PT33\_H : PT3.3

PT34\_H : PT3.4

PT35\_H : PT3.5

PT36\_H : PT3.6

PT37\_H : PT3.7

- **include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set the PT3.5 output low. */  
GPIO_PT3OutputMode(TC35_H);  
GPIO_PT3OutputLow(PT35_H);
```

## 5.2.91. GPIO\_PT3InputMode

- **Prototype**

GPIO\_PT3InputMode(BitSet)

- **Description**

Enable the input mode of the specified pin .

Configure the register TRISC3

- **Parameter**

BitSet [in] : Enable the input mode of the specified pin .

TC30\_H : PT3.0

TC31\_H : PT3.1

TC32\_H : PT3.2

TC33\_H : PT3.3

TC34\_H : PT3.4

TC35\_H : PT3.5

TC36\_H : PT3.6

TC37\_H : PT3.7

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable the input mode of the PT3.6 . */  
GPIO_PT3InputMode(TC36_H);
```

## 5.2.92. GPIO\_PT3SETPU

- **Prototype**

GPIO\_PT3SETPU(BitSet)

- **Description**

Enable pull-up resistor of the specified pin.

Configure the register PT3PU.

- **Parameter**

BitSet [in] : Enable pull-up resistor of the specified pin.

    PU30\_H : Enable PT3.0 pull-up resistor

    PU31\_H : Enable PT3.1 pull-up resistor

    PU32\_H : Enable PT3.2 pull-up resistor

    PU33\_H : Enable PT3.3 pull-up resistor

    PU34\_H : Enable PT3.4 pull-up resistor

    PU35\_H : Enable PT3.5 pull-up resistor

    PU36\_H : Enable PT3.6 pull-up resistor

    PU37\_H : Enable PT3.7 pull-up resistor

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable pull-up resistor of the PT3.4. */  
GPIO_PT3SETPU ( PU34_H );
```

## 5.2.93. GPIO\_PT3CLRPU

- **Prototype**

GPIO\_PT3CLRPU(BitSet)

- **Description**

Disable pull-up resistor of the specified pin.

Clear the register PT3PU.

- **Parameter**

BitSet [in] : Disable pull-up resistor of the specified pin.

    PU30\_H : Disable PT3.0 pull-up resistor

PU31\_H : Disable PT3.1 pull-up resistor  
PU32\_H : Disable PT3.2 pull-up resistor  
PU33\_H : Disable PT3.3 pull-up resistor  
PU34\_H : Disable PT3.4 pull-up resistor  
PU35\_H : Disable PT3.5 pull-up resistor  
PU36\_H : Disable PT3.6 pull-up resistor  
PU37\_H : Disable PT3.7 pull-up resistor

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Disable pull-up resistor of the PT3.4. */  
GPIO_PT3CLRPU ( PU34_H );
```

## 5.2.94. GPIO\_PT3SETPUAll

- **Prototype**

GPIO\_PT3SETPUAll()

- **Description**

Enable pull-up resistor of PT3

Configure the register PT3PU

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable pull-up resistor of PT3 */  
GPIO_PT3SETPUAll();
```

## 5.2.95. GPIO\_PT3InputEnable

- **Prototype**

GPIO\_PT3InputEnable(BitSet)

- **Description**

Enable digital function of the specified pin.

Configure the register PT3IN

- **Parameter**

BitSet [in] : Enable digital function of the specified pin.

IN30\_H : Enable digital function of the PT3.0  
IN31\_H : Enable digital function of the PT3.1  
IN32\_H : Enable digital function of the PT3.2  
IN33\_H : Enable digital function of the PT3.3  
IN34\_H : Enable digital function of the PT3.4  
IN35\_H : Enable digital function of the PT3.5  
IN36\_H : Enable digital function of the PT3.6  
IN37\_H : Enable digital function of the PT3.7

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Enable digital function of the PT3.5 */  
GPIO_PT3InputEnable(IN35_H);
```

### 5.2.96. GPIO\_PT3InputDisable

- **Prototype**

GPIO\_PT3InputDisable(BitSet)

- **Description**

Disable digital function of the specified pin.

Clear the register PT3IN

- **Parameter**

BitSet [in] : Disable digital function of the specified pin.  
IN30\_H : Disable digital function of the PT3.0  
IN31\_H : Disable digital function of the PT3.1  
IN32\_H : Disable digital function of the PT3.2  
IN33\_H : Disable digital function of the PT3.3  
IN34\_H : Disable digital function of the PT3.4  
IN35\_H : Disable digital function of the PT3.5  
IN36\_H : Disable digital function of the PT3.6  
IN37\_H : Disable digital function of the PT3.7

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Disable digital function of the PT3.5 */  
GPIO_PT3InputDisable(IN35_H);
```

### 5.2.97. GPIO\_PT3SETDA

- **Prototype**

GPIO\_PT3SETDA(BitSet)

- **Description**

Enable analogy function of the specified pin.

Configure the register PT3DA

- **Parameter**

BitSet [in] : Enable analogy function of the specified pin

DA30\_H : Enable analogy function of the PT3.0

DA31\_H : Enable analogy function of the PT3.1

DA32\_H : Enable analogy function of the PT3.2

DA33\_H : Enable analogy function of the PT3.3

DA34\_H : Enable analogy function of the PT3.4

DA35\_H : Enable analogy function of the PT3.5

DA36\_H : Enable analogy function of the PT3.6

DA37\_H : Enable analogy function of the PT3.7

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

/\* Enable analogy function of the PT3.5. \*/

GPIO\_PT3SETDA(DA35\_H);

### 5.2.98. GPIO\_PT3CLRDA

- **Prototype**

GPIO\_PT3CLRDA(BitSet)

- **Description**

Disable analogy function of the specified pin.

Clear the register PT3DA

- **Parameter**

BitSet [in] : Disable analogy function of the specified pin

DA30\_H : Disable analogy function of the PT3.0

DA31\_H : Disable analogy function of the PT3.1

DA32\_H : Disable analogy function of the PT3.2

DA33\_H : Disable analogy function of the PT3.3

DA34\_H : Disable analogy function of the PT3.4

DA35\_H : Disable analogy function of the PT3.5  
DA36\_H : Disable analogy function of the PT3.6  
DA37\_H : Disable analogy function of the PT3.7

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Disable analogy function of the PT3.5. */  
GPIO_PT3CLRDA(DA35_H);
```

### 5.2.99. GPIO\_PT3GET

- **Prototype**

GPIO\_PT3GET(BitSet)

- **Description**

Read the status of the specified pin

Read the register PT3

- **Parameter**

BitSet [in] : Read the status of the specified pin

PT30\_H : Read the status of the PT3.0

PT31\_H : Read the status of the PT3.1

PT32\_H : Read the status of the PT3.2

PT33\_H : Read the status of the PT3.3

PT34\_H : Read the status of the PT3.4

PT35\_H : Read the status of the PT3.5

PT36\_H : Read the status of the PT3.6

PT36\_H : Read the status of the PT3.6

PT37\_H : Read the status of the PT3.7

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Read the status of the specified pin PT3.5 and PT3.6 */  
unsigned char PT3_DATA;  
PT3_DATA = GPIO_PT3GET(PT35_H | PT36_H);
```

### 5.2.100. INTE30\_Enable

- **Prototype**

INTE30\_Enable()

- **Description**

Enable PT3.0 interrupt function .

Configure the register PT3INTE[0]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT3.0 interrupt function */
```

```
INTE30_Enable();
```

### 5.2.101. INTE30\_Disable

- **Prototype**

INTE30\_Disable()

- **Description**

Disable PT30 interrupt function .

Clear the register PT3INTE[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT3.0 interrupt function */
```

```
INTE30_Disable();
```

### 5.2.102. INTF30\_IsFlag

- **Prototype**

INTF30\_IsFlag()

- **Description**

Read PT3.0 interrupt flag.

Read the register PT3INTF[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT3.0 interrupt flag */  
unsigned char flag;  
flag = INTF30_IsFlag();
```

## 5.2.103. INTF30\_ClearFlag

- **Prototype**

INTF30\_ClearFlag()

- **Description**

Clear PT3.0 interrupt flag.

Clear the register PT3INTF[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT3.0 interrupt flag */  
INTF30_ClearFlag();
```

## 5.2.104. INTG30\_Edgerise

- **Prototype**

INTG30\_Edgerise()

- **Description**

Set edge rise to trigger PT3.0 interrupt.

Configure the register PT3INT[0]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT3.0 interrupt. */
```

```
INTG30_Edgerise();
```

### 5.2.105. INTG30\_Edgefall

- **Prototype**

```
INTG30_Edgefall()
```

- **Description**

Set edge fall to trigger PT3.0 interrupt.

Clear the register PT3INT[0]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/INT.h
```

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT3.0 interrupt. */
```

```
INTG30_Edgefall();
```

### 5.2.106. INTE31\_Enable

- **Prototype**

```
INTE31_Enable()
```

- **Description**

Enable PT3.1 interrupt function .

Configure the register PT3INTE[1]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/INT.h
```

- **Return Value**

None

- **Example**

```
/* Enable PT3.1 interrupt function */
```

```
INTE31_Enable();
```

### 5.2.107. INTE31\_Disable

- **Prototype**

```
INTE31_Disable()
```

- **Description**

Disable PT30 interrupt function .

Clear the register PT3INTE[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT3.1 interrupt function */  
INTE31_Disable();
```

## 5.2.108. INTF31\_IsFlag

- **Prototype**

INTF31\_IsFlag()

- **Description**

Read PT3.1 interrupt flag.

Read the register PT3INTF[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT3.1 interrupt flag */  
unsigned char flag;  
flag = INTF31_IsFlag();
```

## 5.2.109. INTF31\_ClearFlag

- **Prototype**

INTF31\_ClearFlag()

- **Description**

Clear PT3.1 interrupt flag.

Clear the register PT3INTF[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT3.1 interrupt flag */  
INTF31_ClearFlag();
```

### 5.2.110. INTG31\_Edgerise

- **Prototype**

INTG31\_Edgerise()

- **Description**

Set edge rise to trigger PT3.1 interrupt.

Configure the register PT3INT[1]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT3.1 interrupt. */  
INTG31_Edgerise();
```

### 5.2.111. INTG31\_Edgefall

- **Prototype**

INTG31\_Edgefall()

- **Description**

Set edge fall to trigger PT3.1 interrupt.

Clear the register PT3INT[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT3.1 interrupt. */  
INTG31_Edgefall();
```

### 5.2.112. INTE32\_Enable

---

- **Prototype**

INTE32\_Enable()

- **Description**

Enable PT3.2 interrupt function .

Configure the register PT3INTE[2]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT3.2 interrupt function */
```

```
INTE32_Enable();
```

### 5.2.113. INTE32\_Disable

- **Prototype**

INTE32\_Disable()

- **Description**

Disable PT32 interrupt function .

Clear the register PT3INTE[2]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT3.2 interrupt function */
```

```
INTE32_Disable();
```

### 5.2.114. INTF32\_IsFlag

- **Prototype**

INTF32\_IsFlag()

- **Description**

Read PT3.2 interrupt flag.

Read the register PT3INTF[2]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT3.2 interrupt flag */  
unsigned char flag;  
flag = INTF32_IsFlag();
```

### 5.2.115. INTF32\_ClearFlag

- **Prototype**

INTF32\_ClearFlag()

- **Description**

Clear PT3.2 interrupt flag.

Clear the register PT3INTF[2]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT3.2 interrupt flag */  
INTF32_ClearFlag();
```

### 5.2.116. INTG32\_Edgerise

- **Prototype**

INTG32\_Edgerise()

- **Description**

Set edge rise to trigger PT3.2 interrupt.

Configure the register PT3INT[2]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT3.2 interrupt. */  
INTG32Edgerise();
```

### **5.2.117. INTG32\_Edgefall**

- **Prototype**

INTG32\_Edgefall()

- **Description**

Set edge fall to trigger PT3.2 interrupt.

Clear the register PT3INT[2]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT3.2 interrupt. */  
INTG32_Edgefall();
```

### **5.2.118. INTE33\_Enable**

- **Prototype**

INTE33\_Enable()

- **Description**

Enable PT3.3 interrupt function .

Configure the register PT3INTE[3]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT3.3 interrupt function */  
INTE33_Enable();
```

### **5.2.119. INTE33\_Disable**

- **Prototype**

INTE33\_Disable()

- **Description**

Disable PT33 interrupt function .

Clear the register PT3INTE[3]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT3.3 interrupt function */  
INTE33_Disable();
```

### 5.2.120. INTF33\_IsFlag

- **Prototype**

INTF33\_IsFlag()

- **Description**

Read PT3.3 interrupt flag.

Read the register PT3INTF[3]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT3.3 interrupt flag */  
unsigned char flag;  
flag = INTF33_IsFlag();
```

### 5.2.121. INTF30\_ClearFlag

- **Prototype**

INTF30\_ClearFlag()

- **Description**

Clear PT3.3 interrupt flag.

Clear the register PT3INTF[3]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT3.3 interrupt flag */  
INTF33_ClearFlag();
```

### 5.2.122. INTG33\_Edgerise

- **Prototype**

INTG33\_Edgerise()

- **Description**

Set edge rise to trigger PT3.3 interrupt.

Configure the register PT3INT[3]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT3.3 interrupt. */  
INTG33_Edgerise();
```

### 5.2.123. INTG33\_Edgefall

- **Prototype**

INTG33\_Edgefall()

- **Description**

Set edge fall to trigger PT3.3 interrupt.

Clear the register PT3INT[3]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT3.3 interrupt. */  
INTG33_Edgefall();
```

### 5.2.124. INTE34\_Enable

- **Prototype**

INTE34\_Enable()

- **Description**

Enable PT3.4 interrupt function .

Configure the register PT3INTE[4]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT3.4 interrupt function */
```

```
INTE34_Enable();
```

### 5.2.125. INTE34\_Disable

- **Prototype**

INTE34\_Disable()

- **Description**

Disable PT34 interrupt function .

Clear the register PT3INTE[4]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT3.4 interrupt function */
```

```
INTE34_Disable();
```

### 5.2.126. INTF34\_IsFlag

- **Prototype**

INTF34\_IsFlag()

- **Description**

Read PT3.4 interrupt flag.

Read the register PT3INTF[4]

- **Parameter**

- None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
0 : No interrupt  
1 : Interrupt occurred
- **Example**

```
/* Read PT3.4 interrupt flag */  
unsigned char flag;  
flag = INTF34_IsFlag();
```

### **5.2.127. INTF34\_ClearFlag**

- **Prototype**  
INTF34\_ClearFlag()
- **Description**  
Clear PT3.4 interrupt flag.  
Clear the register PT3INTF[4]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**

```
/* Clear PT3.4 interrupt flag */  
INTF34_ClearFlag();
```

### **5.2.128. INTG34\_Edgerise**

- **Prototype**  
INTG34\_Edgerise()
- **Description**  
Set edge rise to trigger PT3.4 interrupt.  
Configure the register PT3INT[4]=1
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None

- **Example**

```
/* Set edge rise to trigger PT3.4 interrupt. */  
INTG34_Edgerise();
```

### 5.2.129. INTG34\_Edgefall

- **Prototype**

```
INTG34_Edgefall()
```

- **Description**

Set edge fall to trigger PT3.4 interrupt.

Clear the register PT3INT[4]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/INT.h
```

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT3.4 interrupt. */  
INTG34_Edgefall();
```

### 5.2.130. INTE35\_Enable

- **Prototype**

```
INTE35_Enable()
```

- **Description**

Enable PT3.5 interrupt function .

Configure the register PT3INTE[5]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/INT.h
```

- **Return Value**

None

- **Example**

```
/* Enable PT3.5 interrupt function */  
INTE35_Enable();
```

### 5.2.131. INTE35\_Disable

- **Prototype**

```
INTE35_Disable()
```

● **Description**

Disable PT35 interrupt function .

Clear the register PT3INTE[5]

● **Parameter**

None

● **Include**

Driver/HY17M/HY17M24/INT.h

● **Return Value**

None

● **Example**

```
/* Disable PT3.5 interrupt function */  
INTE35_Disable();
```

### 5.2.132. INTF35\_IsFlag

● **Prototype**

INTF35\_IsFlag()

● **Description**

Read PT3.5 interrupt flag.

Read the register PT3INTF[5]

● **Parameter**

None

● **Include**

Driver/HY17M/HY17M24/INT.h

● **Return Value**

0 : No interrupt

1 : Interrupt occurred

● **Example**

```
/* Read PT3.5 interrupt flag */  
unsigned char flag;  
flag = INTF35_IsFlag();
```

### 5.2.133. INTF35\_ClearFlag

● **Prototype**

INTF35\_ClearFlag()

● **Description**

Clear PT3.5 interrupt flag.

Clear the register PT3INTF[5]

● **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT3.5 interrupt flag */  
INTF35_ClearFlag();
```

### 5.2.134. INTG35\_Edgerise

- **Prototype**

INTG35\_Edgerise()

- **Description**

Set edge rise to trigger PT3.5 interrupt.

Configure the register PT3INT[5]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT3.5 interrupt. */  
INTG35_Edgerise();
```

### 5.2.135. INTG35\_Edgefall

- **Prototype**

INTG35\_Edgefall()

- **Description**

Set edge fall to trigger PT3.5 interrupt.

Clear the register PT3INT[5]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT3.5 interrupt. */  
INTG35_Edgefall();
```

### **5.2.136. INT36\_Enable**

- **Prototype**

INT36\_Enable()

- **Description**

Enable PT3.6 interrupt function .

Configure the register PT3INTE[6]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT3.6 interrupt function */  
INT36_Enable();
```

### **5.2.137. INT36\_Disable**

- **Prototype**

INT36\_Disable()

- **Description**

Disable PT36 interrupt function .

Clear the register PT3INTE[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Disable PT3.6 interrupt function */  
INT36_Disable();
```

### **5.2.138. INTF36\_IsFlag**

- **Prototype**

INTF36\_IsFlag()

- **Description**

Read PT3.6 interrupt flag.

Read the register PT3INTF[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read PT3.6 interrupt flag */  
unsigned char flag;  
flag = INTF36_IsFlag();
```

### 5.2.139. INTF36\_ClearFlag

- **Prototype**

INTF36\_ClearFlag()

- **Description**

Clear PT3.6 interrupt flag.

Clear the register PT3INTF[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Clear PT3.6 interrupt flag */  
INTF36_ClearFlag();
```

### 5.2.140. INTG36\_Edgerise

- **Prototype**

INTG36\_Edgerise()

- **Description**

Set edge rise to trigger PT3.6 interrupt.

Configure the register PT3INT[6]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge rise to trigger PT3.6 interrupt. */  
INTG36_Edgerise();
```

### **5.2.141. INTG36\_Edgefall**

- **Prototype**

```
INTG36_Edgefall()
```

- **Description**

Set edge fall to trigger PT3.6 interrupt.

Clear the register PT3INT[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Set edge fall to trigger PT3.6 interrupt. */  
INTG36_Edgefall();
```

### **5.2.142. INTE37\_Enable**

- **Prototype**

```
INTE37_Enable()
```

- **Description**

Enable PT3.7 interrupt function .

Configure the register PT3INTE[7]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/INT.h

- **Return Value**

None

- **Example**

```
/* Enable PT3.7 interrupt function */  
INTE37_Enable();
```

### **5.2.143. INTE37\_Disable**

- **Prototype**

- INTE37\_Disable()
  - **Description**  
Disable PT37 interrupt function .  
Clear the register PT3INTE[7]
  - **Parameter**  
None
  - **Include**  
Driver/HY17M/HY17M24/INT.h
  - **Return Value**  
None
  - **Example**  
/\* Disable PT3.7 interrupt function \*/  
INTE37\_Disable();

#### **5.2.144. INTF37\_IsFlag**

- **Prototype**  
INTF37\_IsFlag()
- **Description**  
Read PT3.7 interrupt flag.  
Read the register PT3INTF[7]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
0 : No interrupt  
1 : Interrupt occurred
- **Example**  
/\* Read PT3.7 interrupt flag \*/  
unsigned char flag;  
flag = INTF37\_IsFlag();

#### **5.2.145. INTF37\_ClearFlag**

- **Prototype**  
INTF37\_ClearFlag()
- **Description**  
Clear PT3.7 interrupt flag.  
Clear the register PT3INTF[7]
- **Parameter**

- None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**  
/\* Clear PT3.7 interrupt flag \*/  
INTF37\_ClearFlag();

### **5.2.146. INTG37\_Edgerise**

- **Prototype**  
INTG37\_Edgerise()
- **Description**  
Set edge rise to trigger PT3.7 interrupt.  
Configure the register PT3INT[7]=1
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**  
/\* Set edge rise to trigger PT3.7 interrupt. \*/  
INTG37\_Edgerise();

### **5.2.147. INTG37\_Edgefall**

- **Prototype**  
INTG37\_Edgefall()
- **Description**  
Set edge fall to trigger PT3.7 interrupt.  
Clear the register PT3INT[7]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/INT.h
- **Return Value**  
None
- **Example**  
/\* Set edge fall to trigger PT3.7 interrupt. \*/

```
INTG37 _Edgefall();
```

### 5.2.148. GPIO\_PM30Sel

- **Prototype**

```
GPIO_PM30Sel(PM30Sel)
```

- **Description**

Select the main function of PT3.0 multiple function pin.

Configure the register PT3M1[1:0]

- **Parameter**

PM30Sel [in] : Select the function of PT3.0

    PM30\_VOHL         : GPIO function

    PM30\_SCL\_2         : I2C SCL pin

    PM30\_TBI0\_1         : TBI0 input pin

- **Include**

```
Driver/HY17M/HY17M24/GPIO.h
```

- **Return Value**

None

- **Example**

```
/* Set PT3.0 as TBI0 input pin*/
```

```
GPIO_PM30Sel(PM30_TBI0_1);
```

### 5.2.149. GPIO\_PM32Sel

- **Prototype**

```
GPIO_PM32Sel(PM32Sel)
```

- **Description**

Select the main function of PT3.2 multiple function pin.

Configure the register PT3M1[5:4]

- **Parameter**

PM32Sel [in] : Select the function of PT3.2

    PM32\_VOHL         : GPIO function

    PM32\_PWM0\_2         : PWM0 output pin

    PM32\_SCL\_3         : I2C SCL pin

- **Include**

```
Driver/HY17M/HY17M24/GPIO.h
```

- **Return Value**

None

- **Example**

```
/* Set PT3.2 as SCL pin */
```

```
GPIO_PM32Sel(PM32_SCL_3);
```

### **5.2.150. GPIO\_PM33Sel**

- **Prototype**

```
GPIO_PM33Sel(PM33Sel)
```

- **Description**

Select the main function of PT3.3 multiple function pin.

Configure the register PT3M1[6]

- **Parameter**

PM33Sel [in] : Select the function of PT3.3

    PM33\_VOHL       : GPIO function

    PM33\_PWM1\_2     : PWM1 output pin

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set PT3.3 as PWM1 output pin*/  
GPIO_PM33Sel(PM33_PWM1_2);
```

### **5.2.151. GPIO\_PM34Sel**

- **Prototype**

```
GPIO_PM34Sel(PM34Sel)
```

- **Description**

Select the main function of PT3.4 multiple function pin.

Configure the register PT3M2[1:0]

- **Parameter**

PM34Sel [in] : Select the function of PT3.4

    PM34\_VOHL       : GPIO function

    PM34\_BZ\_2       : BZ output pin

    PM34\_TX\_3       : UART TX pin

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/* Set PT3.4 as TX pin */  
GPIO_PM34Sel(PM34_TX_3);
```

### **5.2.152. GPIO\_PM36Sel**

- **Prototype**

GPIO\_PM36Sel(PM36Sel)

- **Description**

Select the main function of PT3.6 multiple function pin.

Configure the register PT3M2[5:4]

- **Parameter**

PM36Sel [in] : Select the function of PT3.6

PM36\_VOHL : GPIO function

PM36\_TBI1\_1 : TBI1 input pin

PM36\_TX\_2 : UART TX pin

- **Include**

Driver/HY17M/HY17M24/GPIO.h

- **Return Value**

None

- **Example**

```
/*Set PT3.6 as TX pin */  
GPIO_PM36Sel(PM36_TX_2);
```

## 6. ADC Driver

### 6.1. Introduction

The following functions are included in ADC Manager Section.

Item	Functions	Description
01	ADC_Open	Enable ADC function, set the ADC clock, OSR, the ADC signal input source, AD Gain, DC offset, and reference voltage source
02	ADC_GetData	Get the A/D conversion data
03	ADC_Enable	Enable ADC control
04	ADC_Disable	Disable ADC control
05	ADC_INT_Enable	Enable ADC interrupt
06	ADC_INT_Disable	Disable ADC interrupt
07	ADC_INT_IsFlag	Read ADC interrupt flag
08	ADC_INT_ClearFlag	Clear ADC interrupt flag
09	ADC_OSRSelect	Set the ADC OSR
10	ADC_CMFREnable	Enable Comb filter
11	ADC_CMFRDisable	Disable Comb filter
12	ADC_VRXSelect	Set the ADC full reference range select
13	ADC_GainSelect	Input signal gain for ADC
14	ADC_DCSETSelect	DC offset input voltage selection
15	ADC_ENACMEnable	Enable ACM function
16	ADC_ENACMDisable	Disable ACM function
17	ADC_ACMBufSelect	Select ACM input source
18	ADC_VINSelect	Configure the ADC signal input (positive and negative) source
19	ADC_VRINSelect	Configure the ADC reference voltage input (positive and negative) source
20	ADC_INXSelect	Configure the ADC signal input (positive and negative) exchange controller
21	ADC_ENINXCH_EnableADC_ENINXCH_Disable	Enable the ADC signal input auto switching
22	ADC_ENINXCH_Disable	Disable the ADC signal input auto switching
23	ADC_VCMSSelect	Select VCM source
24	ADC_REFOLSel	Select the REFOI input source
25	ADC_ENTPSEnable	Enable TPS function
26	ADC_ENTPSDisable	Disable TPS function
27	ADC_TPSSelect	Select TPS output phase
28	ADC_DAFMSelect	Select the formats of Comb Filter output
29	ADC_ENCH_Enable	Enable ADC chopper
30	ADC_ENCH_Disable	Disable ADC chopper

### 6.2. Functions

### 6.2.1. ADC\_Open

- **Prototype**

```
void ADC_Open(unsigned char cks, unsigned char inp, unsigned char inn, unsigned char vrh, unsigned  
char vrl, unsigned char adgn, unsigned char vrgn, unsigned char dcset, unsigned char osr, unsigned char  
vcms);
```

- **Description**

Enable ADC function, set the ADC clock, OSR, the ADC signal input source, AD Gain, DC offset, and reference voltage source.

Configure the register AD1CN0/AD1CN1/AD1CN2/AD1CN3/AD1CN4/AD1CN5.

- **Parameters**

cks [in] : Select ADC clock

DADC_DHSCKDIV2	:	DHS_CK/2
DADC_DHSCKDIV4	:	DHS_CK/4
DADC_DHSCKDIV8	:	DHS_CK/8
DADC_DHSCKDIV16	:	DHS_CK/16

inp [in] : Select ADC positive input source

INP_AI0	:	AI0
INP_AI1	:	AI1
INP_AI2	:	AI2
INP_AI4	:	AI4
INP_AI6	:	AI6
INP_AI8	:	AI8
INP_AI10	:	AI10
INP_AI12	:	AI12
INP_AI14	:	AI14
INP_OPOI	:	OPOI
INP_VDDA	:	VDDA
INP_REF0I	:	REF0I
INP_TS0	:	TS0
INP_TS1	:	TS1
INP_VSS	:	VSS
INP.DAOI	:	DAOI

inn [in] : Select ADC negative input source

INN_AI0	:	AI0
INN_AI1	:	AI1
INN_AI2	:	AI2
INN_AI5	:	AI5
INN_AI7	:	AI7

INN\_AI9 : AI9  
INN\_AI11 : AI11  
INN\_AI13 : AI13  
INN\_VDDDIV10 : VDD/10  
INN\_OPOI : OPOI  
INN\_VDDA : VDDA  
INN\_REF0I : REF0I  
INN\_TS0 : TS0  
INN\_TS1 : TS1  
INN\_VSS : VSS  
INN\_DAOI : DAOI

vrh [in] : Select the reference voltage positive input source

VRH\_VDDA : VDDA  
VRH\_AI0 : AI0  
VRH\_AI10 : AI10  
VRH\_REF0I : REF0I

vrl [in] : Select the reference voltage negative input source

VRL\_VSS : VSS  
VRL\_AI2 : AI2  
RL\_AI4 : AI4  
VRL\_REF0I : REF0I

adgn [in] : Select AD gain

ADGN\_1DIV4 : x 1/4  
ADGN\_1DIV2 : x 1/2  
ADGN\_1 : x 1  
ADGN\_2 : x 2  
ADGN\_4 : x 4  
ADGN\_8 : x 8  
ADGN\_16 : x 16  
ADGN\_RSVD : x 16

vrgn [in] : Set the ADC full reference range select

VREGN\_DIV2 : VREF \* 1/2

VREGN\_DIV1 : VREF\* 1

dcset [in] : Select ADC dc offset

DCSET\_P0 : 0  
DCSET\_P1DIV8 : + VREF\* 1/8  
DCSET\_P2DIV8 : + VREF\* 2/8  
DCSET\_P3DIV8 : + VREF\* 3/8

```
DCSET_P4DIV8 : + VREF* 4/8
DCSET_P5DIV8 : + VREF* 5/8
DCSET_P6DIV8 : + VREF* 6/8
DCSET_P7DIV8 : + VREF* 7/8
DCSET_N0      : 0
DCSET_N1DIV8 : -VREF* 1/8
DCSET_N2DIV8 : -VREF* 2/8
DCSET_N3DIV8 : -VREF* 3/8
DCSET_N4DIV8 : -VREF* 4/8
DCSET_N5DIV8 : -VREF* 5/8
DCSET_N6DIV8 : -VREF* 6/8
DCSET_N7DIV8 : -VREF* 7/8

osr [in] : select ADC OSR
OSR_64      : ADC_CK/64
OSR_128     : ADC_CK/128
OSR_256     : ADC_CK/256
OSR_512     : ADC_CK/512
OSR_1024    : ADC_CK/1024
OSR_2048    : ADC_CK/2048
OSR_4096    : ADC_CK/4096
OSR_8192    : ADC_CK/8192
OSR_16384   : ADC_CK/16384
OSR_32768   : ADC_CK/32768
OSR_65536   : ADC_CK/65536

vcms [in] : Select VCM source
VCMS_ACMin  : From ACMin
VCMS_REFOut  : From REFOut
```

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Set DHS_CK/2 as ADC clock, input source AI0-AI1, the reference voltage input source VDDA-VSS · AD
gain is 1, DC Offset 0V · OSR is ADC_CK/65536 · REFOut as VCM source */
ADC_Open(DADC_DHSCKDIV2,INP_AI0,INN_AI1,VRH_VDDA,VRL_VSS,
ADGN_1, VREGN_DIV1,DCSET_P0,OSR_65536,VCMS_REFOut);
```

## 6.2.2. ADC\_GetData

- **Prototype**

```
long ADC_GetData(void);
```

- **Description**

Get the A/D conversion data with signed.  
Configure the register AD1H:AD1M:AD1L

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

24-bit conversion data

- **Example**

```
/* Get the ADC conversion data. */  
long ADC_DATA;  
ADC_DATA = ADC_GetData();
```

## 6.2.3. ADC\_Enable

- **Prototype**

ADC\_Enable()

- **Description**

Enable A/D conversion function  
Configure the register AD1CN0[7]=1.

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Enable ADC function */  
ADC_Enable();
```

## 6.2.4. ADC\_Disable

- **Prototype**

ADC\_Disable()

- **Description**

Disable A/D conversion function  
Clear the register AD1CN0[7].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Disable ADC function */
```

```
ADC_Disable();
```

## 6.2.5. ADC\_INT\_Enable

- **Prototype**

```
ADC_INT_Enable()
```

- **Description**

Enable ADC interrupt function.

Configure the register INTE0[5]=1.

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/HY17M/ADC.h

- **Return Value**

None

- **Example**

```
/* Enable ADC interrupt function. */
```

```
ADC_INT_Enable();
```

## 6.2.6. ADC\_INT\_Disable

- **Prototype**

```
ADC_INT_Disable()
```

- **Description**

Disable ADC interrupt function.

Clear the register INTE0[5].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Disable ADC interrupt function. */
```

```
ADC_INT_Disable();
```

### **6.2.7. ADC\_INT\_IsFlag**

- **Prototype**

ADC\_INT\_IsFlag()

- **Description**

Read the ADC interrupt flag.

Read the register INTF0[5].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the ADC interrupt flag. */  
unsigned char flag;  
flag = ADC_INT_IsFlag();
```

### **6.2.8. ADC\_INT\_ClearFlag**

- **Prototype**

ADC\_INT\_ClearFlag()

- **Description**

Clear the ADC interrupt flag.

Clear the register INTF0[5].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Clear the ADC interrupt flag. */  
ADC_INT_ClearFlag();
```

### **6.2.9. ADC\_OSRSelect**

- **Prototype**

ADC\_OSRSelect(OSRSel)

- **Description**

Set the ADC OSR.

Configure the register 0x41100[5:2]

- **Parameters**

OSRSel [in] : Specify the ADC OSR. (The following output rate is calculated when clock is 2MHZ)

OSR_64	: Data Output Rate is 31250sps
OSR_128	: Data Output Rate is 15625sps
OSR_256	: Data Output Rate is 7813sps
OSR_512	: Data Output Rate is 3906sps
OSR_1024	: Data Output Rate is 1953sps
OSR_2048	: Data Output Rate is 977sps
OSR_4096	: Data Output Rate is 488sps
OSR_8192	: Data Output Rate is 244sps
OSR_16384	: Data Output Rate is 122sps
OSR_32768	: Data Output Rate is 61sps
OSR_65536	: Data Output Rate is 31sps

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Set the OSR of 32768 data rate 61sps. */  
ADC_OSRSelect(OSR_32768);
```

## 6.2.10. ADC\_CMFREnable

- **Prototype**

ADC\_CMFREnable()

- **Description**

Enable Comb filter reset control.

Configure the register AD1CN0[0]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Enable Comb filter reset control. */  
ADC_CMFREnable();
```

### 6.2.11. ADC\_CMFRDisable

- **Prototype**

ADC\_CMFRDisable()

- **Description**

Disable Comb filter reset control.

Clear the register AD1CN0[0].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Disable Comb filter reset control. */
```

```
ADC_CMFRDisable();
```

### 6.2.12. ADC\_VRXSelect

- **Prototype**

ADC\_VRXSelect(VRXSel)

- **Description**

Set the ADC full reference range select.

Configure the register AD1CN1[5]

- **Parameters**

VRXSel [in] : Specify the VREF gain. VREF= VRPS-VRNS

VREGN\_DIV2 : VREF \* 1/2

VREGN\_DIV1 : VREF\* 1

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Set the ADC full reference range input. */
```

```
ADC_VRGainSelect(VREGN_DIV2 );
```

### 6.2.13. ADC\_GainSelect

- **Prototype**

ADC\_GainSelect(adgn,vregn)

- **Description**

Input signal gain for ADC.

Configure the register AD1CN1[2:0]/AD1CN1[5]

- **Parameters**

adgn [in] : Specify the ADC gain.

ADGN\_1DIV4 : x 1/4

ADGN\_1DIV2 : x 1/2

ADGN\_1 : x 1

ADGN\_2 : x 2

ADGN\_4 : x 4

ADGN\_8 : x 8

ADGN\_16 : x 16

ADGN\_RSVD : x 16

VRXSel [in] : Specify the VREF gain.

VREGN\_DIV2 : VREF \* 1/2

VREGN\_DIV1 : VREF\* 1

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

/\* Set the ADC gain is 8\*2

```
ADC_GainConfig(ADGN_8,VREGN_DIV2);
```

## 6.2.14. ADC\_DCSETSelect

- **Prototype**

```
ADC_DCSETSelect(dcset)
```

- **Description**

DC offset input voltage selection (VREF=REFP-REFN)

Configure the register AD1CN2[3:0]

- **Parameters**

dcset [in] : Specify the ADC DCSET.

DCSET\_P0 : 0 VREF

DCSET\_P1DIV8 : + VREF\* 1/8

DCSET\_P2DIV8 : + VREF\* 2/8

DCSET\_P3DIV8 : + VREF\* 3/8

DCSET\_P4DIV8 : + VREF\* 4/8

DCSET\_P5DIV8 : + VREF\* 5/8

DCSET\_P6DIV8 : + VREF\* 6/8

DCSET\_P7DIV8 : + VREF\* 7/8

```
DCSET_N0      : 0VREF
DCSET_N1DIV8  : -VREF* 1/8
DCSET_N2DIV8  : -VREF* 2/8
DCSET_N3DIV8  : -VREF* 3/8
DCSET_N4DIV8  : -VREF* 4/8
DCSET_N5DIV8  : -VREF* 5/8
DCSET_N6DIV8  : -VREF* 6/8
DCSET_N7DIV8  : -VREF* 7/8
```

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Set the DC offset of +1/8 voltage. */
ADC_DCSETSelc(DCSET_P1DIV8);
```

### 6.2.15. ADC\_ENACMEnable

- **Prototype**

ADC\_ENACMEnable()

- **Description**

Enable ADC common mode voltage.

Configure the register AD1CN5[7]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Enable ADC common mode voltage. */
ADC_ENACMEnable();
```

### 6.2.16. ADC\_ENACMDisable

- **Prototype**

ADC\_ENACMDisable()

- **Description**

Disable ADC common mode voltage.

Clear the register AD1CN5[7]

- **Parameters**

- None
- **Include**  
Driver/HY17M/HY17M24/ADC.h
- **Return Value**  
None
- **Example**

```
/* Disable ADC common mode voltage. */  
ADC_ENACMDDisable();
```

## 6.2.17. ADC\_ACMBufSelect

- **Prototype**  
ADC\_ACMBufSelect(SELVINSel)
- **Description**  
Select ADC common mode voltage source.  
Configure the register AD1CN2[4]
- **Parameters**  
SELVINSel [in] : ACM voltage source
  - SELVIN\_1V2 : 1.2V
  - SELVIN\_VDDADIV2 : VDDA/2
- **Include**  
Driver/HY17M/HY17M24/ADC.h
- **Return Value**  
None
- **Example**

```
/* Select 1.2V as ADC common mode voltage source. */  
ADC_ACMBufSelect(SELVIN_1V2);
```

## 6.2.18. ADC\_VINSelect

- **Prototype**  
ADC\_VINSelect(inp,inn)
- **Description**  
Configure the ADC signal input (positive and negative) source.  
Configure the register AD1CN3[7:0]
- **Parameters**  
inp [in] : Select positive input source
  - INP\_AI0 : AI0
  - INP\_AI1 : AI1
  - INP\_AI2 : AI2

INP_AI4	:	AI4
INP_AI6	:	AI6
INP_AI8	:	AI8
INP_AI10	:	AI10
INP_AI12	:	AI12
INP_AI14	:	AI14
INP_OPOI	:	OPOI
INP_VDDA	:	VDDA
INP_REF0I	:	REF0I
INP_TS0	:	TS0
INP_TS1	:	TS1
INP_VSS	:	VSS
INP_DAOI	:	DAOI

inn [in] : Select negative input source

INN_AI0	:	AI0
INN_AI1	:	AI1
INN_AI2	:	AI2
INN_AI5	:	AI5
INN_AI7	:	AI7
INN_AI9	:	AI9
INN_AI11	:	AI11
INN_AI13	:	AI13
INN_VDDDIV10	:	VDD/10
INN_OPOI	:	OPOI
INN_VDDA	:	VDDA
INN_REF0I	:	REF0I
INN_TS0	:	TS0
INN_TS1	:	TS1
INN_VSS	:	VSS
INN_DAOI	:	DAOI

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Set the ADC signal input source AI0---AI1 */
ADC_VINSelect( INP_AI0, INN_AI1);
```

### **6.2.19. ADC\_VRINSelect**

- **Prototype**

ADC\_VRINSelect(vrh,vrl)

- **Description**

Set the ADC reference voltage.

Configure the register AD1CN4[7:6]/AD1CN4[5:4].

- **Parameters**

vrh [in] : Specify the ADC VRH

VRH\_VDDA : Reference voltage VDDA

VRH\_AI0 : Reference voltage AI0

VRH\_AI10 : Reference voltage AI10

VRH\_REF0I : Reference voltage REF0I

vrl [in] : Specify the ADC VRL

VRL\_VSS : Reference voltage VSS

VRL\_AI2 : Reference voltage AI2

VRL\_AI4 : Reference voltage AI4

VRL\_REF0I : Reference voltage REF0I

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Set the ADC reference voltage VRH=AI010, VRL=AI4 */
```

```
ADC_VRINSelect(VRH_AI10,VRL_AI4);
```

## 6.2.20. ADC\_INXSelect

- **Prototype**

ADC\_INXSelect(INXSel)

- **Description**

Configure the ADC signal input (positive and negative) exchange controller

Configure the register AD1CN4[3:2]

- **Parameters**

INXSel [in] : Select input exchange mode

INX\_NORMAL : INP→ADH, NN→ADL

INX\_INN : INN→ADH&ADL, INP floating

INX\_INP : INP→ADH&ADL, INN floating

INX\_CROSS : INP→ADL, INN→ADH

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Set input exchange mode INP→ADH, INN→ADL */
ADC_INXConfig(INX_NORMAL);
```

### 6.2.21. ADC\_ENINXCH\_Enable

- **Prototype**

```
ADC_ENINXCH_Enable()
```

- **Description**

Enable the ADC signal input (positive and negative) auto exchange. Configure the register INX[1:0]=00b and INX[1:0]=11b change over.

Configure the register CSFCN1[5]=1

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/ADC.h
```

- **Return Value**

None

- **Example**

```
/* Enable the ADC signal input (positive and negative) auto exchange */
CSFON_Enable();
ADC_ENINXCH_Enable();
```

### 6.2.22. ADC\_ENINXCH\_Disable

- **Prototype**

```
ADC_ENINXCH_Disable()
```

- **Description**

Disable the ADC signal input (positive and negative) auto exchange.

Clear the register CSFCN1[5]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/ADC.h
```

- **Return Value**

None

- **Example**

```
/* Disable the ADC signal input (positive and negative) auto exchange */
CSFON_Enable();
ADC_ENINXCH_Disable();
```

### 6.2.23. ADC\_VCMSSelect

- **Prototype**

ADC\_VCMSSelect(vcms)

- **Description**

Select the ADC common mode voltage source.

Configure the register AD1CN5[5]

- **Parameters**

cvms [in] : Select the ACM voltage source

VCMS\_REFoint : ADC common mode voltage from REFOint

VCMS\_ACMint : ADC common mode voltage from ACMint

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* ADC common mode voltage from ACMint */
```

```
ADC_VCMSSelect(VCMS_ACMint);
```

### 6.2.24. ADC\_REFIOSel

- **Prototype**

ADC\_REFIOSel(Sel)

- **Description**

Select the REFOI input sourc

Configure the register MCCN1[6]

- **Parameters**

Sel[in] : Select the REFOI input source

VRSEL\_REFoint : REFOI from REFOint

VRSEL\_ACMint : REFOI from ACMint

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* Select the REFOI input sourc from REFOint . */
```

```
ADC_REFIOSel(VRSEL_REFoint);
```

### 6.2.25. ADC\_ENTPSEnable

- **Prototype**

ADC\_ENTPSEnable()

- **Description**

Enable TPS function.

Configure the register AD1CN5[1]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

/\*Enable TPS function \*/

```
ADC_ENTPSEnable();
```

### 6.2.26. ADC\_ENTPSDisable

- **Prototype**

ADC\_ENTPSDisable()

- **Description**

Disable TPS function.

Clear the register AD1CN5[1]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

/\* Disable TPS function \*/

```
ADC_ENTPSDisable();
```

### 6.2.27. ADC\_TPSSelect

- **Prototype**

ADC\_TPSSelect(TPSSel)

- **Description**

Configure the TPS output voltage phase control.

Configure the register AD1CN5[0]

- **Parameters**

TPSSel [in] : TPS output voltage phase control

TPSCH\_NORMAL : normal

TPSCH\_REVERSE : inversion

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* TPS output voltage phase normal */
```

```
ADC_TPSSelect(TPSCH_NORMAL);
```

## 6.2.28. ADC\_DAFMSelect

- **Prototype**

```
ADC_DAFMSelect(DAFMSel)
```

- **Description**

Configure comb filter output data format.

Configure the register LVDCN[7]

- **Parameters**

DAFMSel [in] :

DAFM\_NORMAL : Normal format

DAFM\_CHOPPER : Chopper Result format, first data(ADC1 + (ADC2))/2 · second data(ADC2+ADC3)/2, third data(ADC2 +ADC3)/2, etc.

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/* comb filter output data normal format */
```

```
ADC_DAFMSelect(DAFM_NORMAL);
```

## 6.2.29. ADC\_ENCH\_Enable

- **Prototype**

```
ADC_ENCH_Enable()
```

- **Description**

Enable ADC chopper. Need to configure the register ENINXCH=1, next configure the register ENCH=1.

Configure the register LVDCN[6]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/*Enable ADC Chopper */  
ADC_ENINXCH_Enable();  
ADC_ENCH_Enable();
```

### 6.2.30. ADC\_ENCH\_Disable

- **Prototype**

ADC\_ENCH\_Disable()

- **Description**

Disable ADC chopper.

Clear the register LVDCN[6]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/ADC.h

- **Return Value**

None

- **Example**

```
/*Disable ADC Chopper */  
ADC_ENINXCH_Enable();  
ADC_ENCH_Disable();
```

## 7. UART Driver

### 7.1. Introduction

The Universal Asynchronous Receiver/Transmitter (UART) performs a serial-to-parallel conversion on data characters received from the peripheral such as MODEM, and a parallel-to-serial conversion on data characters received from the CPU. Details please refer to the section in the target chip specification titled UART.

Item	Functions	Description
01	UART_Open	Set UART module
02	UART_BGRSet	Configure the baud of UART
03	UART_Enable	Enable the UART function
04	UART_Disable	Disable the UART function
05	UART_TXEnable	Enable the transmit function of UART
06	UART_TXDisable	Disable the transmit function of UART
07	UART_TX9Enable	Enable the function of TX port send 9 bits
08	UART_TX9Disable	Disable the function of TX port send 9 bits
09	UART_TX9Data	Configure the bit-9 of send data
10	UART_Parity	Configure the parity of UART
11	UART_WUEEnable	Enable receive wake-up mode of UART
12	UART_WUEDisable	Disable receive wake-up mode of UART
13	UART_CREnable	Enable the receive function of UART
14	UART_CRDisable	Disable the receive function of UART
15	UART_CR9Enable	Enable the function of RC port receive 9 bits
16	UART_CR9Disable	Disable the function of RC port receive 9 bits
17	UART_ADDEnable	Enable the addrss detect function
18	UART_ADDDisable	Disable the addrss detect function
19	UART_ABDEnable	Enable the auto baud rate function
20	UART_ABDDisable	Disable the auto baud rate function
21	UART_INT_TXEnable	Enable TX interrupt function
22	UART_INT_TXDisable	Disable TX interrupt function
23	UART_INT_TXIsFlag	Read the TX interrupt flag
24	UART_INT_TXCLEARFlag	Clear the TX interrupt flag
25	UART_INT_RCEnable	Enable RC interrupt function
26	UART_INT_RCDisable	Disable RC interrupt function
27	UART_INT_RCIsFlag	Read the RC interrupt flag
28	UART_INT_RCCLEARFlag	Clear the RC interrupt flag
29	UART_GETRC9	Read the bit 9 value of receive data
30	UART_GETPERR	Read the Parity Error flag of UART
31	UART_GETFERR	Read the RC Fram error flag
32	UART_GETOERR	Read the RC Buffer over run error flag
33	UART_GETRCIDL	Read the RC port status
34	UART_GETTRMT	Read the Transmit shift register(TSR) status
35	UART_GETABDOVF	Read the auto baud rate overflow flag

## 7.2. Functions

### 7.2.1. UART\_Open

- **Prototype**

```
void UART_Open(unsigned int uBG0R,  
              unsigned char uDataBits,  
              unsigned char uParity,  
              unsigned char Uartxsel);
```

- **Description**

Enable the TX/RC function of UART. Configure baud, parity, TX/RC port, and data length. Enable the TX/RC interrupt function.

Configure the register UR0CN/BA0CN/BG0RH/BG0RL/TRISC1/PT1M1/INTE1.

- **Parameter**

uBG0R [in] : 0x00~0xFFFF, Configure baud.

uDataBits [in] : Set UART data length

8 : 8 bits

9 : 9 bits

uParity [in] : Set UART parity mode

PARITY\_ODD : Odd parity

PARITY\_Even : Even parity

PARITY\_None : None

Uartxsel [in] : Select TX/RC port

0 : PT1.5/PT1.6

1 : PT2.0/PT2.1

2 : PT3.6/PT3.7

3 : PT3.4/PT3.5

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* HAO=2MHZ, configure UART baud is 9600bp, 8-bit data, None parity, PT1.5/PT1.6 as TX/RC pin */  
UART_Open(0x33,8,PARITY_None,0);
```

### 7.2.2. UART\_BGRSet

- **Prototype**

```
UART_BGRSet(uBG0R)
```

- **Description**

Configure UART baud.

Configure the register BG0RL/BG0RH[4:0]

- **Parameter**

uBG0R [in] : 0x00~0xFFFF, Configure baud.

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* HAO=2MHZ, configure UART baud is 9600bp */  
UART_BGRSet(0x33);
```

## 7.2.3. UART\_Enable

- **Prototype**

UART\_Enable();

- **Description**

Enable UART function.

Configure the register UR0CN[7]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Enable UART function */  
UART_Enable();
```

## 7.2.4. UART\_Disable

- **Prototype**

UART\_Disable();

- **Description**

Disable UART function.

Clear the register UR0CN[7]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/*Disable UART function */  
UART_Disable();
```

### 7.2.5. **UART\_TXEnable**

- **Prototype**

```
UART_TXEnable();
```

- **Description**

Enable the transmit function of UART.

Configure the register UR0CN[6]=1

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/UART.h
```

- **Return Value**

None

- **Example**

```
/* Enable UART function */  
UART_TXEnable();
```

### 7.2.6. **UART\_TXDisable**

- **Prototype**

```
UART_TXDisable();
```

- **Description**

Disable the transmit function of UART.

Clear the register UR0CN[6]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/UART.h
```

- **Return Value**

None

- **Example**

```
/*Disable UART function */  
UART_TXDisable();
```

### 7.2.7. **UART\_TX9Enable**

---

- **Prototype**

UART\_TX9Enable();

- **Description**

Enable the function of TX send 9 bits.

Configure the register URCON[5]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

/\* Enable the function of TX send 9 bits. \*/

UART\_TX9Enable();

### 7.2.8. UART\_TX9Disable

- **Prototype**

UART\_TX9Disable();

- **Description**

Disable the function of TX send 9 bits.

Clear the register URCON[5]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

/\* Disable the function of TX send 9 bits. \*/

UART\_TX9Disable();

### 7.2.9. UART\_TX9Data

- **Prototype**

UART\_TX9Data ();

- **Description**

Configure the send data of bit 9.

Configure the register UR0CN[4]

- **Parameters**

Sel [in] : Configure the bit-9 of send data

TX9D\_1 : Set bit-9 of send data is 1

TX9D\_0 : Set bit-9 of send data is 0

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Set bit-9 of send data is 1 */  
UART_TX9Enable();  
UART_TX9Data(TX9D_1);
```

## 7.2.10. UART\_Parity

- **Prototype**

UART\_Parity(Sel);

- **Description**

Configure the parity of UART.

Configure the register UR0CN[3]

- **Parameters**

Sel [in] : Set UART parity mode

PARITY\_ODD : Odd parity

PARITY\_Even : Even parity

PARITY\_None : None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Set even parity of UART parity mode*/  
UART_Parity(PARITY_Even);
```

## 7.2.11. UART\_WUEEnable

- **Prototype**

UART\_WUEEnable();

- **Description**

Enable receive wake-up mode of UART.

Configure the register UR0CN[0]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Enable receive wake-up mode of UART */  
UART_WUEEnable();
```

## 7.2.12. **UART\_WUEDisable**

- **Prototype**

UART\_WUEDisable();

- **Description**

Disable receive wake-up mode of UART.

Clear the register UR0CN[0]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Disable receive wake-up mode of UART */  
UART_WUEDisable();
```

## 7.2.13. **UART\_CREnable**

- **Prototype**

UART\_CREnable();

- **Description**

Enable the receive function of UART.

Configure the register BA0CN[3]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Enable the receive function of UART. */  
UART_CREnable();
```

#### 7.2.14. **UART\_CRDDisable**

- **Prototype**

```
UART_CRDDisable();
```

- **Description**

Disable the receive function of UART.

Clear the register BA0CN[3]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Disable the receive function of UART. */  
UART_CRDDisable();
```

#### 7.2.15. **UART\_CR9Enable**

- **Prototype**

```
UART_CR9Enable();
```

- **Description**

Enable the function of RC port receive 9 bits.

Configure the register BA0CN[2]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Enable the function of RC port receive 9 bits. */  
UART_CR9Enable();
```

#### 7.2.16. **UART\_CR9Disable**

- **Prototype**

```
UART_CR9Disable();
```

- **Description**

Disable the function of RC port receive 9 bits.

Clear the register BA0CN[2]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Disable the function of RC port receive 9 bits. */  
UART_CR9Disable();
```

## 7.2.17. UART\_ADDEnable

- **Prototype**

UART\_ADDEnable();

- **Description**

Enable the address detect function.

Configure the register BA0CN[1]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Enable the address detect function. */  
UART_ADDEnable();
```

## 7.2.18. UART\_ADDDisable

- **Prototype**

UART\_ADDDisable();

- **Description**

Disable the address detect function.

Clear the register BA0CN[1]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Disable the address detect function. */  
UART_ABDDisable();
```

### 7.2.19. **UART\_ABDEnable**

- **Prototype**

```
UART_ABDEnable();
```

- **Description**

Enable the auto baud rate function.

Configure the register BA0CN[0]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Enable the auto baud rate function. */  
UART_ABDEnable();
```

### 7.2.20. **UART\_ABDDisable**

- **Prototype**

```
UART_ABDDisable();
```

- **Description**

Disable the auto-baud function.

Clear the register BA0CN[0]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Disable the auto-baud function. */  
UART_ABDDisable();
```

### 7.2.21. **UART\_INT\_TXEnable**

- **Prototype**

```
UART_INT_TxisEnable();
```

- **Description**

- **Description**  
Enable TX interrupt function.  
Configure the register INTE1[5]=1
- **Parameters**  
None
- **Include**  
Driver/HY17M/HY17M24/UART.h
- **Return Value**  
None
- **Example**  

```
/* Enable TX interrupt function. */  
UART_INT_TXEnable();
```

## 7.2.22. UART\_INT\_TXDisable

- **Prototype**  
UART\_INT\_TxisDisable();
- **Description**  
Disable TX interrupt function.  
Clear the register INTE1[5]
- **Parameters**  
None
- **Include**  
Driver/HY17M/HY17M24/UART.h
- **Return Value**  
None
- **Example**  

```
/* Enable TX interrupt function. */  
UART_INT_TxisDisable();
```

## 7.2.23. UART\_INT\_TxisFlag

- **Prototype**  
UART\_INT\_TxisFlag();
- **Description**  
Read the TX interrupt flag.  
Read the register INTF1[5]
- **Parameters**  
None
- **Include**  
Driver/HY17M/HY17M24/UART.h
- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the TX interrupt flag. */  
unsigned char flag ;  
flag = UART_INT_TXIsFlag();
```

#### **7.2.24. UART\_INT\_TXClearFlag**

- **Prototype**

UART\_INT\_TXClearFlag();

- **Description**

Clear the TX interrupt flag.

Clear the register INTF1[5]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/*Clear the TX interrupt flag. */  
UART_INT_TXClearFlag();
```

#### **7.2.25. UART\_INT\_RCEnable**

- **Prototype**

UART\_INT\_RCIIsEnable();

- **Description**

Enable RC interrupt function.

Configure the register INTE1[4]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/* Enable RC interrupt function. */  
UART_INT_RCEnable();
```

### **7.2.26. UART\_INT\_RCDisable**

- **Prototype**

```
UART_INT_RCIsDisable();
```

- **Description**

Disable RC interrupt function.

Clear the register INTE1[4]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/UART.h
```

- **Return Value**

None

- **Example**

```
/* Enable RC interrupt function. */  
UART_INT_RCEnable();
```

### **7.2.27. UART\_INT\_RCIsFlag**

- **Prototype**

```
UART_INT_RCIsFlag();
```

- **Description**

Read the RC interrupt flag.

Read the register INTF1[4]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/UART.h
```

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the RC interrupt flag. */  
unsigned char flag ;  
flag = UART_INT_RCIsFlag();
```

### **7.2.28. UART\_INT\_RCClearFlag**

- **Prototype**

```
UART_INT_RCClearFlag();
```

- **Description**

Clear the RC interrupt flag.

Clear the register INTF1[4]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/*Clear the RC interrupt flag. */  
UART_INT_RCClearFlag();
```

## 7.2.29. UART\_GETRC9

- **Prototype**

UART\_GETRC9();

- **Description**

Read the bit 9 value of receive data.

Read the register UR0STA[6]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

0 : The bit 9 data is 0

1 : The bit 9 data is 1

- **Example**

```
/* Read the bit 9 value of receive data. */  
unsigned char RC9D;  
RC9D = UART_GETRC9()>>6;
```

## 7.2.30. UART\_GETPERR

- **Prototype**

UART\_GETPERR();

- **Description**

Get the Parity Error flag of UART1.

Read the register UR0STA[5]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

0 : No parity error

1 : Parity error

- **Example**

```
/* Get the PERR flag. */  
unsigned char PERR_F;  
PERR_F = UART_GETPERR()>>5;
```

### 7.2.31. **UART\_GETFERR**

- **Prototype**

UART\_GETFERR()

- **Description**

Get the FERR flag of UART1.

Read the register UR0STA[4]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

0 : No framing error

1 : Framing error

- **Example**

```
/* Get the FERR flag. */  
unsigned char FERR_F ;  
FERR_F = UART_GETFERR()>>4;
```

### 7.2.32. **UART\_GETOERR**

- **Prototype**

UART\_GETOERR();

- **Description**

Get the OERR flag of UART1.

Read the register UR0STA[3]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

0 : No overrun error

1 : Overrun error

- **Example**

```
/* Get the OERR flag. */
unsigned char OERR_F;
OERR_F = UART_GETOERR()>>3;
```

## 7.2.33. **UART\_GETRCIDL**

- **Prototype**

UART\_GETRCIDL();

- **Description**

Read the RC port status.

Read the register UR0STA[2]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

0 : Idle

1 : Receiving

- **Example**

```
/* Get the RC port status. */
unsigned char flag ;
flag = UART_GETRCIDL()>>2;
```

## 7.2.34. **UART\_GETTRMT**

- **Prototype**

UART\_GETTRMT();

- **Description**

Read the Transmit shift register(TSR) status

Read the register UR0STA[1]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

0 : TSR is empty

1 : TSR is full

- **Example**

```
/* Get the TSR status */
```

```
unsigned char flag ;  
flag = UART_GETTRMT()>>1;
```

### 7.2.35. **UART\_GETABDOVF**

- **Prototype**

```
UART_GETABDOVF();
```

- **Description**

Read the auto baud rate overflow flag.

Read the register UR0STA[0]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/UART.h
```

- **Return Value**

0 : baudrate not overflow

1 : baudrate has been overflow

- **Example**

```
/* Get the auto baudrate overflow flag */  
unsigned char flag ;  
flag = UART_GETABDOVF();
```

## 8. CMP Driver

### 8.1. Introduction

The following functions are included in Comparator(CMP) Manager Section.

Item	Functions	Description
01	CMP_Open	Enable CMP function, configure the input channel, reference voltage, and select output port
02	CMP_RLOSet	Set the voltage source of ladder resistor, the resistor divider node, and configure hysteresis function
03	CMP_Enable	Enable CMP function
04	CMP_Disable	Disable CMP function
05	CMP_CMPResult	Read the comparison result of CMP
06	CMP_PInput	Select the CMP positive input channel
07	CMP_NInput	Select the CMP negative input channel
08	CMP_OutputSelect	Select the CMP output channel
09	CMP_OutReverse	Configure the CMP output phase control
10	CMP_2usLPFEnable	Enable the low-pass filter function
11	CMP_2usLPFDisable	Disable the low-pass filter function
12	CMP_MODESel	Configure the CMP mode control
13	CMP_CPRLOpen	Set the ladder resistor open
14	CMP_CPRLShort	Set the ladder resistor short
15	CMP_RLO_VrefSel	Configure the voltage source of ladder resistor
16	CMP_R_DASel	Configure the resistor divider node
17	CMP_CPDMSet	Configure the hysteresis function
18	CMP_INT_Enable	Enable CMP interrupt function
19	CMP_INT_Disable	Disable CMP interrupt function
20	CMP_INT_IsFlag	Read the CMP interrupt flag
21	CMP_INT_ClearFlag	Clear the CMP interrupt flag

### 8.2. Functions

#### 8.2.1. CMP\_Open

- **Prototype**

```
void CMP_Open(unsigned char cpps, unsigned char cpns, unsigned char cmphs, unsigned char cpor,
unsigned char enrcc);
```

- **Description**

Enable CMP function, configure the input channel, reference voltage, and select output port.

Configure the register MCCN0/MCCN1

- **Parameter**

cpps [in] : Select positive input channel

CPPS\_CH0 : CH0  
CPPS\_CH1 : CH1  
CPPS\_CH2 : CH2  
CPPS\_1V2 : 1.2V

cpns [in] : Select negative input channel

CPNS\_CH0 : CH0  
CPNS\_CH1 : CH1  
CPNS\_CH2 : CH2  
CPNS\_RLO : RLO

cmphs [in] : Select CMP mode

CMPHS\_NORMAL : Normal mode  
CMP\_LOWPOWER : Low-power mode

cpor [in] : Select output phase

CPOR\_INVERSE : Inversion  
CPOR\_NORMAL : Normal

enrcc [in] : Select output channel

ENRCC\_DISABLE : Disable  
ENRCC\_RC : Output to UART RC  
ENRCC\_PT16 : Output to PT1.6

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Enable CMP function, set input (positive/negative) channel CH1-CH2, output channel PT1.6, normal
mode, output inversion */
CMP_Open( CPPS_CH1, CPNS_CH2, CMPHS_NORMAL, CPOR_INVERSE, ENRCC_PT16 );
```

### 8.2.2. CMP\_RLOSet

- **Prototype**

```
void CMP_RLOSet(unsigned char cprh, unsigned char cprl, unsigned char cpda, unsigned char cpdm );
```

- **Description**

Set the voltage source of ladder resistor, the resistor divider node, and configure hysteresis function.

Configure the register MCCN1/MCCN2/MCCN3

- **Parameter**

cprh [in] : The ladder resistor voltage source

CPRH\_DISABLE : Disable

CPRH\_VDD : Voltage from VDD  
CPRH\_VDDA : Voltage from VDDA  
cprl [in] : The ladder resistor short control  
CPRL\_OPEN : The ladder resistor open  
CPRL\_SHORT : The ladder resistor short  
cpda [in] : The ladder resistor divider node control  
CPDA\_0 : 0  
CPDA\_1DIV32 : 1/32(CPRLH-CPPLL)  
CPDA\_2DIV32 : 2/32(CPRLH-CPPLL)  
CPDA\_3DIV32 : 3/32(CPRLH-CPPLL)  
CPDA\_4DIV32 : 4/32(CPRLH-CPPLL)  
CPDA\_5DIV32 : 5/32(CPRLH-CPPLL)  
CPDA\_6DIV32 : 6/32(CPRLH-CPPLL)  
CPDA\_7DIV32 : 7/32(CPRLH-CPPLL)  
CPDA\_8DIV32 : 8/32(CPRLH-CPPLL)  
CPDA\_9DIV32 : 9/32(CPRLH-CPPLL)  
CPDA\_10DIV32 : 10/32(CPRLH-CPPLL)  
CPDA\_11DIV32 : 11/32(CPRLH-CPPLL)  
CPDA\_12DIV32 : 12/32(CPRLH-CPPLL)  
CPDA\_13DIV32 : 13/32(CPRLH-CPPLL)  
CPDA\_14DIV32 : 14/32(CPRLH-CPPLL)  
CPDA\_15DIV32 : 15/32(CPRLH-CPPLL)  
CPDA\_16DIV32 : 16/32(CPRLH-CPPLL)  
CPDA\_17DIV32 : 17/32(CPRLH-CPPLL)  
CPDA\_18DIV32 : 18/32(CPRLH-CPPLL)  
CPDA\_19DIV32 : 19/32(CPRLH-CPPLL)  
CPDA\_20DIV32 : 20/32(CPRLH-CPPLL)  
CPDA\_21DIV32 : 21/32(CPRLH-CPPLL)  
CPDA\_22DIV32 : 22/32(CPRLH-CPPLL)  
CPDA\_23DIV32 : 23/32(CPRLH-CPPLL)  
CPDA\_24DIV32 : 24/32(CPRLH-CPPLL)  
CPDA\_25DIV32 : 25/32(CPRLH-CPPLL)  
CPDA\_26DIV32 : 26/32(CPRLH-CPPLL)  
CPDA\_27DIV32 : 27/32(CPRLH-CPPLL)  
CPDA\_28DIV32 : 28/32(CPRLH-CPPLL)  
CPDA\_29DIV32 : 29/32(CPRLH-CPPLL)  
CPDA\_30DIV32 : 30/32(CPRLH-CPPLL)  
CPDA\_31DIV32 : 31/32(CPRLH-CPPLL)

cpdm [in] : Hysteresis function control

CPDM0\_ENABLE : Enable CPDA[0] hysteresis function, CPDA[0]=CPOB

CPDM1\_ENABLE : Enable CPDA[1] hysteresis function, CPDA[1]=CPOB

CPDM2\_ENABLE : Enable CPDA[2] hysteresis function, CPDA[2]=CPOB

CPDM3\_ENABLE : Enable CPDA[3] hysteresis function, CPDA[3]=CPOB

CPDM4\_ENABLE : Enable CPDA[4] hysteresis function, CPDA[4]=CPOB

CPDM\_DISABLE : Hysteresis function disable

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/*Set CMP negative input source from RLO, reference voltage source from VDDA, the ladder resistor
short, divider node 5/32(CPRLH-CPRLL), enable CPDA[0] hysteresis function. */
CMP_NInput(CPNS_RLO);
CMP_RLOSet(CPRH_VDDA,CPRL_OPEN,CPDA_5DIV32,0x01);
```

## 8.2.3. CMP\_Enable

- **Prototype**

CMP\_Enable();

- **Description**

Enable CMP function.

Configure the register MCCN0[0]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Enable CMP function. */
```

CMP\_Enable();

## 8.2.4. CMP\_Disable

- **Prototype**

CMP\_Disable();

- **Description**

Disable CMP function.

Clear the register MCCN0[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Disable CMP function. */
```

```
CMP_Disnable();
```

### **8.2.5. CMP\_CMPResult**

- **Prototype**

```
CMP_CMPResult();
```

- **Description**

Read the comparison result of CMP.

Read the register MCCN0[5].

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

0 : Negative input signal > Positive input signal

1 : Positive input signal > Negative input signal

- **Example**

```
/* Read the comparison result */
```

```
unsigned char cmp_result;
```

```
cmp_result = CMP_CMPResult()>>5;
```

### **8.2.6. CMP\_PInput**

- **Prototype**

```
CMP_PInput(Sel);
```

- **Description**

Select the CMP positive input channel.

Configure the register MCCN1[3:2].

- **Parameter**

Sel [in] : the CMP positive input channel

CPPS\_CH0 : CH0

CPPS\_CH1 : CH1

CPPS\_CH2 : CH2  
CPPS\_1V2 : 1.2V

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Set the CH2 as positive input channel */  
CMP_PInput(CPPS_CH2 );
```

### 8.2.7. CMP\_NInput

- **Prototype**

CMP\_NInput(Sel);

- **Description**

Select the CMP negative input channel.

Configure the register MCCN1[1:0].

- **Parameter**

Sel [in] : the CMP negative input channel

CPNS\_CH0 : CH0  
CPNS\_CH1 : CH1  
CPNS\_CH2 : CH2  
CPNS\_1V2 : 1.2V

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Set 1.2V as negative input channel */  
CMP_NInput(CPNS_1V2 );
```

### 8.2.8. CMP\_OutputSelect

- **Prototype**

CMP\_OutputSelect(Sel);

- **Description**

Select the CMP output channel.

Configure the register MCCN0[7:6]

- **Parameter**

Sel [in] : Select the output channel.

ENRCC\_DISABLE : Disable  
ENRCC\_RC : Output to UART RC port  
ENRCC\_PT16 : Output to PT1.6

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Set the CMP output to PT1.6 */  
CMP_OutputSelect(ENRCC_PT16 );
```

## 8.2.9. CMP\_OutReverse

- **Prototype**

CMP\_OutReverse(Sel);

- **Description**

Configure the CMP output phase control.

Configure the register MCCN0[3].

- **Parameter**

Sel [in] : Configure the output phase control.

CPOR\_INVERSE : Inverse

CPOR\_NORMAL : Normal

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Set the CMP output to PT1.6 */  
CMP_OutputSelect(ENRCC_PT16 );
```

## 8.2.10. CMP\_2usLPFEnable

- **Prototype**

CMP\_2usLPFEnable();

- **Description**

Enable the low-pass filter function.

Configure the register MCCN0[2]=1.

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Enable the low-pass filter function. */  
CMP_2usLPFEnable();
```

## 8.2.11. CMP\_2usLPFDisable

- **Prototype**

```
CMP_2usLPFDisable();
```

- **Description**

Disable the low-pass filter function.

Clear the register MCCN0[2].

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/CMP.h
```

- **Return Value**

None

- **Example**

```
/* Disable the low-pass filter function. */  
CMP_2usLPFDisable();
```

## 8.2.12. CMP\_MODESel

- **Prototype**

```
CMP_MODESel (Sel);
```

- **Description**

Configure the CMP mode control.

Clear the register MCCN0[1].

- **Parameter**

Sel [in] : Configure the CMP mode control.

CMPHS\_LOWPOWER : Low power mode

CMPHS\_NORMAL : Normal mode

- **Include**

```
Driver/HY17M/HY17M24/CMP.h
```

- **Return Value**

None

- **Example**

```
/* Set the CMP of low power */  
CMP_MODESel(CMPHS_LOWPOWER) ;
```

### 8.2.13. CMP\_CPRLOpen

- **Prototype**

```
CMP_CPRLOpen();
```

- **Description**

Set the ladder resistor open.

Configure the register MCCN1[7].

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/CMP.h
```

- **Return Value**

None

- **Example**

```
/* Set the ladder resistor open. */  
CMP_CPRLOpen();
```

### 8.2.14. CMP\_CPRLShort

- **Prototype**

```
CMP_CPRLShort();
```

- **Description**

Set the ladder resistor open.

Clear the register MCCN1[7].

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/CMP.h
```

- **Return Value**

None

- **Example**

```
/* Set the ladder resistor short. */  
CMP_CPRLShort();
```

### 8.2.15. CMP\_RLO\_VrefSel

- **Prototype**

```
CMP_RLO_VrefSel(Sel);
```

- **Description**

Configure the voltage source of ladder resistor.

Configure the register MCCN1[5:4]

- **Parameter**

Sel [in] : The ladder resistor voltage source  
CPRH\_DISABLE : Disable  
CPRH\_VDD : Voltage from VDD  
CPRH\_VDDA : Voltage from VDDA

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Set the ladder resistor voltage from VDDA. */  
CMP_RLO_VrefSel(CPRH_VDDA);
```

### 8.2.16. CMP\_R\_DASel

- **Prototype**

CMP\_R\_DASel(Sel);

- **Description**

Configure the resistor divider node.

Configure the register MCCN2[4:0]

- **Parameter**

Sel [in] : Select the resistor divider node

CPDA\_0 : 0  
CPDA\_1DIV32 : 1/32(CPRLH-CPRLL)  
CPDA\_2DIV32 : 2/32(CPRLH-CPRLL)  
CPDA\_3DIV32 : 3/32(CPRLH-CPRLL)  
CPDA\_4DIV32 : 4/32(CPRLH-CPRLL)  
CPDA\_5DIV32 : 5/32(CPRLH-CPRLL)  
CPDA\_6DIV32 : 6/32(CPRLH-CPRLL)  
CPDA\_7DIV32 : 7/32(CPRLH-CPRLL)  
CPDA\_8DIV32 : 8/32(CPRLH-CPRLL)  
CPDA\_9DIV32 : 9/32(CPRLH-CPRLL)  
CPDA\_10DIV32 : 10/32(CPRLH-CPRLL)  
CPDA\_11DIV32 : 11/32(CPRLH-CPRLL)  
CPDA\_12DIV32 : 12/32(CPRLH-CPRLL)  
CPDA\_13DIV32 : 13/32(CPRLH-CPRLL)  
CPDA\_14DIV32 : 14/32(CPRLH-CPRLL)  
CPDA\_15DIV32 : 15/32(CPRLH-CPRLL)  
CPDA\_16DIV32 : 16/32(CPRLH-CPRLL)

CPDA\_17DIV32 : 17/32(CPRLH-CPRLL)  
CPDA\_18DIV32 : 18/32(CPRLH-CPRLL)  
CPDA\_19DIV32 : 19/32(CPRLH-CPRLL)  
CPDA\_20DIV32 : 20/32(CPRLH-CPRLL)  
CPDA\_21DIV32 : 21/32(CPRLH-CPRLL)  
CPDA\_22DIV32 : 22/32(CPRLH-CPRLL)  
CPDA\_23DIV32 : 23/32(CPRLH-CPRLL)  
CPDA\_24DIV32 : 24/32(CPRLH-CPRLL)  
CPDA\_25DIV32 : 25/32(CPRLH-CPRLL)  
CPDA\_26DIV32 : 26/32(CPRLH-CPRLL)  
CPDA\_27DIV32 : 27/32(CPRLH-CPRLL)  
CPDA\_28DIV32 : 28/32(CPRLH-CPRLL)  
CPDA\_29DIV32 : 29/32(CPRLH-CPRLL)  
CPDA\_30DIV32 : 30/32(CPRLH-CPRLL)  
CPDA\_31DIV32 : 31/32(CPRLH-CPRLL)

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Set the resistor divider node 5/32(CPRLH-CPRLL) . */  
CMP_R_DASel(CPDA_15DIV32);
```

### 8.2.17. CMP\_CPDMSet

- **Prototype**

CMP\_CPDMSet(Set);

- **Description**

Configure the hysteresis function.

Configure the register MCCN3[4 :0]

- **Parameter**

cpdm [in] : Hysteresis function control

CPDM0\_ENABLE : Enable CPDA[0] hysteresis function, CPDA[0]=CPOB

CPDM1\_ENABLE : Enable CPDA[1] hysteresis function, CPDA[1]=CPOB

CPDM2\_ENABLE : Enable CPDA[2] hysteresis function, CPDA[2]=CPOB

CPDM3\_ENABLE : Enable CPDA[3] hysteresis function, CPDA[3]=CPOB

CPDM4\_ENABLE : Enable CPDA[4] hysteresis function, CPDA[4]=CPOB

CPDM\_DISABLE : Hysteresis function disable

- **Include**

Driver/HY17M/HY17M24/CMP.h

- **Return Value**

None

- **Example**

```
/* Enable CPDA[0] hysteresis function. */  
CMP_CPDMSet (0x01);
```

### **8.2.18. CMP\_INT\_Enable**

- **Prototype**

```
CMP_INT_Enable();
```

- **Description**

Enable CMP interrupt function.

Configure the register INTE2[2]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/CMP.h
```

- **Return Value**

None

- **Example**

```
/* Enable CMP interrupt function. */  
CMP_INT_Enable();
```

### **8.2.19. CMP\_INT\_Disable**

- **Prototype**

```
CMP_INT_Disable();
```

- **Description**

Disable CMP interrupt function.

Clear the register INTE2[2]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/CMP.h
```

- **Return Value**

None

- **Example**

```
/* Disable CMP interrupt function. */  
CMP_INT_Disable();
```

### **8.2.20. CMP\_INT\_IsFlag**

---

- **Prototype**

CMP\_INT\_IsFlag();

- **Description**

Read the CMP interrupt flag.

Read the register INTF2[2]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the CMP interrupt flag. */  
unsigned char flag ;  
flag = CMP_INT_IsFlag();
```

### 8.2.21. CMP\_INT\_ClearFlag

- **Prototype**

CMP\_INT\_ClearFlag();

- **Description**

Clear the CMP interrupt flag.

Clear the register INTF2[2]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/UART.h

- **Return Value**

None

- **Example**

```
/*Clear the CMP interrupt flag. */  
CMP_INT_ClearFlag();
```

## 9. OPAMP Driver

### 9.1. Introduction

The following functions are included in Rail-to-Rail OPAMP Manager Section.

Item	Functions	Description
01	OPA_Out2Dig_Open	Configure the OPA operate on digital mode, set the output phase, and enable the interrupt function
02	OP1_Enable	Enable OP1 function
03	OP1_Disable	Disable OP1 function
04	OP1_InputShort	Configure the OP1 input short control
05	OP1_INPSet	Configure the OP1 positive input signal source
06	OP1_INN0Set	Configure the OP1 negative input signal source
07	OP1_INN1Set	Configure the OP1 negative input signal source
08	OP1_AnalogyOutSel	Configure the OP1 analog output control
09	OP1_DigitalOutEnable	Enable the OP1 digital output function
10	OP1_DigitalOutDisable	Disable the OP1 digital output function
11	OP1_OutputReverse	Configure the OP1 output phase control
12	OP1_10pF_AppSel	Configure the OP1 built-in capacitor operating mode
13	OP1_FilterEnable	Enable filter function
14	OP1_FilterDisable	Disable filter function
15	OP1_GAINSelect	Configure the negative feedback amplification control
16	OP1_GAINSourceSel	Select the negative feedback source
17	OP1_INT_Trigger	Configure the OP1 interrupt trigger mode
18	OP1_INT_Enable	Enable the OP1 interrupt function
19	OP1_INT_Disable	Disable the OP1 interrupt function
20	OP1_INT_IsFlag	Read the OP1 interrupt flag
21	OP1_INT_ClearFlag	Clear the OP1 interrupt flag

### 9.2. Functions

#### 9.2.1. OPA\_Out2Dig\_Open

- Prototype

```
void OPA_Out2Dig_Open(unsigned char ins, unsigned char opdr, unsigned char trig);
```

- **Description**

Configure the OPA operate on digital mode, set the output phase, and enable the interrupt function.

Configure the register OP1CN0

- **Parameter**

ins[in] : The OP1 input short control

OPINS\_SHORT : Short

OPINS\_NORMAL : Open

opdr[in] : The OP1 output phase control

OPDR\_REVERSE : Reverse

OPDR\_NORMAL : Normal

trig [in] : The OP1 interrupt trigger mode

OPOEG\_EDGEFALL : Edge fall, OPC status 1→0

OPOEG\_EDGERISE : Edge rise, OPC status 0→1

OPOEG\_LEV : OPC status 1→0 or 0→1

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Set the OPA operate to digital mode, disable the input short control, output normal phase, set the edge
rise trigger mode */
```

```
OP1_Out2Dig_Open( OPINS_NORMAL, OPDR_NORMAL, OPOEG_EDGERISE );
```

## 9.2.2. OP1\_Enable

- **Prototype**

```
OP1_Enable();
```

- **Description**

Enable OP1 function.

Configure the register OP1CN0[0] =1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Enable OP1 function. */
```

```
OP1_Enable();
```

### 9.2.3. OP1\_Disable

- **Prototype**

OP1\_Disable();

- **Description**

Disable OP1 function.

Clear the register OP1CN0[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

/\* Disable OP1 function. \*/

OP1\_Disable();

### 9.2.4. OP1\_InputShort

- **Prototype**

OP1\_InputShort(Set);

- **Description**

Configure the OP1 input (positive and negative) short control.

Configure the register OP1CN0[7]

- **Parameter**

Set [in] : Configure the input (positive and negative) short control.

OPINS\_SHORT : Short

OPINS\_NORMAL : Open

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

/\* Set the OP1 input (positive and negative) short. \*/

OP1\_InputShort( OPINS\_SHORT );

### 9.2.5. OP1\_INPSet

- **Prototype**

OP1\_INP(Set);

- **Description**

Select OP1 positive input selection.

Configure the register OP1NP[7:0]

- **Parameter**

Set [in] : OP1 positive input selection.

OP1INP_AI0_ENABLE	:	AI0
OP1INP_AI2_ENABLE	:	AI2
OP1INP_AI3_ENABLE	:	AI3
OP1INP_AI10_ENABLE	:	AI10
OP1INP_REF0I_ENABLE	:	REF0I
OP1INP_DAOI_ENABLE	:	DAOI
OP1INP_AI13_ENABLE	:	AI13
OP1INP_VSS_ENABLE	:	VSS

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Selection the OP1 positive input of AI3. */
OP1_INPSet( OP1INP_AI3_ENABLE );
```

## 9.2.6. OP1\_INN0Set

- **Prototype**

OP1\_INN0Set(Set);

- **Description**

Select OP1 negative input selection.

Configure the register OP1NN0[7:0]

- **Parameter**

Set [in] : OP1 negative input selection register.

OP1INN0_AI1_ENABLE	:	AI1
OP1INN0_AI4_ENABLE	:	AI4
OP1INN0_AI9_ENABLE	:	AI9
OP1INN0_REF0I_ENABLE	:	REF0I
OP1INN0_R1_fb_ENABLE	:	R1_fb
OP1INN0_OPOI_ENABLE	:	OPOI
OP1INN0_OPOS_ENABLE	:	OPOS
OP1INN0_OPO_ENABLE	:	OPO

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Selection the OP1 negative input of AI4. */  
OP1_INN0Set( OP1INN0_AI4_ENABLE );
```

### 9.2.7. OP1\_INN1Set

- **Prototype**

```
OP1_INN1Set(Set);
```

- **Description**

Select OP1 negative input selection.

Configure the register OP1NN1[2:0]

- **Parameter**

Set [in] : OP1 negative input selection register.

OP1INN1\_DAOI\_ENABLE : DAOI

OP1INN1\_AI14\_ENABLE : AI14

OP1INN1\_VSS\_ENABLE : VSS

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Selection the OP1 negative input of AI14. */  
OP1_INN1Set( OP1INN0_AI14_ENABLE );
```

### 9.2.8. OP1\_AnalogyOutSel

- **Prototype**

```
OP1_AnalogyOut(Sel);
```

- **Description**

Configure the OP1 analog output control

Configure the register OP1CN0[2:1]

- **Parameter**

Sel [in] : The analog output control

OP1OS\_DIGITAL : Disable

OP1OS\_AI0 : Output to AI0

OP1OS\_R1\_O : Output to R1\_O

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Set OP1 output to AI0 */  
OP1_AnalogOut (OP1OS_AI0);
```

### 9.2.9. OP1\_DigitalOutEnable

- **Prototype**

```
OP1_DigitalOutEnable();
```

- **Description**

Enable the OP1 digital output function.

Configure the register OP1CN0[3]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/OPA.h
```

- **Return Value**

None

- **Example**

```
/* Enable the OP1 digital output function. */  
OP1_DigitalOutEnable();
```

### 9.2.10. OP1\_DigitalOutDisable

- **Prototype**

```
OP1_DigitalOutDisable();
```

- **Description**

Disable the OP1 digital output function.

Clear the register OP1CN0[3]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/OPA.h
```

- **Return Value**

None

- **Example**

```
/* Disable the OP1 digital output function. */  
OP1_DigitalOutDisable();
```

### 9.2.11. OP1\_OutputReverse

- **Prototype**

```
OP1_OutputReverse(Set);
```

- **Description**

Configure the OP1 output phase control.

Configure the register OP1CN0[6]

- **Parameter**

Set [in] : The output phase control

OPDR\_NORMAL : Normal

OPDR\_REVERSE : Reverse

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Set the OP1 output normal phase. */
```

```
OP2_OutputSet(OPDR_NORMAL);
```

## 9.2.12. OP1\_10pF\_AppSel

- **Prototype**

```
OP1_10pF_AppSel(Sel);
```

- **Description**

Configure the OP1 built-in capacitor operating mode.

Configure the register OP1CN0[5]

- **Parameter**

Set [in] : The built-in capacitor operating mode

OPCS\_BUILT\_IN : Built-in capacitor mode, connect OPOI

OPCS\_SAMPLE : Sampling capacitor mode, connect VSS

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Set the built-in capacitor operate to Sampling capacitor mode */
```

```
OP1_10pF_AppSel (OPCS_SAMPLE);
```

## 9.2.13. OP1\_FilterEnable

- **Prototype**

```
OP1_FilterEnable();
```

- **Description**

Enable filter function.

Configure the register OP1CN0[4]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Enable filter function. */
```

```
OP1_FilterEnable();
```

## 9.2.14. OP1\_FilterDisable

- **Prototype**

```
OP1_FilterDisable();
```

- **Description**

Disable filter function.

Clear the register OP1CN0[4]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Disable filter function. */
```

```
OP1_FilterDisable();
```

## 9.2.15. OP1\_GAINSelect

- **Prototype**

```
OP1_GAINSelect(Sel);
```

- **Description**

Configure the negative feedback amplification control.

Configure the register OP1CN1[5:4]

- **Parameter**

Set [in] : Negative feedback amplification control

OPGAINS\_4 : 4 times

OPGAINS\_8 : 8 times

OPGAINS\_16 : 16 times

OPGAINS\_32 : 32 times

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* The negative feedback amplification 4 times */  
OP1_GAINSelect (OPGAINS_4);
```

## 9.2.16. OP1\_GAINSourceSel

- **Prototype**

```
OP1_GAINSourceSel(Sel);
```

- **Description**

Select the negative feedback source.

Configure the register OP1CN1[3:2]

- **Parameter**

Sel [in] : Negative feedback source

OPDIEN\_VSS : From VSS

OPDIEN\_REF0 : From REF0

OPDIEN\_AI1 : From AI1

OPDIEN\_DAIO : From DAIO

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* The negative feedback source is from AI1. */  
OP1_GAINSourceSel (OPDIEN_AI1);
```

## 9.2.17. OP1\_INT\_Trigger

- **Prototype**

```
OP1_INT_Trigger(Sel);
```

- **Description**

Configure the OP1 interrupt trigger mode.

Configure the register OP1CN1[1:0]

- **Parameter**

Sel [in] : The OP1 interrupt trigger mode

OPOEG\_EDGEFALL : Edge fall, OPC status 1→0

OPOEG\_EDGERISE : Edge rise, OPC status 0→1

OPOEG\_LEV : OPC status 1→0 or 0→1

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Set the OP1 interrupt trigger Edge fall mode. */  
OP1_INT_Trigger (OPOEG_EDGEFALL);
```

## 9.2.18. OP1\_INT\_Enable

- **Prototype**

OP1\_INT\_Enable();

- **Description**

Enable OP1 interrupt function.

Configure the register INTE2[1]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Enable OP1 interrupt function. */  
OPA_INT_Enable();
```

## 9.2.19. OP1\_INT\_Disable

- **Prototype**

OP1\_INT\_Disable();

- **Description**

Disable OP1 interrupt function.

Clear the register INTE2[1]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/OPA.h

- **Return Value**

None

- **Example**

```
/* Disable OP1 interrupt function. */  
OPA_INT_Disable();
```

### 9.2.20. OP1\_INT\_IsFlag

- **Prototype**

```
OP1_INT_IsFlag();
```

- **Description**

Read the OP1 interrupt flag.

Read the register INTF2[1]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/UART.h
```

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the OP1 interrupt flag. */  
unsigned char flag ;  
flag = OP1_INT_IsFlag();
```

### 9.2.21. OP1\_INT\_ClearFlag

- **Prototype**

```
OP1_INT_ClearFlag();
```

- **Description**

Clear the OP1 interrupt flag.

Clear the register INTF2[1]

- **Parameters**

None

- **Include**

```
Driver/HY17M/HY17M24/UART.h
```

- **Return Value**

None

- **Example**

```
/*Clear the OP1 interrupt flag. */  
OP1_INT_ClearFlag();
```

## 10. PWR Driver

### 10.1. Introduction

The following functions are included in Power Manager Section.

Item	Functions	Description
01	PWR_VDDAOpen	Enable VDDA voltage function , and VDDA voltage selection
02	PWR_BGREnable	Band gap enable control
03	PWR_BGRDisable	Band gap disable control
04	PWR_LDOEnable	VDDA LDO enable control
05	PWR_LDODisable	VDDA LDO disable control
06	PWR_VDDASel	VDDA voltage selection
07	PWR_LDOMODE	VDDA output selection
08	PWR_LDOPLEnable	Enable Output pull-down resistor
09	PWR_LDOPLDisable	Disable Output pull-down resistor
10	PWR_ENREFOEnable	Enable REFO voltage output control
11	PWR_ENREFODisable	Disable REFO voltage output control
12	PWR_REFOSel	Reference voltage selection
13	PWR_REFOISel	Select REFOI source

### 10.2. Functions

#### 10.2.1. PWR\_VDDAOpen

- **Prototype**

```
void PWR_VDDAOpen(unsigned char vdda);
```

- **Description**

Enable VDDA voltage function , and VDDA voltage selection

Configure the register PWRCN

- **Parameter**

vdda [in] : VDDA voltage selection

LDOC\_2V4 : 2.4V

LDOC\_2V6 : 2.6V

LDOC\_2V9 : 2.9V

LDOC\_3V3 : 3.3V

LDOC\_3V6 : 3.6V

LDOC\_4V0 : 4.0V

LDOC\_4V5 : 4.5V

LDOC\_5V0 : 5.0V

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/* Enable VDDA voltage function, set VDDA =2.6V */
```

```
PWR_VDDAOpen( LDOC_2V6 );
```

### **10.2.2. PWR\_BGREnable**

- **Prototype**

```
PWR_BGREnable();
```

- **Description**

Band gap enable control.

Configure the register PWRCN[7]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/* Enable Band gap voltage. */
```

```
PWR_BGREnable();
```

### **10.2.3. PWR\_BGRDisable**

- **Prototype**

```
PWR_BGRDisable();
```

- **Description**

Band gap Disable control.

Clear the register PWRCN[7]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/* Disable Band gap voltage. */  
PWR_BGRDisable();
```

## 10.2.4. PWR\_LDOEnable

- **Prototype**

```
PWR_LDOEnable();
```

- **Description**

VDDA LDO enable control.

Configure the register PWRCN[1]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/PWR.h
```

- **Return Value**

None

- **Example**

```
/* Enable VDDA LDO. */  
PWR_LDOEnable();
```

## 10.2.5. PWR\_LDODisable

- **Prototype**

```
PWR_LDODisable();
```

- **Description**

VDDA LDO disable control.

Clear the register PWRCN[1]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/PWR.h
```

- **Return Value**

None

- **Example**

```
/* Disable VDDA LDO. */  
PWR_LDODisable();
```

## 10.2.6. PWR\_VDDASel

- **Prototype**

```
PWR_VDDASel(Sel) ;
```

- **Description**

Select VDDA voltage. Need to set ENLDO=1 before output VDDA.

Configure the register PWRCN[6:4]

- **Parameter**

Sel [in] : VDDA voltage selection

LDOC\_2V4 : 2.4V

LDOC\_2V6 : 2.6V

LDOC\_2V9 : 2.9V

LDOC\_3V3 : 3.3V

LDOC\_3V6 : 3.6V

LDOC\_4V0 : 4.0V

LDOC\_4V5 : 4.5V

LDOC\_5V0 : 5.0V

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/* Set VDDA=2.4V */  
PWE_LDOEnable();  
PWR_VDDASel(LDOC_2V4 );
```

## 10.2.7. PWR\_LDOMODE

- **Prototype**

PWR\_LDOMODE(Sel) ;

- **Description**

Select VDDA source. When ENLDO=0, this set will output to VDDA port.

Configure the register PWRCN[3:2]

- **Parameter**

Sel [in] : VDDA source selection

LDOM\_DISABLE : Disable

LDOM\_VDD : Output VDD voltage

LDOM\_HIGH : Pull high to VDD by 1.5mA

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/*Output VDD voltage to VDDA */
```

```
PWR_LDODisable();  
PWR_LDOMODE(LDOM_VDD) ;
```

### **10.2.8. PWR\_LDOPLEnable**

- **Prototype**

```
PWR_LDOPLEnable();
```

- **Description**

Enable Output pull-down resistor.

Configure the register AD1CN5[4]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/* Enable Output pull-down resistor. */  
PWR_LDOPLEnable();
```

### **10.2.9. PWR\_LDOPLDisable**

- **Prototype**

```
PWR_LDOPLDisable();
```

- **Description**

Disable Output pull-down resistor.

Clear the register AD1CN5[4]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/* Disable Output pull-down resistor. */  
PWR_LDOPLDisable();
```

### **10.2.10. PWR\_ENREFOEnable**

- **Prototype**

```
PWR_ENREFOEnable();
```

- **Description**

- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/PWR.h
- **Return Value**  
None
- **Example**

```
/* Enable REFO voltage output control. */
PWR_ENREFOEnable();
```

## 10.2.11. PWR\_ENREFODisable

- **Prototype**  
`PWR_ENREFODisable();`
- **Description**  
Disable REFO voltage output control.  
Clear the register AD1CN5[3]
- **Parameter**  
None
- **Include**  
Driver/HY17M/HY17M24/PWR.h
- **Return Value**  
None
- **Example**

```
/* Disable REFO voltage output control. */
PWR_ENREFODisable();
```

## 10.2.12. PWR\_REFOSel

- **Prototype**  
`PWR_REFOSel(Sel);`
- **Description**  
Reference voltage selection.  
Configure the register AD1CN1[4:3]
- **Parameter**  
Sel [in] : Reference voltage selection
  - REFOS\_1V2 : 1.2V
  - REFOS\_2V0 : 2.0V

REFOS\_2V4 : 2.4V

REFOS\_3V0 : 3.0V

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/* Set REFO voltage=1.2V */
```

```
PWR_REFOSel(REFOS_1V2);
```

## 10.2.13. PWR\_REFOSel

- **Prototype**

```
PWR_REFOSel(Sel);
```

- **Description**

Select REFOI source.

Configure the register MCCN1[6]

- **Parameter**

Sel [in] : the input range is 0~1

VRSEL\_REFoint : From REFOint

VRSEL\_ACMint : From ACMint

- **Include**

Driver/HY17M/HY17M24/PWR.h

- **Return Value**

None

- **Example**

```
/* Set REFOI voltage source is from REFOint */
```

```
PWR_REFOSel(VRSEL_REFoint);
```

# 11. 12-bit Resistance Ladder Driver

## 11.1. Introduction

The following functions are included in 12-bit resistance ladder (the file:DrvDAC.h)Manager Section.

Item	Functions	Description
01	DAC_Open	Open the DAC
02	LADER_DASelect	DAC (positive/ negative) reference input selection.
03	LADDER_DALH_Enable	Enable 12-bit resistance ladder(DAC) internal output
04	LADDER_DALH_Disable	Disable 12-bit resistance ladder(DAC) internal output
05	LADDER.DAOE_Enable	DAC output enable
06	LADDER.DAOE_Disable	DAC output disable
07	LADDER_ENDA_Enable	Enable the DAC function
08	LADDER_ENDA_Disable	Disable the DACfunction

## 11.2. Functions

### 11.2.1. DAC\_Open

- **Prototype**

```
void DAC_Open(unsigned char daps, unsigned char dans, unsigned int dabit);
```

- **Description**

Enable the DAC · select positive and negative reference input, set the initial scale value of DAC output voltage.

Configure the register DACCN0/ DACCN1

- **Parameter**

daps [in] : DAC positive reference input selection.

DAPS\_VDDA : VDDA

DAPS\_REF0I : REF0I

DAPS\_AI0 : AI0

DAPS\_AI4 : AI4

DAPS\_AI5 : AI5

DAPS\_AI7 : AI7

DAPS\_AI9 : AI9

DAPS\_AI13 : AI13  
dans [in] : DAC negative reference input selection.

DANS\_VSS : VSS  
DANS\_REF0I : REF0I  
DANS\_AI0 : AI0  
DANS\_AI8 : AI8

dabit [in] : The scale value of output voltage DAO/4095  
DABIT[11:0]buffer from MSB to LSB, the input range is 0~4095

- **Include**

Driver/HY17M/HY17M24/ladder.h

- **Return Value**

None

- **Example**

```
/* Enable DAC, Select positive reference input=VDDA, negative reference input=VSS, DABIT=2048 */  
DAC_Open(DAPS_VDDA,DANS_VSS, 2048);
```

## 11.2.2. LADER\_DASelect

- **Prototype**

LADER\_DASelect(DAPSel,DANSel);

- **Description**

Select positive and negative reference input

Configure the register DACCN0[5:4]/ DACCN0[2:0]

- **Parameter**

daps [in] : DAC positive reference input selection.

DAPS\_VDDA : VDDA  
DAPS\_REF0I : REF0I  
DAPS\_AI0 : AI0  
DAPS\_AI4 : AI4  
DAPS\_AI5 : AI5  
DAPS\_AI7 : AI7  
DAPS\_AI9 : AI9  
DAPS\_AI13 : AI13

dans [in] : DAC negative reference input selection.

DANS\_VSS : VSS  
DANS\_REF0I : REF0I  
DANS\_AI0 : AI0  
DANS\_AI8 : AI8

- **Include**

Driver/HY17M/HY17M24/ladder.h

- **Return Value**

None

- **Example**

```
/* Select positive reference input=VDDA, negative reference input=VSS. */
```

```
LADER_DASelect (DAPS_VDDA,DANS_VSS);
```

### **11.2.3. LADDER\_DALH\_Enable**

- **Prototype**

```
LADDER_DALH_Enable();
```

- **Description**

Enable 12-bit resistance ladder(DAC) internal output

Configure the register DACCN1[3]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/ladder.h
```

- **Return Value**

None

- **Example**

```
/* Enable 12-bit resistance ladder(DAC) internal output. */
```

```
LADDER_DALH_Enable();
```

### **11.2.4. LADDER\_DALH\_Disable**

- **Prototype**

```
LADDER_DALH_Disable();
```

- **Description**

Disable 12-bit resistance ladder(DAC) internal output

Clear the register DACCN1[3]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/ladder.h
```

- **Return Value**

None

- **Example**

```
/* Disable 12-bit resistance ladder(DAC) internal output. */
```

```
LADDER_DALH_Disable();
```

### **11.2.5. LADDER.DAOE\_Enable**

- **Prototype**

```
LADDER_DAOE_Enable();
```

- **Description**

DAC output enable.

Configure the register DACCN1[1]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/ladder.h
```

- **Return Value**

None

- **Example**

```
/* DAC output enable. */
```

```
LADDER_DAOE_Enable();
```

## 11.2.6. LADDER\_DAOE\_Disable

- **Prototype**

```
LADDER_DAOE_Disable();
```

- **Description**

DAC output disable.

Clear the register DACCN1[1]

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/ladder.h
```

- **Return Value**

None

- **Example**

```
/* DAC output disable. */
```

```
LADDER_DAOE_Disable();
```

## 11.2.7. LADDER\_ENDA\_Enable

- **Prototype**

```
LADDER_ENDA_Enable();
```

- **Description**

Enable the DAC function.

Configure the register DACCN1[0]=1

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/ladder.h

- **Return Value**

None

- **Example**

```
/* Enable the DAC function. */  
LADDER_ENDA_Enable();
```

### 11.2.8. LADDER\_ENDA\_Disable

- **Prototype**

LADDER\_ENDA\_Disable();

- **Description**

Disable the DAC function.

Clear the register DACCN1[0]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/ladder.h

- **Return Value**

None

- **Example**

```
/* Disable the DAC function. */  
LADDER_ENDA_Disable();
```

## 12. I2C Driver

### 12.1. Introduction

The following functions are included in I2C Manager Section.

Item	Functions	Description
01	I2C_Open	Enable the I2C and configure the I2C bus clock
02	I2C_TimeOutOpen	Enable TimeOut function, set clock pre scale and time out limit
03	I2C_SlaveSet	Enable slave mode · set address, choose whether to enable GC
04	I2C_Ctrl	To set I2C control bit include Start, Stop, Acknowledge, Interrupt in control register.
05	I2CEnable	Enable the I2C function
06	I2CDisable	Disable the I2C function
07	I2C_TimeOutEnable	Ensable the I2C Time-out function
08	I2C_TimeOutDisable	Disable the I2C Time-out function
09	I2C_GCRstEnable	Enable I2C reset function
10	I2C_GCRstDisable	Disable I2C reset function
11	I2C_SCLCLKSet	Configure the I2C bus clock
12	I2C_SlaveModeEnable	Enable I2C slave mode
13	I2C_SlaveModeDisable	Disable I2C slave mode
14	I2C_I2CER_READ	Read the I2C error flag
15	I2C_I2CER_CLEAR	Clear the I2C error flag
16	I2C_MACTF_READ	Read the I2C master mode flag
17	I2C_SACTF_READ	Read the I2C slave mode flag
18	I2C_RDBF_READ	Read the I2C received stop/repeat-start flag
19	I2C_RWF_READ	Read the I2C read/write status flag
20	I2C_DFF_READ	Read the I2C data field flag
21	I2C_ACKF_READ	Read the I2C ACK flag
22	I2C_GCF_READ	Read the I2C general call flag
23	I2C_ARBF_READ	Read the I2C arbitration lost flag
24	I2C_I2CTF_READ	Read the Time-out flag
25	I2C_I2CTF_CLEAR	Clear the Time-out flag
26	I2C_TimeOutCLKSel	Set the time-out clock pre scale
27	I2C_TimeOutCYCSel	Set the time out limit
28	I2C_SendData	To set a byte of data to be sent.
29	I2C_ReceiveData	Read the data form receiver data buffer.
30	I2C_INT_Enable	Enable the I2C Interrupt
31	I2C_INT_Disable	Disable the I2C Interrupt
32	I2C_INT_IsFlag	Read the I2C Interrupt flag.
33	I2C_INT_ClearFlag	Clear the I2C Interrupt flag.
34	I2C_ERINT_Enable	Enable the I2C error Interrupt
35	I2C_ERINT_Disable	Disable the I2C error Interrupt
36	I2C_ERINT_IsFlag	Read the I2C error Interrupt flag.
37	I2C_ERINT_ClearFlag	Clear the I2C error Interrupt flag.

### 12.2. Functions

Note : Configure the IIC register after enable IIC

### 12.2.1. I2C\_Open

- **Prototype**

```
void I2C_Open(unsigned char dbr);
```

- **Description**

Enable the I2C and configure the I2C bus clock

Configure the register CFG0/CRG0/INTE1

- **Parameters**

dbr [in] : Set CRG value. It could be 0x00~0xff. Data Baud Rate = (I2CLK/(4\*(CRG+1)))

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Enable I2C and set CRG value 51 */  
I2C_Open(51);
```

### 12.2.2. I2C\_TimeOutOpen

- **Prototype**

```
void I2C_TimeOutOpen(unsigned int cks, unsigned char cyc);
```

- **Description**

Enable Time-Out function, and set the clock pre scale and time out limit.

Configure the register CFG0/TOC0

- **Parameters**

cks [in] : Configure Time-out clock pre scale

DI2C_CPUCKDIV1	:	CPU_CK/1
DI2C_CPUCKDIV2	:	CPU_CK/2
DI2C_CPUCKDIV4	:	CPU_CK/4
DI2C_CPUCKDIV8	:	CPU_CK/8
DI2C_CPUCKDIV16	:	CPU_CK/16
DI2C_CPUCKDIV32	:	CPU_CK/32
DI2C_CPUCKDIV64	:	CPU_CK/64
DI2C_CPUCKDIV128	:	CPU_CK/128

cyc [in] : Configure time out Limit

I2CTLT_CLKPS1	:	1*CLKPS Cycle
I2CTLT_CLKPS2	:	2*CLKPS Cycle
I2CTLT_CLKPS3	:	3*CLKPS Cycle

I2CTLT_CLKPS4	: 4*CLKPS Cycle
I2CTLT_CLKPS5	: 5*CLKPS Cycle
I2CTLT_CLKPS6	: 6*CLKPS Cycle
I2CTLT_CLKPS7	: 7*CLKPS Cycle
I2CTLT_CLKPS8	: 8*CLKPS Cycle
I2CTLT_CLKPS9	: 9*CLKPS Cycle
I2CTLT_CLKPS10	: 10*CLKPS Cycle
I2CTLT_CLKPS11	: 11*CLKPS Cycle
I2CTLT_CLKPS12	: 12*CLKPS Cycle
I2CTLT_CLKPS13	: 13*CLKPS Cycle
I2CTLT_CLKPS14	: 14*CLKPS Cycle
I2CTLT_CLKPS15	: 15*CLKPS Cycle
I2CTLT_CLKPS16	: 16*CLKPS Cycle

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Enable Time-Out function, set clock pre scale / 32 and time out limit=15 * CLKps Cycle */
I2C_TimeOutOpen (DI2C_CPUCKDIV32, I2CTLT_CLKPS15);
```

## 12.2.3. I2C\_SlaveSet

- **Prototype**

void I2C\_SlaveSet(unsigned int sid);

- **Description**

Enable slave mode, and set the location address.

Configure the register CFG0/SID0

- **Parameters**

sid [in] : Set SID value. It could be 0x00~0xFF.

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Enable Slave mode, SID setting 0xA0*/
I2C_SlaveSet ( 0xA0 );
```

## 12.2.4. I2C\_Ctrl

- **Prototype**

```
void I2C_Ctrl(unsigned char S, unsigned char P, unsigned char I, unsigned char A,)
```

- **Description**

To set I2C control bit include Start, Stop, Acknowledge, Interrupt in control register.

Configure the register ACT0

- **Parameters**

S [in] : START singal

0 : Normal

1 : Generate START or repeat START signal.

P [in] : STOP singal

0 : Normal

1 : Generate STOP singal.

I [in] : Interrupt

0 : Normal

1 : Interrupt occurred

A [in] : Acknowledge

0 : no reply ACK or reply NACK

1 : has replied ACK

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Generate START signal */
```

```
I2C_Ctrl(1,0,0,0);
```

### 12.2.5. I2CEnable

- **Prototype**

```
I2CEnable();
```

- **Description**

Enable the I2C function.

Configure the register CFG0[0]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Enable the I2C function. */
```

```
I2CEnable();
```

#### **12.2.6. I2CDisable**

- **Prototype**

```
I2CDisable();
```

- **Description**

Disable the I2C function.

Clear the register CFG0[0]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Disable the I2C function. */
```

```
I2CDisable();
```

#### **12.2.7. I2C\_TimeOutEnable**

- **Prototype**

```
I2C_TimeOutEnable();
```

- **Description**

Enable Time-Out function.

Configure the register CFG0[1]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Enable Time-Out function. */
```

```
I2C_TimeOutEnable();
```

#### **12.2.8. I2C\_TimeOutDisable**

- **Prototype**

```
I2C_TimeOutDisable();
```

- **Description**

Disable Time-Out function.

Clear the register CFG0[1]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Disable Time-Out function. */
```

```
I2C_TimeOutDisable();
```

## 12.2.9. I2C\_GCRstEnable

- **Prototype**

```
I2C_GCRstEnable();
```

- **Description**

Enable I2C reset function.

Configure the register CFG0[2]=1

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Enable I2C reset function. */
```

```
I2C_GCRstEnable();
```

## 12.2.10. I2C\_GCRstDisable

- **Prototype**

```
I2C_GCRstDisable();
```

- **Description**

Disable I2C reset function.

Clear the register CFG0[2]

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Disable I2C reset function. */  
I2C_GCRstDisable();
```

### 12.2.11. I2C\_SCLCLKSet

- **Prototype**

```
I2C_SCLCLKSet(Set);
```

- **Description**

Configure the I2C bus clock. Data Baud Rate(Hz)=I2C\_CK/[4\*(Set+1)]

Configure the register CRG0

- **Parameters**

Set [in] : Set CRG value. It could be 0x00~0xff.

- **Include**

```
Driver/HY17M/HY17M24/I2C.h
```

- **Return Value**

None

- **Example**

```
/* Set CRG value 51*/  
I2C_SCLCLKSet(51);
```

### 12.2.12. I2C\_SlaveModeEnable

- **Prototype**

```
I2C_SlaveModeEnable();
```

- **Description**

Enable I2C slave mode.

Configure the register ACT0[7]=1

- **Parameter**

None

- **Include**

```
Driver/HY17M/HY17M24/I2C.h
```

- **Return Value**

None

- **Example**

```
/* Enable I2C slave mode. */  
I2C_SlaveModeEnable();
```

### 12.2.13. I2C\_SlaveModeDisable

- **Prototype**

```
I2C_SlaveModeDisable();
```

- **Description**

Disable I2C slave mode.

Clear the register ACT0[7]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Disable I2C slave mode. */  
I2C_SlaveModeDisable();
```

## 12.2.14. I2C\_I2CER\_READ

- **Prototype**

I2C\_I2CER\_READ();

- **Description**

Read the I2C error flag.

Configure the register ACT0[4]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the I2C error flag. */  
unsigned char Flag;  
Flag=I2C_I2CER_READ();
```

## 12.2.15. I2C\_I2CER\_CLEAR

- **Prototype**

I2C\_I2CER\_CLEAR();

- **Description**

Clear the I2C error flag.

Clear the register ACT0[4]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Clear the I2C error flag. */  
I2C_I2CER_CLEAR();
```

### **12.2.16. I2C\_MACTF\_READ**

- **Prototype**

I2C\_MACTF\_READ();

- **Description**

Read the I2C master mode flag.

Read the register STA0[7]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : Disable master mode

1 : Enable master mode

- **Example**

```
/* Read the I2C master mode flag. */  
I2C_MACTF_READ();
```

### **12.2.17. I2C\_SACTF\_READ**

- **Prototype**

I2C\_SACTF\_READ();

- **Description**

Read the I2C slave mode flag.

Read the register STA0[6]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : Disable slave mode

1 : Enable slave mode

- **Example**

```
/* Read the I2C slaver mode flag. */  
I2C_SACTF_READ();
```

### **12.2.18. I2C\_RDBF\_READ**

- **Prototype**

```
I2C_RDBF_READ();
```

- **Description**

Read the I2C received stop/repeat-start flag.

Read the register STA0[5]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : Normal

1 : Received stop/repeat-start has been received or transmitted.

- **Example**

```
/* Read the I2C received stop/repeat-start flag. */  
unsigned char Flag;  
Flag=I2C_RDBF_READ();
```

### **12.2.19. I2C\_RWF\_READ**

- **Prototype**

```
I2C_RWF_READ();
```

- **Description**

Read the I2C read/write status flag.

Read the register STA0[4]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : Write command has been received or transmitted.

1 : Read command has been received or transmitted.

- **Example**

```
/* Read the I2C read/write status flag. */  
unsigned char Flag;  
Flag=I2C_RWF_READ();
```

### **12.2.20. I2C\_DFF\_READ**

- **Prototype**

```
I2C_DFF_READ();
```

- **Description**

Read the I2C data field flag.

Read the register STA0[3]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : Normal.

1 : I2C Data Byte has been transmitted or received.

- **Example**

```
/* Read the I2C data field flag. */  
unsigned char Flag;  
Flag=I2C_DFF_READ();
```

### **12.2.21. I2C\_ACKF\_READ**

- **Prototype**

```
I2C_ACKF_READ();
```

- **Description**

Read the I2C ACK flag.

Read the register STA0[2]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : Ack has been transmitted or received.

1 : Ack hasn't been transmitted or received.

- **Example**

```
/* Read the I2C ACK flag. */  
unsigned char Flag;  
Flag=I2C_ACKF_READ();
```

### **12.2.22. I2C\_GCF\_READ**

- **Prototype**

```
I2C_GCF_READ();
```

● **Description**

Read the I2C general call flag.

Read the register STA0[1]

● **Parameter**

None

● **Include**

Driver/HY17M/HY17M24/I2C.h

● **Return Value**

0 : Normal.

1 : Currently General Call Operation

● **Example**

```
/* Read the I2C general call flag. */
```

```
unsigned char Flag;
```

```
Flag=I2C_GCF_READ();
```

### 12.2.23. I2C\_ARBF\_READ

● **Prototype**

```
I2C_ARBF_READ();
```

● **Description**

Read the I2C arbitration lost flag.

Read the register STA0[0]

● **Parameter**

None

● **Include**

Driver/HY17M/HY17M24/I2C.h

● **Return Value**

0 : Normal.

1 : Arbitration Lost.

● **Example**

```
/* Read the I2C arbitration lost flag. */
```

```
unsigned char Flag;
```

```
Flag=I2C_ARBF_READ();
```

### 12.2.24. I2C\_I2CTF\_READ

● **Prototype**

```
I2C_I2CTF_READ();
```

● **Description**

Read the Time-out flag.

Read the register TOC0[7]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : Normal.

1 : I2C Bus Clock Stretching Time-Out

- **Example**

```
/* Read the Time-out flag. */  
unsigned char Flag;  
Flag=I2C_I2CTF_READ();
```

### **12.2.25. I2C\_I2CTF\_CLEAR**

- **Prototype**

I2C\_I2CTF\_CLEAR();

- **Description**

Clear the Time-out flag.

Clear the register TOC0[7]

- **Parameter**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Clear the Time-out flag. */  
I2C_I2CTF_CLEAR();
```

### **12.2.26. I2C\_TimeOutCLKSel**

- **Prototype**

I2C\_TimeOutCLKSel(cks);

- **Description**

Set the clock pre scale.

Configure the register TOC0[6:4]

- **Parameters**

cks [in] : Configure Time-out clock pre scale

DI2C\_CPUCKDIV1 : CPU\_CK/1

DI2C\_CPUCKDIV2 : CPU\_CK/2

DI2C_CPUCKDIV4	: CPU_CK/4
DI2C_CPUCKDIV8	: CPU_CK/8
DI2C_CPUCKDIV16	: CPU_CK/16
DI2C_CPUCKDIV32	: CPU_CK/32
DI2C_CPUCKDIV64	: CPU_CK/64
DI2C_CPUCKDIV128	: CPU_CK/128

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Set Time-Out clock pre scale / 32. */  
I2C_TimeOutCLKSel (DI2C_CPUCKDIV32);
```

### 12.2.27. I2C\_TimeOutCYCSel

- **Prototype**

I2C\_TimeOutCYCSel(cyc);

- **Description**

Set time out limit.

Configure the register CFG0/TOC0

- **Parameters**

cyc [in] : Configure time out Limit

I2CTLT_CLKPS1	: 1*CLKPS Cycle
I2CTLT_CLKPS2	: 2*CLKPS Cycle
I2CTLT_CLKPS3	: 3*CLKPS Cycle
I2CTLT_CLKPS4	: 4*CLKPS Cycle
I2CTLT_CLKPS5	: 5*CLKPS Cycle
I2CTLT_CLKPS6	: 6*CLKPS Cycle
I2CTLT_CLKPS7	: 7*CLKPS Cycle
I2CTLT_CLKPS8	: 8*CLKPS Cycle
I2CTLT_CLKPS9	: 9*CLKPS Cycle
I2CTLT_CLKPS10	: 10*CLKPS Cycle
I2CTLT_CLKPS11	: 11*CLKPS Cycle
I2CTLT_CLKPS12	: 12*CLKPS Cycle
I2CTLT_CLKPS13	: 13*CLKPS Cycle
I2CTLT_CLKPS14	: 14*CLKPS Cycle
I2CTLT_CLKPS15	: 15*CLKPS Cycle
I2CTLT_CLKPS16	: 16*CLKPS Cycle

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Set time out limit=15 * CLKps Cycle */  
I2C_TimeOutOpen (I2CTLT_CLKPS15);
```

### **12.2.28. I2C\_SendData**

- **Prototype**

I2C\_SendData(udata);

- **Description**

Set data to be sent.

Configure the register TDB0

- **Parameters**

udata [in] : The data to be sent, 0x00~0xff.

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Set byte data 0xa0 into transmitter data buffer register. */  
I2C_SendData(0xa0);
```

### **12.2.29. I2C\_ReceiveData**

- **Prototype**

I2C\_ReceiveData(uRec);

- **Description**

Read the data from receiver data buffer.

Read the register RDB0

- **Parameters**

udata [in] : The data to be sent, 0x00~0xff.

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

Received data

- **Example**

```
/* Read the data from receiver data buffer. */  
unsigned char Data;  
I2C_ReceiveData(Data);
```

### **12.2.30. I2C\_INT\_Enable**

- **Prototype**

I2C\_INT\_Enable()

- **Description**

Enable I2C interrupt function.

Configure the register INT1[2]=1.

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Enable I2C interrupt function. */  
I2C_INT_Enable();
```

### **12.2.31. I2C\_INT\_Disable**

- **Prototype**

I2C\_INT\_Disable()

- **Description**

Disable I2C interrupt function.

Clear the register INT1[2].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Disable I2C interrupt function. */  
I2C_INT_Disable();
```

### **12.2.32. I2C\_INT\_IsFlag**

- **Prototype**

I2C\_INT\_IsFlag()

- **Description**

Read the I2C interrupt flag.

Read the register INTF1[2].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the I2C interrupt flag. */
unsigned char flag;
flag = I2C_INT_IsFlag();
```

## 12.2.33. I2C\_INT\_ClearFlag

- **Prototype**

I2C\_INT\_ClearFlag()

- **Description**

Clear the I2C interrupt flag.

Clear the register INTF1[2].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Clear the I2C interrupt flag. */
I2C_INT_ClearFlag();
```

## 12.2.34. I2C\_ERINT\_Enable

- **Prototype**

I2C\_ERINT\_Enable()

- **Description**

Enable I2C error interrupt function.

Configure the register INTE1[3]=1.

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Enable I2C error interrupt function. */  
I2C_ERINT_Enable();
```

### 12.2.35. I2C\_ERINT\_Disable

- **Prototype**

I2C\_ERINT\_Disable()

- **Description**

Disable I2C error interrupt function.

Clear the register INTE1[3].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Disable I2C error interrupt function. */  
I2C_ERINT_Disable();
```

### 12.2.36. I2C\_ERINT\_IsFlag

- **Prototype**

I2C\_ERINT\_IsFlag()

- **Description**

Read the I2C error interrupt flag.

Read the register INTF1[3].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

0 : No interrupt

1 : Interrupt occurred

- **Example**

```
/* Read the I2C error interrupt flag. */  
unsigned char flag;  
flag = I2C_ERINT_IsFlag();
```

### **12.2.37. I2C\_ERINT\_ClearFlag**

- **Prototype**

I2C\_ERINT\_ClearFlag()

- **Description**

Clear the I2C error interrupt flag.

Clear the register INTF1[3].

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/I2C.h

- **Return Value**

None

- **Example**

```
/* Clear the I2C error interrupt flag. */
```

```
I2C_ERINT_ClearFlag();
```

## 13. BIE Driver

### 13.1. Introduction

The following functions are included in Built-In EPROM (BIE) Manager Section

Item	Functions	Description
01	BIE2_Enable	Enable BIE function
02	BIE2_Disable	Disable BIE function
03	BIE2_DataWrite	Write data to BIE
04	BIE2_Clear	Clear Information Block 2 data
05	BIE2_DataRead	Read the data of BIE

### 13.2. Functions

#### 13.2.1. BIE2\_Enable

- **Prototype**

`BIE2_Enable();`

- **Description**

Enable BIE function.

Configure the register BIE2ARH[7]=1

- **Parameters**

None

- **Include**

`Driver/HY17M/HY17M24/BIE.h`

- **Return Value**

None

- **Example**

`/* Enable BIE function. */`

`BIE2_Enable();`

#### 13.2.2. BIE2\_Disable

- **Prototype**

`BIE2_Disable();`

- **Description**

- Disable BIE function.  
Clear the register BIE2ARH[7]
- **Parameters**  
None
- **Include**  
Driver/HY17M/HY17M24/BIE.h
- **Return Value**  
None
- **Example**

```
/* Disable BIE function. */  
BIE2_Disable();
```

## 13.2.3. BIE2\_DataWrite

- **Prototype**  
`BIE2_DataWrite();`
- **Description**  
Write data to BIE. Set data into BIE writer buffer EERD0[7:0]~EERD31[7:0], before enable write control.  
Configure the register EECR1[0]=1
- **Parameters**  
None
- **Include**  
Driver/HY17M/HY17M24/BIE.h
- **Return Value**  
None
- **Example**

```
/* Write data 0x55 into BIE address 0. */  
EERD0=0x55;  
BIE2_DataWrite();
```

## 13.2.4. BIE2\_Clear

- **Prototype**  
`BIE2_Clear();`
- **Description**  
Clear Information Block 2 data.  
Configure the register BIE2CN[5]=1
- **Parameters**  
None
- **Include**  
Driver/HY17M/HY17M24/BIE.h

- **Return Value**

None

- **Example**

```
/* Clear Information Block 2 data. */  
BIE2_Clear();
```

### **13.2.5. BIE2\_DataRead**

- **Prototype**

```
BIE2_DataRead();
```

- **Description**

Read the data of BIE. BIE data will reload into EERD0~EERD31.

Configure the register EECR2/EERD0~EERD31

- **Parameters**

None

- **Include**

Driver/HY17M/HY17M24/BIE.h

- **Return Value**

None

- **Example**

```
/* Read the data of BIE. */  
BIE_DataRead();
```

## **14. Library**

### **14.1. Library File**

HY17M24 Driver C Library source code under software table H08  
CIDE\Driver\HY17M\HY17M24.

## 15. Revision History

Version	Page	Revision Summary	The Date Of Revision
V01	ALL	First edition	2020/04/28
V02	31 ~ 34	Change the defined name of HAOM HAOM_1843KHZ, HAOM_4147KHZ, HAOM_8755KHZ, HAOM_17510KHZ	2021/09/15

## 16. Library Change List

Date	Previous Version List		New version List	
	Version	Bug List	Version	Improvement
2020-03-24	V01	None	V01	None
2021-09-15	V01	None	V02	Change the defined name of HAOM